

## **INSTALLATION INSTRUCTIONS**




## **WALL MOUNTED PACKAGE AIR CONDITIONERS**

**MODELS**

**20WA1**

**24WA2**

**BARD MANUFACTURING COMPANY**  
P. O. Box 607      Bryan, Ohio 43506  
(419) 636-1194



ELECTRICAL INFORMATION									WIRING INFORMATION**		
Model	Rated Volts & Ph	Operating Voltage Range	Heater* Kw	Max Unit Amps	No. Field Power Circuits	Internal Fuses	Req'd. Ext. Fuses	Min. Ckt. Ampacity	Field Power Wiring	Ground Wire Size	Wiring Diagram Number
20WA1	230/208-1	197-253	0	12.8	1		25	16	12	12	4007-110C
			4	17.9	1		25	23	10	10	-120C
			5	22	1		30	28	10	10	-120C
			8	34.5	1		45	43	6	10	-130C
			10	42.8	1		60	53.5	6	10	-130C
24WA2	230/208-1	197-253	0	16.3	1		30	20	12	12	4007-110C
			4	17.9	1		30	23	10	10	-120C
			5	22	1		30	28	10	10	-120C
			8	34.5	1		45	43	6	10	-130C
			10	42.8	1		60	53.5	6	10	-130C

\*Electric heaters are nominal Kw @ 240V.

\*\*Based on using 60°C copper wire. Other wiring materials must be rated for marked minimum circuit ampacity or greater. Not all models approved for aluminum wire.

## APPLICATION AND INSTALLATION INSTRUCTIONS

### GENERAL

Units are shipped completely assembled and internally wired, requiring only duct connections, thermostat wiring and external 220-240 volt AC power supply. The refrigerant system is completely assembled and charged.

These instructions and any instructions packaged with any separate equipment should be carefully read before beginning the installation. Note particularly any tags and/or labels attached to the equipment.

While these instructions are intended as a general recommended guide, they do not supersede any national and/or local codes in any way. Authorities having jurisdiction should be consulted before the installation is made.

### SHIPPING DAMAGE

Upon receipt of equipment, the carton should be checked for external signs of shipping damage. If damage is found, the receiving party must contact the last carrier *immediately*, preferably in writing, requesting inspection by the carrier's agent.

### INSTALLATION

Size of unit for a proposed installation should be based on heat loss calculation made according to methods of National Warm Air Heating and Air Conditioning Association. The air duct should be installed in accordance with the Standards of the National Fire Protection Association for the Installation of Air Conditioning and Ventilating Systems of Other Than Residence Type, NFPA No. 90A, and Residence Type Warm Air Heating and Air Conditioning Systems, NFPA No. 90B. Where local regulations are at a variance with instructions, installer should adhere to local codes.

### DUCTWORK

Design the ductwork according to methods given by the National Warm Air Heating and Air Conditioning Association. When duct runs through unheated spaces, it should be insulated with a minimum of two inches of insulation. Use insulation with a vapor barrier on the outside of the insulation. Flexible joints should be used to connect the ductwork to the equipment in order to keep the noise transmission to a minimum.

A one inch clearance to combustible material for the first three feet of duct attached to the outlet air frame is required. See page 4 for further details.

### FILTER

A 1" throwaway filter is supplied with each unit. The filter slides into position making it easy to service. This filter can be serviced from the outside by removing the service door.

### FRESH AIR INTAKE

All units are built with a fresh air inlet hole punched in the service panel. The fresh air damper assembly is shipped with each unit, and must be attached at the installation site. See Fig. 3 on page 6 for typical installation procedure.

The fresh air damper assembly is standard equipment with the unit because of the variety of state or local codes requiring fresh air capability.

All capacity, efficiency and cost of operation information as required for Department of Energy "Energyguide" Fact Sheets is based upon the fresh air blank off plate in place and is recommended for maximum energy efficiency.

The blank off plate is available upon request from the factory and is installed in place of the fresh air damper shipped with each unit.

### WALL MOUNTING

1. Two holes, the size of the supply and return air openings must be cut through the wall as shown in Fig. 1 and 2 on page 5.
2. On wood-frame walls, the wall construction must be strong and rigid enough to carry the weight of the unit without transmitting any unit vibration.
3. Concrete block walls must be thoroughly inspected to insure that they are capable of carrying the weight of the installing unit.
4. Ducts through the walls must be insulated and all joints taped or sealed to prevent air or moisture entering the wall cavity.
5. Some installations may not require any return air duct. It is recommended that on this type of installation, a filter grille be located in the wall. Filters must be of sufficient size to allow a maximum velocity of 400 FPM.

### WIRING - MAIN POWER

Refer to the unit rating plate for wiring size information and maximum fuse size. Each outdoor unit is marked with a "Minimum Circuit Ampacity." This means that the field wiring used must be sized to carry that amount of current. Depending on the installed Kw of electric heat, there may be two field power circuits required. If this is the case, the unit serial plate will so indicate. Some models are suitable only for connection with copper wire, while others can be wired with either copper or aluminum wire. Each unit and/or wiring diagram will be marked "Use Copper Conductors Only" or "Use Copper or Aluminum Conductors." These instructions *MUST BE* adhered to. Refer to the National Electrical Code for complete current carrying capacity data on the various insulation grades of wiring material.

The electrical specifications on page 1 lists fuse and wire sizes (60°F copper) for all models, including the most commonly used heater sizes. Also shown are the number of field power circuits required for the various models with heaters.

The unit rating plate lists a "Maximum Time Delay Fuse" that is to be used with the equipment. The correct size fuse must be used for proper circuit protection and also to assure that there will be no nuisance tripping due to the momentary high starting current of the compressor motor.

### PRESSURE SERVICE PORTS

High and low pressure service ports are installed on all units so that the system operating pressures can be observed. Pressure curves can be found later in the manual covering all models on both cooling and heating cycles. It is imperative to match the correct pressure curve to the unit by model number.


### CONDENSATE DRAIN

A plastic drain hose extends from the drain pan at the top of the unit down to the unit base. There are openings in the unit base for the drain hose to pass through. In the event the drain hose is connected to a drain system of some type, it must be an open or vented type system to assure proper drainage.

#### FAN BLADE SETTING DIMENSIONS

Shown in the drawing below are the correct fan blade setting dimensions for proper air delivery across the outdoor coil.

Any service work requiring removal or adjustment in the fan and/or motor area will require that the dimensions below be checked and blade adjusted in or out on the motor shaft accordingly.



MODEL	DIM.A	DIM.C
20WA1	3/4"	1-1/2"
24WA2	3/4"	1-1/4"

#### FAN BLADE REMOVAL

To facilitate removal of the fan blade for replacement or inspection, it is easiest to remove the air inlet grille on the right side (located under the electrical connections to the cabinet), and then to remove the three screws securing the fan enclosure to the coil and the three screws securing the fan enclosure to the unit base. The three screws at the opposite end that secure the fan enclosure to the coil remain in place. The fan enclosure can then be swung back towards the rear of the unit, gaining enough clearance for the fan blade to be extruded from the unit.



Reverse the above procedure to put the unit back into an operating condition. Be sure to adjust the fan blade to the correct setting as shown under "Fan Blade Setting Dimensions" before locking down the set screws on to the flats of the motor shaft.

#### REFRIGERANT CHARGE



The correct system R-22 charge is shown on the unit rating plate. Optimum unit performance will occur with a refrigerant charge resulting in a suction line temperature (6" from compressor) as shown in the following table:

Model	Rated Airflow	95°F OD Temp.	82°F OD Temp.
20WA1	710	56-58	63-65
24WA2	815	51-53	56-58

The above suction line temperatures are based upon 80°F dry bulb/67°F wet bulb (50% R.H.) temperature and rated airflow across the evaporator during cooling cycle.



**NOTE: 1" clearance to combustible materials required  
for first 3 feet of supply air duct system.**



**Models 20WA1 & 24WA2**

MOUNTING ON CONCRETE BLOCK WALL

These units are secured by wall mounting brackets which secure the unit to the outside wall surface at both sides and at the bottom. (Fig. 1).

In a standard 8 x 16 in. block wall, saw or knock out two 22 inch sections of concrete blocks normally the 7th, 8th and 11th course of blocks above floor level. In both cases, this should be one whole block plus 3 in. of the block on each side.

On the wall, lay out approximately the position for the bottom and side brackets. Fasten these brackets to the wall firmly with 3/8 in. lag screws.

The side brackets should be located approximately 15 in. down from the top of the unit and fastened to both sides with metal screws.

After mounting the unit on the wall, a metal weather stripping should be installed at the top to insure a water tight application.

INSTALLATION SCHEMATIC




Fig. 1

**Models 20WA1 & 24WA2**

MOUNTING ON WOOD FRAME WALLS

Locate and cut out two openings as shown in (Fig. 2). Cut away the outside siding to the depth of the sheathing. Install metal weather stripping at the top and caulk or otherwise seal joints between siding and sheathing. Frame in the openings between the wall studs as necessary for the particular wall involved with the plates at the bottom of each wall opening being sufficiently strong to carry the weight of the unit.

Install the two side brackets to the unit (15 in. down from the top). Mount unit on wall and pull in firmly using three 3/8 in. lag screws through each of the wall mounting brackets.

For additional mounting rigidity, each air opening collar may be screwed to the plate at the bottom of each wall opening. Drill two 1/4 in. holes in the bottom flange of each collar before hanging the unit, then fasten to wall plate with No. 10 by 1-1/2 in. wood screws.

OUTSIDE FRAME WALL SCHEMATIC






Fig. 2

SUPPLY AIR METAL DUCT LINER  
MODELS WA AND WH

The cabinets on all models, with or without electric heaters, are approved for 0" clearance to combustible materials. The outlet duct on all models with electric heaters must have 1" clearance to combustible materials for at least the first 3 feet of duct.

Whenever a model WA or WH is installed, a galvanized metal duct liner must always be attached (Fig. 1). Before installing, determine the wall thickness. If the installation is free air flow, with no external duct, then the liner should be cut flush with the inside wall opening. In order to insure no sweating, the duct liner should be wrapped with a minimum of 1" insulation.



The galvanized metal duct liner is to be fabricated to the same size as the supply air opening. Fasten duct liner to unit before mounting and tape all joints.

COOLING AND HEATING ANTICIPATION  
FOR WALL THERMOSTATS

All 24v wall thermostats are built with both cooling and heating anticipators. The purpose of these anticipators is to compensate the thermostat for various system controls and allow the best possible cycle rates.

The cooling anticipator for all thermostats, and the heating anticipator on a limited number, are fixed and require no adjustment. Most heating anticipators are adjustable and DO REQUIRE ADJUSTMENT to match the current rating of the relay, contactor or other control being cycled by that heating stage. In the case of a two stage heating thermostat there will be an anticipator for each stage, either both adjustable, one fixed and one adjustable, or both fixed.


The fixed anticipators are rated for a maximum of 1.5A. The adjustable anticipators generally have a range of .2 - 1.2A, and MUST BE ADJUSTED. Failure to adjust the anticipator lever to correspond to the actual current draw passing through that stage mercury switch and anticipator will cause severe short cycling conditions if set too low and room temperature may never attain the thermostat set point, and if set too high, will cause room temperature over-shoot.

While oil burner primary controls and gas valves are normally marked with the nominal current rating, the contactors and relays installed in air conditioners and heat pumps are not. Listed below are some of the more popularly used controls and their nominal current ratings.

Contactor or Relay	Nominal Current Rating
Honeywell - R810B Series	.55
- R8110 Series	.40
- R8112 Series	.40
- R8114 Series	.40
- R8122 Series	.38
- R8128 Series	.38
- R8142 Series	.38
- R8143 Series	.38
RBM	
- Type 84	.12
- Type 91	.36
- Type 112	.34
- Type 143	.34
- Type 154	.26
- Type 184	.12
Elmwood	
- 308020	.39
- 308020	.39
- 308020	.39
- 308020	.21
- 308030	.21
- 308030	.21

Below is a procedure which allows accurate low amperage current measurements with a standard clamp-on ammeter with a 0-6A range. It is actually recommended that this measurement always be taken, since variations in voltage, thermostat wire length, etc. can all cause some change in current draw.

1. Wrap exactly 10 loops of thermostat wire (W1) around the prongs of an Amprobe.
2. Let the heating system operate for one minute before reading the W1 or W2 current draw.
3. Divide the reading obtained in Step 2 by 10.
4. Use the value calculated in step 3 to set the heat anticipator.
5. Repeat the procedure for (W2) if 2-stage heat.








Fig. 3


BARD MANUFACTURING COMPANY  
20WA1



Cooling curves are based on 80° ab 67°W and  
rated CFM (air flow) across the indoor coil.

BARD MANUFACTURING COMPANY  
24WA2






MODELS  
20WA1 & 24WA2

Factory Wiring \_\_\_\_\_  
Field Wiring - - - - -


4007-110 C



Models  
20WA1 & 24WA2  
w/4 or 5kW

Factory Wiring \_\_\_\_\_  
Field Wiring - - - - -

4007-120 C



- 1** Capacitor provides off-cycle crankcase heat.
- 2** See alternate thermostat sheet. Set heat anticipator at .40A.

230/208-60-1

Fused  
Disconnect  
Switch

Models  
20WA1 & 24WA2  
w/8 or 10Kw

Factory Wiring \_\_\_\_\_  
Field Wiring - - - - -

4007-130 C

PARTS LIST  
SINGLE PACKAGE AIR CONDITIONERS

PART NO.	DESCRIPTION	20WA1	24WA2
5152-030	Blower Housing 9-7	X	X
5152-028	Blower Wheel 9-7	X	X
5152-029	Blower Wheel 9-7	X	X
8552-027	Capacitor 25/370V	X	X
8552-002	Capacitor 5/370V	X	X
5811-021	Capillary Tube - Cool	X	
5811-020	Capillary Tube - Cool		X
8000-061	Compressor RES3-0175-PFV-270	X	
8000-062	Compressor AB224FT-014-A4		X
5051-017	Condenser Coil	X	
5051-025	Condenser Coil		X
8401-007	Contactor - Comp. 25A	X	X
8401-006	Contactor - Heater 2P18	X	X
5060-024	Evaporator Coil	X	X
5151-024	Fan Blade A-1831-5	X	X
7004-006	Filter 14x25	X	X
8604-041	Heat Strip 4Kw	X	X
8604-042	Heat Strip 5Kw	X	X
8604-043	Heat Strip 8Kw	X	X
8604-044	Heat Strip 10Kw	X	X
8402-029	Limit Switch 160°	X	X
8102-008	Motor - Blower 1/6 hp	X	X
8103-009	Motor - Fan 1/5 hp	X	X
8552-004	Capacitor 7.5/370V	X	X
8200-023	Motor Mount - Fan	X	X
5210-002	Strainer	X	X
8201-009	Relay - Blower	X	X
8607-006	Terminal Board 24V	X	X
8607-001	Terminal Block 230V	X	X
8402-030	Thermal Cut-off	X	X
8407-007	Transformer 40VA	X	X

IMPORTANT

PURCHASER'S RESPONSIBILITIES

Below are the responsibilities of the purchaser and these items cannot be considered as defects in workmanship or material.

1. Air filter cleaning or replacement.
2. Failure to operate due to improper air distribution over indoor and outdoor equipment sections.
3. Failure to start due to voltage conditions, blown fuses or other damage due to inadequacy or interruption of electrical service.
4. Damage caused directly or indirectly by improper installation.
5. Damage due to lack of proper and periodic maintenance.
6. Damage resulting from transportation, moving or storage of unit.
7. Unit must be readily accessible for servicing and/or repair at all times.
8. Any adjustment or service to the unit should be made by qualified service personnel.
9. Misapplication of product.

MODEL NO. \_\_\_\_\_ SERIAL NO. \_\_\_\_\_ DATE  
INSTALLED \_\_\_\_\_

INSTALLER: Please fill in above blanks and leave this manual with equipment owner/operator.

