

ORIGINAL

MANUAL 2100-038A

INSTALLATION INSTRUCTIONS




WALL MOUNTED PACKAGE AIR CONDITIONERS

MODELS

42WA

49WA

BARD MANUFACTURING COMPANY
P. O. Box 607 Bryan, Ohio 43506
(419) 636-1194



ELECTRICAL INFORMATION								WIRING INFORMATION**			
MODEL	Rated Volts & Ph	Operating Voltage Range	Heater* KW	Max Unit Amps	No. Field Power Circuits	Internal Fuses Ckt. A/B	Required Δ Overcurrent Protection	Min. Ckt. Ampacity Ckt. A/B	Field Power Wiring Ckt. A/B	Ground Wire Size Ckt. A/B	Wiring Diagram Number
42WA	230/208-1	197-253	0	27.8	1		50	33	8	10	4010-110F -120F -130F -140G -150H
			5	27.8	1		50	33	8	10	
			10	45.6	1		60	57	4	10	
			15	66.5	1		90	83	3	8	
			20	87.2	1		110	109	1	6	
42WA	230/208-3	187-253	0	19.8	1		35	24	10	10	4010-210D -220F -230E -230E -240E
			9	25.7	1		35	32	8	10	
			12	32.9	1		45	41	6	10	
			15	40.2	1		50	50	6	10	
			18	47.4	1		60	59	4	10	
42WA	460-3	414-506	0	11.4	1		20	15	14	14	4010-310C -320C -320C -320C -330C
			9	12.8	1		20	17	12	12	
			12	16.2	1		25	22	10	10	
			15	20	1		30	26	10	10	
			18	23.7	1		35	31	8	10	
49WA	230/208-1	197-253	0	29.8	1		50	35	8	10	4010-110F -120F -130F -140G -150H
			5	29.8	1		50	35	8	10	
			10	45.6	1		60	56	4	10	
			15	66.5	1		90	83	3	8	
			20	87.2	1		110	109	1	6	
49WA	230/208-3	187-253	0	22.8	1		35	25	10	10	4010-210D -220F -230E -230E -240E
			9	25.7	1		40	32	8	10	
			12	32.9	1		45	41	6	10	
			15	40.2	1		50	50	6	10	
			18	47.4	1		60	59	4	10	
49WA	460-3	414-506	0	11.4	1		20	15	14	14	4010-310C -320C -320C -320C -330C
			9	12.8	1		20	17	12	12	
			12	16.4	1		25	22	10	10	
			15	20	1		30	26	10	10	
			18	23.7	1		35	31	8	10	

*Electric heaters are nominal KW @ 240V or 480V.

**Based on 60°C copper wire. Other wiring materials must be rated for marked minimum circuit ampacity or greater. Not all models are approved for aluminum wire.

Δ Time delay fuses or "HACR Type" circuit breakers must be used for 60 and smaller sizes. Standard fuses or circuit breakers suitable for sizes 70 and larger.

APPLICATION AND INSTALLATION INSTRUCTIONS FOR WA PACKAGE AIR CONDITIONERS

IMPORTANT

The equipment covered in this manual is to be installed by trained, experienced service and installation technicians. Any heat pump is more critical of proper operating, charge and an adequate duct system than a straight air conditioning unit. All ductwork, supply and return, must be properly sized for the design air flow requirement of the equipment. NESCA is an excellent guide to proper sizing. All duct work or portions thereof not in the conditioned space should be properly insulated in order to both conserve energy and prevent condensation or moisture damage.

SHIPPING DAMAGE

Upon receipt of equipment, the carton should be checked for external signs of shipping damage. If damage is found, the receiving party must contact the last carrier immediately, preferably in writing, requesting inspection by the carrier's agent.

GENERAL

The refrigerant system is completely assembled and charged. All internal wiring is complete.

The unit is designed for use with or without duct work. Flanges are provided for attaching the supply and return ducts.

These instructions explain the recommended method to install the air cooled self-contained unit and the electrical wiring connections to the unit.

These instructions and any instructions packaged with any separate equipment required to make up the entire air conditioning system should be carefully read before beginning the installation. Note particularly "Starting Procedure" and any tags and/or labels attached to the equipment.

While these instructions are intended as a general recommended guide, they do not supersede any national and/or local codes in any way. Authorities having jurisdiction should be consulted before the installation is made.

INSTALLATION

Size of unit for a proposed installation should be based on heat loss calculation made according to methods of National Warm Air Heating and Air Conditioning Association. The air duct should be installed in accordance with the Standards of the National Fire Protection Association for the Installation of Air Conditioning and Ventilating Systems of Other Than Residence Type, NFPA No. 90A, and Residence Type Warm Air Heating and Air Conditioning Systems, NFPA No. 90B. Where local regulations are at a variance with instructions, installer should adhere to local codes.

DUCTWORK

Design the ductwork according to methods given by the National Warm Air Heating and Air Conditioning Association. When duct runs through unheated spaces, it should be insulated with a minimum of two inches of insulation. Use insulation with a vapor barrier on the outside of the insulation. Flexible joints should be used to connect the ductwork to the equipment in order to keep the noise transmission to a minimum.

A one inch clearance to combustible material for the first three feet of duct attached to the outlet air frame is required. See page 6 for further details.

FILTER

A 1" throwaway filter is supplied with each unit. The filter slides into position making it easy to service. This filter can be serviced from the outside by removing the service door.

FRESH AIR INTAKE

All units are built with a fresh air inlet hole punched in the service panel. The fresh air damper assembly is shipped with each unit, and must be attached at the installation site. See Figure 1 for typical installation procedure.

The fresh air damper assembly is standard equipment with the unit because of the variety of state or local codes requiring fresh air capability.

All capacity, efficiency and cost of operation information as required for Department of Energy "Energy-guide" Fact Sheets is based upon the fresh air blank-off plate in place and is recommended for maximum energy efficiency.

The blank-off plate is available upon request from the factory and is installed in place of the fresh air damper shipped with each unit.

WALL MOUNTING

1. Two holes, the size of the supply and return air openings must be cut through the wall as shown in Figure 2.
2. On wood-frame walls, the wall construction must be strong and rigid enough to carry the weight of the unit without transmitting any unit vibration.
3. Concrete block walls must be thoroughly inspected to insure that they are capable of carrying the weight of the installing unit.
4. Ducts through the walls must be insulated and all joints taped or sealed to prevent air or moisture entering the wall cavity.
5. Some installations may not require any return air duct. It is recommended that on this type of installation that a filter grille be located in the wall. Filters must be of sufficient size to allow a maximum velocity of 400 FPM.

WIRING - MAIN POWER

Refer to the unit rating plate for wire sizing information and maximum fuse or "HACR Type" circuit breaker size. Each outdoor unit is marked with a "Minimum Circuit Ampacity." This means that the field wiring used must be sized to carry that amount of current. Depending on the installed Kw of electric heat, there may be two field power circuits required. If this is the case, the unit serial plate will so indicate. Some models are suitable only for connection with copper wire, while others can be wired with either copper or aluminum wire. Each unit and/or wiring diagram will be marked "Use Copper Conductors Only" or "Use Copper or Aluminum Conductors." These instructions MUST BE adhered to. Refer to the National Electrical Code for complete current carrying capacity data on the various insulation grades of wiring material.

The electrical data lists fuse and wire sizes (60°F copper) for all models, including the most commonly used heater sizes. Also shown are the number of field power circuits required for the various models with heaters.

The unit rating plate lists a "Maximum Time Delay Fuse" or "HACR Type" circuit breaker that is to be used with the equipment. The correct size must be used for proper circuit protection and also to assure that there will be no nuisance tripping due to the momentary high starting current of the compressor motor.

IMPORTANT INSTALLER NOTES:

1. For improved start-up performance wash the indoor coil with a dishwasher detergent.

PRESSURE SERVICE PORTS

High and low pressure service ports are installed on all units so that the system operating pressures can be observed. Pressure curves can be found later in the manual covering all models on both cooling and heating cycles. It is imperative to match the correct pressure curve to the unit by model number.

CRANKCASE HEATERS

All units are provided with some form of compressor crankcase heat. Some single phase units utilize the compressor motor start winding in series with a portion of the run capacitor to generate heat within the compressor shell to prevent liquid refrigerant migration.

Some three phase units utilize a wraparound type of crankcase heater that warms the compressor oil from the outside.

Some single and three phase models have an insertion well-type heater located in the lower section of the compressor housing. This is a self-regulating type heater that draws only enough power to maintain the compressor at a safe temperature.

Some form of crankcase heat is essential to prevent liquid refrigerant from migrating to the compressor, causing oil pump out on compressor start-up and possible valve failure due to compressing a liquid.

Refer to unit wiring diagram to find exact type of crankcase heater used.

The following decal is affixed to all outdoor units detailing start-up procedure. This is very important. Please read carefully.

IMPORTANT

THESE PROCEDURES MUST BE FOLLOWED AT INITIAL START-UP AND AT ANY TIME POWER HAS BEEN REMOVED FOR 12 HOURS OR LONGER.

TO PREVENT COMPRESSOR DAMAGE WHICH MAY RESULT FROM THE PRESENCE OF LIQUID REFRIGERANT IN THE COMPRESSOR CRANKCASE


1. MAKE CERTAIN THE ROOM THERMOSTAT IS IN THE "OFF" POSITION (THE COMPRESSOR IS NOT TO OPERATE).
2. APPLY POWER BY CLOSING THE SYSTEM DISCONNECT SWITCH THIS ENERGIZES THE COMPRESSOR HEATER WHICH EVAPORATES THE LIQUID REFRIGERANT IN THE CRANKCASE.
3. ALLOW 4 HOURS OR 60 MINUTES PER POUND OF REFRIGERANT IN THE SYSTEM AS NOTED ON THE UNIT RATING PLATE, WHICHEVER IS GREATER.
4. AFTER PROPERLY ELAPSED TIME THE THERMOSTAT MAY BE SET TO OPERATE THE COMPRESSOR.
5. EXCEPT AS REQUIRED FOR SAFETY WHILE SERVICING — **DO NOT OPEN SYSTEM DISCONNECT SWITCH.**

7961-061

FAN BLADE SETTING DIMENSIONS

Shown in the drawing below are the correct fan blade setting dimensions for proper air delivery across the outdoor coil.

Any service work requiring removal or adjustment in the fan and/or motor area will require that the dimensions below be checked and blade adjusted in or out on the motor shaft accordingly.



REFRIGERANT CHARGE

The correct system R-22 charge is shown on the unit rating plate. Optimum unit performance will occur with a refrigerant charge resulting in a suction line temperature (6" from compressor) as shown in the following table:

MODEL	AIRFLOW	95°F O.D. Temp.	82°F O.D. Temp.
42WA	1575	57-59	67-69
49WA	1725	60-62	68-70


The above suction line temperatures are based upon 80°F dry bulb/67°F wet bulb (50% R.H.) temperature and rated airflow across the evaporator during cooling cycle.

RATED CFM AND E.S.P. (WET COIL—COOLING)			
MODEL	RATED CFM	RATED E.S.P.	RECOMMENDED AIRFLOW RANGE
42WA	1575	.40	1440-1700 CFM
49WA	1725	.30	1440-1900 CFM

INDOOR BLOWER PERFORMANCE CFM — DRY COIL WITH FILTER	
E.S.P. Inches H ₂ O	MODEL 42WA, 49WA
.0	2125
.1	2035
.2	1950
.3	1845
.4	1735
.5	1620
.6	1490

UNIT MODELS


20WA1
24WA2
18WH2
24WH2




Model FAD10
Fresh Air Cover
With Adjustable
Damper

UNIT MODELS




30WA2
36WA4
30WH1
36WH2
42WA
49WA
48WH2



MODEL FAD25
Fresh Air Cover
With Adjustable
Damper



Insert top flange of fresh air cover into opening in service door and push top of cover assembly all the way to top of opening.




Secure bottom of Fresh Air Cover Assembly with two screws.

FIGURE 1

SIDE VIEW

WALL VIEW




MOUNTING INSTRUCTIONS

1. These units are secured by wall mounting brackets which secure the unit to the outside wall surface at both sides and at the bottom.
2. The unit itself is suitable for "0" inch clearance, but the supply air duct flange and the first few feet of supply air duct require 1 inch clearance to combustible material. If combustible wall, use K and L dimensions for sizing, if non-combustible, use D and J.
3. After the wall opening positions have been selected, lay out the position for the bottom and side brackets. Fasten the brackets securely to the wall (type of fasteners will depend on wall construction).
4. Be sure to observe the P dimension when attaching the side brackets. This will assure that no screws are driven into the unit sides damaging any internal parts. One-half inch sheet metal screws are recommended.
5. For additional mounting rigidity, the return air and supply air (depending upon wall construction) frames or collars can be drilled and screwed or welded to the structural wall itself. Be sure to observe required clearance if combustible wall.


MODEL	A	B	C	D	E	F	G	J	K	L	M	N	P	Q
20WA1, 24WA2	32-1/4	13-1/2	69-3/8	8	20-1/2	12	27-1/2	20	22	10	19-1/2	24	10	31
18WH2, 24WH2	32-1/4	13-1/2	69-3/8	8	20-1/2	12	27-1/2	20	22	10	19-1/2	24	10	31
30WA2, 36WA4	38-1/4	15-1/4	74	8	18	14	32-5/8	28	30	10	17	34	10	31
30WH1, 36WH2	38-1/4	15-1/4	74	8	18	14	32-5/8	28	30	10	17	34	10	31
42WA, 49WA	42	22	84	10	30	16	26-5/8	30	32	12	29	34	10	42
48WH2	42	22	84	10	30	16	26-5/8	30	32	12	29	34	10	42



FIGURE 2



BARD MANUFACTURING COMPANY
MODEL 49WA







BARD MANUFACTURING COMPANY
MODEL 49WA

















4010-310



4010-240E



PARTS LIST
SINGLE PACKAGE AIR CONDITIONERS

Effective 9-16-81
Supersedes 7-24-81

PART NO.	DESCRIPTION	42WA	42WA-3	49WA	49WA-3	42WA-3 460V	49WA-3 460V	49WA-3 460V
* 5152-011	Blower Housing	X	X	X	X	X	X	X
5152-012	Blower Wheel DD10-8A	X	X	X	X	X	X	X
8552-028	Capacitor - Comp. 35/440V	X	X	X	X	X	X	X
8552-005	Capacitor - Blower	X	X	X	X	X	X	X
8552-026	Capacitor - Fan	X	X	X	X	X	X	X
8552-030	Capacitor - Comp. 40/440V	(2)	(2)	(2)	(2)	(2)	(2)	(2)
5811-021	Capillary Tube - Cool	X	X	X	X	X	X	X
8000-058	Compressor CRJ1-0300-PFV-270	X	X	X	X	X	X	X
8000-059	Compressor CRJ1-0300-TFS-270	X	X	X	X	X	X	X
8000-063	Compressor CRK1-0325-PFV-270	X	X	X	X	X	X	X
8000-064	Compressor CRK1-0325-TFS-270	X	X	X	X	X	X	X
8000-060	Compressor CRJ1-0300-TFD-270	X	X	X	X	X	X	X
8000-065	Compressor CRK1-0325-TFD-270	X	X	X	X	X	X	X
5051-027	Condenser Coil	X	X	X	X	X	X	X
5051-028	Condenser Coil	X	X	X	X	X	X	X
8401-007	Contact - Comp. 25A	X	X	X	X	X	X	X
8401-002	Contact - 25A	X	X	X	X	X	X	X
8401-006	Contact - Heater 24V	X	X	X	X	X	X	X
8401-003	Contact - Comp. 30A	X	X	X	X	X	X	X
5060-025	Evaporator Coil	X	X	X	X	X	X	X
5151-021	Fan Blade B2430-4 ccw	X	X	X	X	X	X	X
7004-016	Filter 20x30	X	X	X	X	X	X	X
8614-017	Fuse Block 15Kw	X	X	X	X	X	X	X
8614-018	Fuse Block 20Kw	X	X	X	X	X	X	X
8614-022	Fuse 60A	X	X	X	X	X	X	X
8614-006	Fuse 30A	X	X	X	X	X	X	X
8614-007	Fuse 60A	X	X	X	X	X	X	X
8604-042	Heat Strip 5Kw	X	X	X	X	X	X	X
8604-044	Heat Strip 10Kw	X	X	X	X	X	X	X
8604-047	Heat Strip 15Kw	X	X	X	X	X	X	X
8604-048	Heat Strip 9Kw	X	X	X	X	X	X	X
8604-046	Heat Strip 12Kw	X	X	X	X	X	X	X
8604-050	Heat Strip 9Kw	X	X	X	X	X	X	X
8604-051	Heat Strip 12Kw	X	X	X	X	X	X	X
8402-024	Limit Switch L180-4	X	X	X	X	X	X	X
8106-014	Motor - Blower 1/2 hp	X	X	X	X	X	X	X
8105-021	Motor - Fan 1/3 hp	X	X	X	X	X	X	X
8201-009	Relay - Blower	X	X	X	X	X	X	X
8201-008	Relay - Blower Heat/Cool	X	X	X	X	X	X	X
8200-004	Motor Mount - Fan	X	X	X	X	X	X	X
5210-005	Strainer	X	X	X	X	X	X	X
8607-005	Terminal Board 24V	X	X	X	X	X	X	X
8607-001	Terminal Block 230V	X	X	X	X	X	X	X
8607-002	Terminal Block	X	X	X	X	X	X	X
8402-032	Thermal Cuf-off	X	X	X	X	X	X	X
8407-007	Transformer 40VA	X	X	X	X	X	X	X
8407-015	Transformer 55VA	X	X	X	X	X	X	X
8407-004	Transformer - Stepdown	X	X	X	X	X	X	X

* Please order by model number.
** Denotes Change.

[Faint, illegible text, possibly bleed-through from the reverse side of the page]

