


**INSTALLATION INSTRUCTIONS**

**WALL MOUNTED  
PACKAGE AIR CONDITIONERS**

**MODELS**

MAC30A

MAC36A



NOTE: Maintain minimum 30" clear space on right and front for service access.

### SPECIFICATIONS

MODEL	MAC30A-A00	MAC30A-A05	MAC30A-A10	MAC30A-A15	MAC36A-A00	MAC36A-A05	MAC36A-A10	MAC36A-A15
Heater Kw @ 240/208V	None	5/3.75	10/7.5	15*/11.25	None	5/3.75	10/7.5	15*/11.25
Cooling Capacity Btu/h	30,600	30,600	30,600	30,600	35,400	35,400	35,400	35,400
Heating Capacity Btu/h**	None	19,000/ 15,000	36,000/ 27,000	53,000/ 40,000	None	19,000/ 15,000	36,000/ 27,000	53,000/ 40,000
Electrical Rating -- 60Hz	230/208-1	230/208-1	230/208-1	230/208-1	230/208-1	230/208-1	230/208-1	230/208-1
Operating Voltage Range	197-253	197-253	197-253	197-253	197-253	197-253	197-253	197-253
Minimum Circuit Ampacity	25	31	57	83	30	31	57	83
No. Field Power Ckts.	1	1	1	1	1	1	1	1
**Field Wire Size	#10	#8	#4	#2	#10	#8	#4	#2
Ground Wire Size	#10	#10	#10	#8	#10	#10	#10	#8
***Req'd Max. External Fuses	40	40	60	90+	45	45	60	90+
Total Unit Amps 240/208	18.3/19.8	24.7/22.0	45.5/40.1	66.4/58.0	22.3/23.8	24.7/23.8	45.5/40.1	66.4/58.0
Internal Fuses (Standard)	None	None	None	60/30	None	None	None	60/30
Internal Circuit Breakers (Option C)	40	40	60	60, 30	45	45	60	60, 30
Compressor -- Circuit A								
Volts	230/208				230/208			
Rated Load Amps 230/208	13/14.5				17/18.5			
Branch Circuit Selection Current	15.5				19.5			
Lock Rotor Amps	81/81				97/97			
Fan Motor & Condenser								
Fan Motor -- HP/RPM	1/5/1050				1/5/1050			
Fan Motor -- AMPS	1.4				1.4			
Fan -- DIA/CFM	20"/1800				20"/1800			
Face Area Sq.Ft./Row/Fins per in.	4.7/2/12				4.7/2/12			
Motor and Evaporator								
Blower Motor -- HP/RPM	1/2/1600				1/2/1600			
Blower Motor - Amps	3.9				3.9			
CFM Cooling & E.S.P. w/Filter (Rated) (Hi)	1000/.30				1060/.15			
Face Area Sq.Ft./Row.Fins per in.	2.7/2/13				2.7/2/13			
Filter Sizes (Inches)	14x25x1				14x25x1			
Refrigerant 22 -- oz.	62				56			
Shipping Weight -- lbs.	310				315			

\*15Kw models must be installed using high speed only.



\*\*60°C copper wire size.

\*\*\*Maximum time delay fuse or HACR type circuit breaker.

+Sizes 70A or greater are not HACR type.

++includes blower motor.

Specifications subject to change without notice.

NOMENCLATURE EXPLANATION	IMPORTANT
<p>Example:</p> <p>MAC36A-A10/C</p> <ul style="list-style-type: none"> <li>Basic Model</li> <li>Modification Code</li> <li>Optional Equipment (Built in Circuit Breakers)</li> <li>KW Electric Heat</li> <li>Electrical Characteristics (230/208-1-60)</li> <li>Nominal Capacity</li> </ul>	<p>While this electrical data is presented as a guide, it is important to electrically connect, properly sized fuses and conductor wires in accordance with the National Electrical Code and all existing local codes.</p> <div style="text-align: center;">   </div> <p>CERTIFIED LISTED Underwriters Listed for outdoor Installation.</p>

## IMPORTANT

The equipment covered in this manual is to be installed by trained, experienced service and installation technicians. Any heat pump is more critical of proper operating, charge and an adequate duct system than a straight air conditioning unit. All duct work supply and return, must be properly sized for the design air flow requirement of the equipment. ACCA is an excellent guide to proper sizing. All duct work or portions thereof not in the conditioned space should be properly insulated in order to both conserve energy and prevent condensation or moisture damage.

## SHIPPING DAMAGE

Upon receipt of equipment, the carton should be checked for external signs of shipping damage. If damage is found, the receiving party must contact the last carrier immediately, preferably in writing, requesting inspection by the carrier's agent.

## GENERAL

The refrigerant system is completely assembled and charged. All internal wiring is complete.

The unit is designed for use with or without duct work. Flanges are provided for attaching the supply and return ducts.

These instructions explain the recommended method to install the air cooled self-contained unit and the electrical wiring connections to the unit.

These instructions and any instructions packaged with any separate equipment required to make up the entire air conditioning system should be carefully read before beginning the installation. Note particularly "Starting Procedure" and any tags and/or labels attached to the equipment.

While these instructions are intended as a general recommended guide, they do not supersede any national and/or local codes in any way. Authorities having jurisdiction should be consulted before the installation is made.

## INSTALLATION

Size of unit for a proposed installation should be based on heat loss calculation made according to methods of Air Conditioning Contractors of America (ACCA). The air duct should be installed in accordance with the Standards of the National Fire Protection Association for the Installation of Air Conditioning and Ventilating systems of Other Than Residence Type, NFPA No. 90A, and Residence Type Warm Air Heating and Air Conditioning Systems, NFPA No. 90B. Where local regulations are at a variance with instructions, installer should adhere to local codes.

## DUCT WORK

Design the duct work according to methods given by the Air Conditioning Contractors of America. When duct runs through unheated spaces, it should be insulated with a minimum of one inch of insulation. Use insulation with a vapor barrier on the outside of the insulation. Flexible joints should be used to connect the duct work to the equipment in order to keep the noise transmission to a minimum.

A one-inch clearance to combustible material for the first three feet of duct attached to the outlet air frame is required. See page 3 for further details.

## FILTER

A one inch throwaway filter is supplied with each unit. The filter slides into position making it easy to service. This filter can be serviced from the outside by removing the service door.

## FRESH AIR INTAKE

All units are built with a fresh air inlet opening punched in the left unit side. This opening is covered by a factory installed blank off plate, model BOP20.

A fresh air damper assembly, model FAD20, may be ordered separately to accommodate the variety of state and local codes requiring fresh air capability.

All capacity, efficiency and cost of operation information as required for Department of Energy "EnergyGuide" fact sheets is based on the fresh air blank off plate being in place and is recommended for maximum energy efficiency.

## WALL MOUNTING

1. Two holes, the size of the supply and return air openings must be cut through the wall as shown in Figure 2.
2. On wood-frame walls, the wall construction must be strong and rigid enough to carry the weight of the unit without transmitting any unit vibration.
3. Concrete block walls must be thoroughly inspected to insure that they are capable of carrying the weight of the installing unit.
4. Ducts through the walls must be insulated and all joints taped or sealed to prevent air or moisture entering the wall cavity.
5. Some installations may not require any return air duct. It is recommended that on this type of installation that a filter grille be located in the wall. Filters must be of sufficient size to allow a maximum velocity of 400 FPM.

NOTE: If no return air duct is used, applicable installation codes may limit this cabinet to installation only in a single story structure.


## WIRING - MAIN POWER

Refer to the unit rating plate for wire sizing information and maximum fuse or "HACR Type" circuit breaker size. Each outdoor unit is marked with a "Minimum Circuit Ampacity." This means that the field wiring used must be sized to carry that amount of current. Some models are suitable only for connection with copper wire, while others can be wired with either copper or aluminum wire. Each unit and/or wiring diagram will be marked "Use Copper Conductors Only" or "Use Copper or Aluminum Conductors." These instructions MUST BE adhered to. Refer to the National Electrical Code for complete current carrying capacity data on the various insulation grades of wiring material.

The electrical data lists fuse and wire sizes (60°C copper) for all models, including the most commonly used heater sizes.

The unit rating plate lists a "Maximum Time Delay Relay Fuse" or "HACR Type" circuit breaker that is to be used with the equipment. The correct size must be used for proper circuit protection and also to assure that there will be no nuisance tripping due to the momentary high starting current of the compressor motor.

FIGURE 1.




MOUNTING INSTRUCTIONS

1. These units are secured by wall mounting brackets which secure the unit to the outside wall surface at both sides and at the bottom.
2. The unit itself is suitable for "0" inch clearance, but the supply air duct flange and the first few feet of supply air duct require 1 inch clearance to combustible material. If combustible wall, use 30"x10" dimensions for sizing, if non-combustible, use 28"x8" dimensions.
3. After the wall opening positions have been selected, lay out the position for the bottom and side brackets. Fasten the brackets securely to the wall (type of fasteners will depend on wall construction).
4. Be sure to observe the 10" dimension when attaching the side brackets. This will assure that no screws are driven into the unit sides damaging any internal parts. One-half inch sheet metal screws are recommended.
5. For additional mounting rigidity, the return air and supply air (depending upon wall construction) frames or collars can be drilled and screwed or welded to the structural wall itself. Be sure to observe required clearance if combustible wall.
6. Maintain 30 inches minimum clearance on right side of unit to allow access to heat strip and control panel.

**FAN BLADE SETTING DIMENSIONS**

Shown in the drawing below are the correct fan blade setting dimensions for proper air delivery across the outdoor coil.

Any service work requiring removal or adjustment in the fan and/or motor area will require that the dimensions below be checked and blade adjusted in or out on the motor shaft accordingly.



**INDOOR BLOWER PERFORMANCE**

All units are factory shipped wired on high speed tap. If low static operation is needed, low speed may be used for all except 15kw models. All 15kw models must be applied using high speed only. Refer to the chart below for CFM outputs at various E.S.P. conditions.

INDOOR BLOWER PERFORMANCE CFM - Dry Coil		
E.S.P. Inches H <sub>2</sub> O	MAC30A, MAC36A	
	High	Low*
.0	1200	975
.10	1160	930
.20	1120	900
.30	1075	
.40	1035	
.50	970	

\*MAC30A and MAC36A models with 15kw electric heat must use high speed only.

If this unit is operated in cooling below a 65° outdoor ambient temperature, the installation of low ambient control (LAC-1) to unit is required.

**REFRIGERANT CHARGE**

The correct system R-22 charge is shown on the unit rating plate. Optimum unit performance will occur with a refrigerant charge resulting in a suction line temperature (6" from compressor) as shown in the following table:

Model	Rated Airflow	95°F OD Temp.	82°F OD Temp.
MAC30A	1000	53 - 55	60 - 62
MAC36A	1060	50 - 52	54 - 56

The above suction line temperatures are based upon 80°F dry bulb/67°F wet bulb (50% R.H.) temperature and rated airflow across the evaporator during cooling cycle.

RATED CFM AND E.S.P. (WET COIL--COOLING)			
Model	Rated CFM *	Rated E.S.P. *	Recommended Airflow Range
MAC30A	1000	.30	900 - 1100
MAC36A	1060	.15	900 - 1160

\*Rated CFM and ESP on high speed tap.

**IMPORTANT INSTALLER NOTE**

For improved start-up performance wash the indoor coil with a dishwasher detergent.

**PRESSURE SERVICE PORTS**

High and low pressure service ports are installed on all units so that the system operating pressures can be observed. Pressure curves can be found later in the manual covering all models on both cooling and heating cycles. It is imperative to match the correct pressure curve to the unit by model number.


PARTS LIST

Single Package Air Conditioners

Part No.	Description	MAC30A	MAC30A-A05	MAC30A-A10	MAC30A-A15	MAC30A-A00/C	MAC30A-A05/C	MAC30A-A10/C	MAC30A-A15/C	MAC36A	MAC36A-A05	MAC36A-A10	MAC36A-A15	MAC36A-A00/C	MAC36A-A05/C	MAC36A-A10/C	MAC36A-A15/C
		5152-054	Blower Housing	x	x	x	x	x	x	x	x	x	x	x	x	x	x
5152-055	Blower Wheel	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x
5152-056	Blower Wheel	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x
8552-035	Capacitor 40/370V	x	x	x	x	x	x	x	x								
8552-028	Capacitor 35/440V									x	x	x	x	x	x	x	x
8552-002	Capacitor 5/370V	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x
8552-004	Capacitor 7 1/2/370V	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x
8000-092	Compressor H23A303ABCA	x	x	x	x	x	x	x	x								
8000-087	Compressor H23A383ABCA									x	x	x	x	x	x	x	x
5051-048	Condenser Coil	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x
8401-007	Contactora	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x
8401-006	Contactora		x	x			x	x			x	x			x	x	
8401-002	Contactora				x				x				x				x
5060-048	Evaporator Coil	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x
5151-032	Fan Blade	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x
7004-006	Filter 14x25x1	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x
8614-022	Fuse TR60				2									2			
8614-006	Fuse OT30				2									2			
8614-017	Fuse Block 15kw				1								1				
7051-021	Grille - Condenser	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x
7051-022	Grille - Inlet	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x
8604-042	Heat Strip 5kw		1				1				1						
8604-044	Heat Strip 10kw			1				1				1				1	
8604-047	Heat Strip 15kw				1				1				1				1
8402-049	Limit Control		x	x	x		x	x	x		x	x	x		x	x	x
8106-022	Motor - Evaporator	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x
8103-019	Motor - Condenser	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x
8200-001	Motor Mount (Fan)	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x
8200-032	Motor Mount (Blower)	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x
8201-009	Relay - Blower	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x
8607-013	Terminal Block		x	x							x	x					
8607-018	Terminal Board	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x
8402-030	Thermal Cutoff		1	2	3		1	2	3		1	2	3		1	2	3
8407-034	Transformer	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x
8615-010	Circuit Breaker													1	1		
8615-014	Circuit Breaker					1	1										
8615-016	Circuit Breaker							1	1							1	1
8615-013	Circuit Breaker								1								1
4081-110	Wiring Diagram	x								x							
4081-111	Wiring Diagram					x								x			
4081-120	Wiring Diagram		x								x						
4081-121	Wiring Diagram						x								x		
4081-130	Wiring Diagram			x								x					
4081-131	Wiring Diagram							x								x	
4081-140	Wiring Diagram				x								x				
4081-141	Wiring Diagram								x								x

Supersedes all previous lists. Subject to change without notice.


These curves are based upon 80°DB, 67°WB R.A. Temp. and rated CFM (airflow) across the evaporator coil and should be used for reference purposes only. Special information can be found under section titled "Refrigerant Charge" elsewhere in manual. If there is any doubt as to correct operating charge being in the system, the charge should be removed, system evacuated, and recharged according to serial plate instructions.



AIR TEMPERATURE ENTERING OUTDOOR COIL--DEGREE F.

These curves are based upon 80°DB, 67°WB R.A. Temp. (read CFM (airflow) across the evaporator coil and should be used for reference purposes only. Special information can be found under section titled "Refrigerant Charge" elsewhere in manual. If there is any doubt as to correct operating charge being in the system, the charge should be removed, system evacuated, and recharged according to serial plate instructions.

HIGH SIDE (DISCHARGE LINE) PRESSURE--PSIG



AIR TEMPERATURE ENTERING OUTDOOR COIL--DEGREE F.

LOW SIDE PRESSURE--PSIG  
(SUCTION LINE)

100  
90  
80  
70  
60  
50  
40





# AIR CONDITIONING PROCEDURE FOR LEAK TEST-EVACUATION-CHARGING

## GAUGE MANIFOLD

A necessary instrument in checking and servicing air conditioning and heat pump equipment is the gauge manifold. Its purpose is to determine the operating refrigerant pressures in order for the serviceman to analyze the condition of the system.

The valving on the manifold is so arranged that when the valves are closed (front-seated) the center port on the manifold is closed to the gauges and gauge ports. With the valves in the closed position, the gauge ports are still open to the gauges, permitting the gauges to register system pressures. Opening either valve opens the center port to that side of the manifold and system.



4. Make sure coupler is lined up straight with Schrader valve. Screw coupler on to valve.
5. Open gauge manifold valve slightly and purge air from hose with refrigerant.
6. Read the suction pressure on compound gauge and heat pressure on pressure gauge.
7. To remove, push end of hose tight against end of Schrader valve and hold in place while quickly unscrewing coupler nut from Schrader valve.
8. Remove coupler from Schrader valve. Replace caps on valve.

### WARNING

As a safety measure, it is wise to detach refrigerant hoses at the lowest pressure readings on the system. To do this:

- (a) Remove the suction pressure hose (A) first. (Unit is running).
- (b) Remove the high pressure hose (B) next. (Unit is not running).

## ATTACHING GAUGE MANIFOLD

For leak testing, purging, checking charge, charging liquid or evacuating, connect high pressure side of gauge manifold to Schrader valve on liquid or discharge line. Connect suction side of gauge manifold to Schrader valve on suction line. On heat pumps the suction line is between compressor and reversing valve.

## ATTACHING MANIFOLD HOSE TO SCHRADER VALVE

### WARNING

As a safety measure, it is wise to attach refrigerant hoses at the lowest pressure readings on the system. To do this:

- (a) Put high pressure hose (B) on first. (Unit should not be running).
- (b) Put low pressure hose (A) on second. (Unit should be running).

1. Remove cap from valve.
2. Make sure gauge manifold valves are closed.
3. If hose does not have an unseating pin, a number 395 Superior or equivalent unseating coupler must be used.

## LEAK TEST

1. Remove gauge port cap from suction and liquid service valve ports and attach manifold gauge hoses. Connect an upright R22 drum to center port of gauge manifold. Open refrigerant drum valve and manifold high pressure gauge valve to pressurize system. Pressurize the complete system with R22 until the pressure reaches 100 psig. DO NOT exceed 150 psig.
2. Close manifold high pressure gauge valve. Check all soldered joints, including those on the evaporator coil with an Electronic Leak Detector. If a leak is found which requires soldering, pressure in the system must be bled off since it is impossible to solder with unit pressurized. Be sure all leaks are located and marked before bleeding pressure from system.
3. Close drum valve and disconnect from center port. Release refrigerant into the atmosphere through suction line of gauge manifold.
4. Correct any leaks and recheck. When leaks, if any have been repaired, system is ready to be evacuated and charged. Relieve all pressure from the system down to 0 psig.

## EVACUATION

1. Evacuate the system to less than 1000 microns, using a good vacuum pump and an accurate high vacuum gauge. Operate the pump below 1000 microns for 60 minutes and then close valve to the vacuum pump. Allow the system to stand for 30 additional minutes to be sure a 1000 micron vacuum or less is maintained.
2. An alternate method of removing moisture and noncondensables from the system is:
  - a) Evacuate system to 29 inches vacuum for ten minutes per ton of system. Break vacuum with refrigerant to be used for final charging of system and vapor charge to 35-50 lbs. gauge pressure. Leave vapor charge in system for a minimum of five minutes. Reduce pressure to five to zero gauge pressure.
  - b) Repeat step (a) two more times.
  - c) Evacuate system to 30 inches vacuum for twenty minutes per ton. Charge system with the specified kind and quantity of refrigerant (charge into vacuum).

### WARNING

At no time use the compressor to evacuate the system or any part of it.

3. Disconnect charging line at vacuum pump and connect to refrigerant supply. (Dial-A-Charge Cylinder) crack valve and purge charging line at center on manifold. Then close valve.
4. The system is now ready for the correct operating charge of Refrigerant R22.

## CHARGING

1. SINGLE PACKAGE UNITS - Refer to the unit serial plate for the full operating charge.
2. SPLIT SYSTEMS - The outdoor unit factory charge is shown on the unit serial plate. The total system charge required to recharge the system after service repairs should be marked on the serial plate under TOTAL R22 CHARGE. This is normally marked by the Installer and is determined from the R22 System Charge Table located on the inside of the outdoor unit access panel.
3. CTO ADAPTER KITS - When using CTO adapters and field tubing, use the procedure outlined on the bottom of page 3, Manual 2100-002. This determines the correct ounces of R22 for the tubing only.
4. FILTER-DRIER CHARGES - If a liquid line filter-drier is used, either in conjunction with field tubing and a CTO adapter kit, or as part of procedure for system clean-up after a compressor burn-out, additional R22 must be added to the system when recharging. This is in addition to the amount determined from the R22 System Charge Table.

PART NO.	MODEL NO.	OZ. of R22
5202-001	C-083S	8
5202-002	C-163S	10
5201-009	BFK-083S	7
5201-010	BFK-163S	13

## PRELIMINARY CHARGING STEPS

If the system has been open to the atmosphere, it should be first evacuated. Then proceed as follows:

1. Attach a drum of proper, clean refrigerant to the center port of the charging manifold with one of the charging hoses.
2. Attach a second charging hose to the suction gauge (low pressure) side of the gauge manifold.
3. Remove the cap from the suction line valve.
4. Loosely attach the suction gauge hose to the line valve. Open the valve on the refrigerant drum and the suction valve on the charging manifold slightly to purge the air from the manifold and hoses before tightening the fitting.
5. Attach the third hose to the high pressure side of the manifold and the liquid line valve. Repeat steps 3 and 4 above.


## CHARGING THE SYSTEM BY WEIGHT\*

1. Connect manifold as instructed.
2. Place refrigerant drum upright on scale and determine exact weight of the refrigerant and cylinder or use a Dial-A-Charge cylinder.
3. With manifold suction valve closed and manifold discharge valve open, open refrigerant cylinder valve and allow pressure in system to balance with pressure of cylinder. For charging in the liquid phase, drum is placed upside down (valve down).
4. When there is approximately a full charge, front seat (close) the discharge manifold valve and let the system stabilize for about five minutes.
5. Start compressor by setting thermostat.
6. Finish charging with vapor by placing drum upright (valve up). Open drum valve and manifold low pressure valve to allow refrigerant to flow into the system. Throttle refrigerant drum valve to keep pressure about 100 psig for R22.
7. When the correct weight of refrigerant has been added to the unit, close refrigerant cylinder valve and allow unit to run for 30 minutes. Refer to Start-Up Procedure and Check List for further start-up details. Check the charge against the allowable head pressure as shown in the Head Pressure Chart and correct if needed.
8. Front seat gauge manifold valves, disconnect charging and gauge hoses and replace all valve caps.

### WARNING

To speed refrigerant flow, it may be necessary to place refrigerant drum in a pan of warm water (not greater than 130°F). Remember to either consider the total weight of the pan of water or remove the drum for weighing frequently to keep track of the charging process.

\*This charging method requires the scales or Dial-A-Charge cylinder to be extremely accurate since the charge in this type of system is quite critical.



### AIR CONDITIONING AND HEAT PUMP ON COOLING CYCLE

#### TROUBLESHOOTING — SYSTEM PRESSURE CHECK

##### Low Suction — Low Head Pressure

1. Restricted air flow over indoor coil.
2. Defective indoor fan motor.
3. Low indoor and outdoor temperature.
4. Iced indoor coil.
5. Restricted liquid line, drier, or capillary tube.
6. Low charge.

##### High Suction — Low Head Pressure

1. Defective or broken valves.
2. IPRV valve open.

##### Low Suction — High Head Pressure

1. Partial restriction and then overcharged.


*Note:* On a split heat pump the vapor line should be within 10 psig of the pressure in liquid line on heating mode and within 10 psig of suction line on cooling mode. If not, check for sticking check valves.

##### High Suction — High Head Pressure

1. High ambient.
2. Low outdoor air flow
3. Overcharged.
4. Air in system.
5. Restricted condenser.



T874C1000 Thermostat  
Q674A1001 Subbase



NEC Class 2  
24V Wiring

24V.  
Terminal  
Block

Compressor  
Contactor

5/370  
Capacitor

Outdoor  
Motor

208 v.

24V Transformer

High  
Speed  
(Black)

(7.5 MFD)  
Capacitor

Indoor  
Motor

Blower Relay

Equip.  
Ground


- 1 Add jumper RC to RH. set heater anticipator  
For W1 and W2 at 40 Amps.
- 2 MAC30A : 40/370  
MAC36A : 35/440
- 3 For 208V. operation move this wire to  
208V. transformer tap.

230/208-60-1

USE COPPER WIRE

FACTORY WIRING	FIELD WIRING
Low Voltage	-----
High Voltage	-----

T874C1000 Thermostat  
Q674A1001 Subbase




- 1 Add jumper RC to RH. set heater anticipator for W1 and W2 at 40 Amps.
- 2 MAC30A-A00/C :40/370  
MAC36A-A00/C :35/440
- 3 For 208V. operation move this wire to 208V. transformer cap.
- 4 MAC30A-A00/C 35A  
MAC36A-A00/C 45A

CKT. A  
230/208-60-1

FACTORY WIRING	FIELD WIRING
Low Voltage ———	-----
High Voltage ———	-----

USE COPPER OR ALUMINUM WIRE

T874C1000 Thermostat  
Q674A1001 Subbase




230/208-60-1

<b>FACTORY WIRING</b>	<b>FIELD WIRING</b>
Low Voltage ———	-----
High Voltage ———	-----

USE COPPER OR ALUMINUM WIRE

T874C1000 Thermostat  
Q674A1001 Subbase



- 1 Add jumper RC to RH, set heater anticipator for W1 and W2 at 40 Amps.
- 2 MAC30A-A05/C :40/370  
MAC36A-A05/C :35/440
- 3 For 208V. operation move this wire to 208V. transformer tap.  
MAC30A-A05/C :35A  
MAC36A-A05/C :45A
- 4


230/208-60-1

FACTORY WIRING	FIELD WIRING
Low Voltage ———	—————
High Voltage ———	—————

USE COPPER OR ALUMINUM WIRE



T874C1000 Thermostat  
Q674A1001 Subbase




- 1 Add jumper RC to RH. set heater anticipator for W1 and W2 at 40 Amps.
- 2 MAC30A-A10 :40/370  
MAC36A-A10 :35/440
- 3 For 208V. operation move this wire to 208V. transformer tap.

230/208-60-1

**FACTORY WIRING**    **FIELD WIRING**  
 Low Voltage ————  
 High Voltage ————

USE COPPER OR ALUMINUM WIRE

T874C1000 Thermostat  
Q674A1001 Subbase




- 1 Add jumper RC to RH. set heater anticipator for W1 and W2 at 40 Amps.
- 2 MAC30A-A10/C :40/370  
MAC36A-A10/C :35/440
- 3 For 208V. operation move this wire to 208V. transformer tap.

230/208-60-1

<b>FACTORY WIRING</b>	<b>FIELD WIRING</b>
Low Voltage ———	—————
High Voltage ———	—————

USE COPPER OR ALUMINUM WIRE

T874C1000 Thermostat  
Q674A1001 Subbase




- 1 Add jumper RC to RH. set heater anticipator for W1 and W2 at 40 Amps.
- 2 MAC30A-A15:40/370  
MAC36A-A15:35/440
- 3 For 208V. operation move this wire to 208V. transformer tap.
- 4 This model not approved and must not be operated on low speed.

NOTE: Fuse A -60A Time Delay  
Fuse B -30A  
All Fuses Type K-5

<b>FACTORY WIRING</b>	<b>FIELD WIRING</b>
Low Voltage ———	—————
High Voltage ———	—————

USE COPPER OR ALUMINUM WIRE

T874C1000 Thermostat  
Q674A1001 Subbase



- 1 Add jumper RC to RH. set heater anticipator for W1 and W2 at 40 Amps.
- 2 MAC30A-A15/C :40/370  
MAC36A-A15/C :35/440
- 3 For 208V. operation move this wire to 208V. transformer tap.
- 4 This model is not approved and must not be operated on low speed.

**FACTORY WIRING**    **FIELD WIRING**  
 Low Voltage ————  
 High Voltage ————

USE COPPER OR ALUMINUM WIRE