

# **INSTALLATION INSTRUCTIONS**

## **SPLIT SYSTEM HEAT PUMP COIL ONLY INDOOR SECTION**

**FOR USE WITH:**

**OIL  
GAS  
FURNACES**

MANUAL 2100-024 REV. N  
SUPERSEDES REV. M  
FILE VOL. I, TAB 6

COPYRIGHT JUNE, 1989  
BARD MANUFACTURING COMPANY  
BRYAN, OHIO

## TABLE OF CONTENTS

|  |       |
|--|-------|
| I. Application and Location . . . . .                      | 1     |
| General . . . . .  | 1     |
| Application . . . . .                                      | 3     |
| Airflow Pressure Drop Measurement . . . . .                | 4     |
| CFM For Add-On Heat Pump . . . . .                         | 4     |
| Condensate Drain Drop . . . . .                            | 6     |
| <br>II. Wiring . . . . .                                   | <br>7 |
| General Operation--Heat Pump/Fossil Fuel Furnace . . . . . | 7     |
| Note On Indoor Blower Operation . . . . .                  | 7     |
| Control Circuit Wiring . . . . .                           | 7     |
| Wall Thermostats . . . . .                                 | 8     |
| Wiring Diagrams . . . . .                                  | 9     |

## FIGURES AND TABLES

|                    |   |
|--------------------|---|
| Figure 1 . . . . . | 2 |
| Figure 2 . . . . . | 3 |
| Figure 3 . . . . . | 3 |
| Figure 4 . . . . . | 4 |
| Figure 5 . . . . . | 6 |

|                   |   |
|-------------------|---|
| Table 1 . . . . . | 1 |
| Table 2 . . . . . | 1 |
| Table 3 . . . . . | 5 |
| Table 4 . . . . . | 7 |
| Table 5 . . . . . | 8 |

## I. APPLICATION AND LOCATION

### GENERAL

The indoor cooling coils are designed for use with outdoor section listed in Table 2. They are designed for use with gas or oil furnaces. Optional coil casing plenums are also available.

These instructions cover the indoor coil sections listed in Table 2, all of which are supplied less blower. The outdoor compressor units shown can also be matched with blower coil indoor sections, and those are covered by separate installation manuals shipped with the respective blower coil units.


TABLE 1

| COIL DIMENSIONS (Inches) |        |        |        |                         |           |
|--------------------------|--------|--------|--------|-------------------------|-----------|
| Coil                     | A      | B      | C      | Drain Pan Opening (W&L) | Coil Type |
| H3AQ1                    | 18     | 20-1/2 | 16-1/2 | 12-1/4 & 15-1/4         | "A"       |
| H4AQ1                    | 23-3/4 | 24-7/8 | 20-1/4 | 12-1/8 & 19-3/4         | "A"       |
| H5AQ1                    | 23-3/4 | 24-7/8 | 24     | 12-1/8 & 19-3/4         | "A"       |

TABLE 2

| APPROVED MATCHED COMBINATIONS, RATED CFM<br>STATIC PRESSURE DROP ①   |                              |      |                                     |                            |
|--|------------------------------|------|-------------------------------------|----------------------------|
| Condensing Unit Model Number   | Evaporator Coil Model Number | CFM  | Rated Airflow Pressure Drop "H2O" ② | Recommended Air Flow Range |
| WQS30<br>WQSD30  | H3AQ1 ④                      | 1150 | .15                                 | 980 - 1250                 |
| WQS36<br>WQSD36  | H3AQ1 ④                      | 1250 | .25                                 | 1025 - 1375                |
| 42HPQ4   | H4AQ1 ④                      | 1450 | .25                                 | 1160 - 1575                |
| 48HPQ5   | H4AQ1 ④                      | 1450 | .25                                 | 1160 - 1575                |
| 60HPQ5   | H5AQ1 ④                      | 1800 | .25                                 | 1600 - 1850                |
| WQS50<br>WQSD50  | H4AQ1                        | 1625 | .30                                 | 1500 - 1885                |
| ① All coils are suitable for up or down airflow direction.<br>② Measured across the evaporator coil assembly, including drain pan.<br>③ Coil suitable for horizontal airflow direction.<br>④ Coil suitable for horizontal airflow direction only when optional horizontal drain pan is used. |                              |      |                                     |                            |

FIGURE 1



## APPLICATION

FIGURE 2  
TYPICAL APPLICATION OF  
COIL TO HIGHBOY FURNACE





FIGURE 3  
TYPICAL APPLICATION OF COIL  
COUNTERFLOW FURNACE



Every coil must have the required two inch minimum clearance between furnace heater exchanger and bottom of coil (Figure 2, dimension A), and not exceed a maximum of two inches between the top of coil and bottom of horizontal ductwork (Figure 2, dimension B).

When the ductwork takes off from only one side of the plenum, the minimum distance from top of coil to top of plenum is six inches (Figure 2, dimension C).

A duct should never be located between the coil and the source of air supply. If your coil is larger than the top of your furnace, a transition is required with a minimum of three inches.


**CAUTION:** Be sure to seal area on all sides between coil drain pan and plenum to prevent air from bypassing coil.

It is important to provide a removable access door in the plenum slightly larger than the coil for servicing or cleaning the coil.

## AIRFLOW PRESSURE DROP MEASUREMENT

A manometer or air draft gauge is required to check the air pressure drop across the indoor evaporator coil section.

The pressure (or positive) side of the gauge should connect to the air inlet (entering) side of the coil, and the suction (or negative) side of the gauge to the downstream (leaving) side of the coil. See Figure 3.



### CFM FOR ADD-ON COILS

The furnace that you are going to add a heat pump to must be able to deliver enough air to satisfy the airflow listed in Table 2 for the coil being used.

In a heat pump application, the indoor coil becomes the condensing coil, this is why the amount of air is so critical. Not enough air results in too high of high side pressures and temperatures. The furnace CFM can be calculated by using the following formula:

$$\text{CFM} = \frac{\text{Output (BTU/H)}}{1.08 \times \text{Temp. Rise}}$$

When adding a coil to an existing GAS FURNACE, proceed as follows to determine the gas input to the furnace. Shut off all other gas appliances in the home, then set the indoor wall thermostat to call for heat. Go to the gas meter and clock the fastest moving dial, then refer to the chart below.

**EXAMPLE:** Most gas utilities use 1000 BTU per cubic foot of gas. If you were to clock the one cubic foot dial and found it took 36 seconds for one revolution, then in one hour the furnace would use 100,000 BTU, but we all know that no furnace is 100 percent efficient, so suppose we assume this furnace to be 70 percent efficient, then we should have approximately 70,000 BTU per hour output. Using the figure our formula would look like this:

$$\text{CFM} = \frac{70,000}{1.08 \times \text{T.R.}} \quad \text{or} \quad \text{CFM} = \frac{70,000}{1.08 \times ?}$$



We must still obtain a temperature rise through the furnace. This is done by measuring the return air temperature and the supply air temperature. Let's again assume we were able to measure a 60 degree F temperature rise through the furnace. Now we can complete our formula.

$$CFM = \frac{70,000}{1.08 \times 60} \quad \text{or} \quad CFM = \frac{70,000}{65}$$

Then, our CFM for this furnace would be 1076 CFM.

TABLE 3

| Seconds<br>For One<br>Rev. | SIZE OF TEST DIAL |                |              |              |              | Seconds<br>For One<br>Rev. | SIZE OF TEST DIAL |                |              |              |              |
|----------------------------|-------------------|----------------|--------------|--------------|--------------|----------------------------|-------------------|----------------|--------------|--------------|--------------|
|                            | 1/4<br>Cu. Ft.    | 1/2<br>Cu. Ft. | 1<br>Cu. Ft. | 2<br>Cu. Ft. | 5<br>Cu. Ft. |                            | 1/4<br>Cu. Ft.    | 1/2<br>Cu. Ft. | 1<br>Cu. Ft. | 2<br>Cu. Ft. | 5<br>Cu. Ft. |
| 10                         | 90                | 180            | 360          | 720          | 1800         | 36                         | 25                | 50             | 100          | 200          | 500          |
| 11                         | 82                | 164            | 327          | 655          | 1636         | 37                         | --                | --             | 97           | 195          | 486          |
| 12                         | 75                | 150            | 300          | 600          | 1500         | 38                         | 23                | 47             | 95           | 189          | 474          |
| 13                         | 69                | 138            | 277          | 555          | 1385         | 39                         | --                | --             | 92           | 185          | 462          |
| 14                         | 64                | 129            | 257          | 514          | 1286         | 40                         | 22                | 45             | 90           | 180          | 450          |
| 15                         | 60                | 120            | 240          | 480          | 1200         | 41                         | --                | --             | --           | 176          | 439          |
| 16                         | 56                | 113            | 225          | 450          | 1125         | 42                         | 21                | 43             | 86           | 172          | 429          |
| 17                         | 53                | 106            | 212          | 424          | 1059         | 43                         | --                | --             | --           | 167          | 419          |
| 18                         | 50                | 100            | 200          | 400          | 1000         | 44                         | --                | 41             | 82           | 164          | 409          |
| 19                         | 47                | 95             | 189          | 379          | 947          | 45                         | 20                | 40             | 80           | 160          | 400          |
| 20                         | 45                | 90             | 180          | 360          | 900          | 46                         | --                | --             | 78           | 157          | 391          |
| 21                         | 43                | 86             | 171          | 343          | 857          | 47                         | 19                | 38             | 76           | 153          | 383          |
| 22                         | 41                | 82             | 164          | 327          | 818          | 48                         | --                | --             | 75           | 150          | 375          |
| 23                         | 39                | 78             | 157          | 313          | 783          | 49                         | --                | --             | --           | 147          | 367          |
| 24                         | 37                | 75             | 150          | 300          | 750          | 50                         | 18                | 36             | 72           | 144          | 360          |
| 25                         | 36                | 72             | 144          | 288          | 720          | 51                         | --                | --             | --           | 141          | 355          |
| 26                         | 34                | 69             | 138          | 277          | 692          | 52                         | --                | --             | 69           | 138          | 346          |
| 27                         | 33                | 67             | 133          | 267          | 667          | 53                         | 17                | 34             | --           | 136          | 340          |
| 28                         | 32                | 64             | 129          | 257          | 643          | 54                         | --                | --             | 67           | 133          | 333          |
| 29                         | 31                | 62             | 124          | 248          | 621          | 55                         | --                | --             | --           | 131          | 327          |
| 30                         | 30                | 60             | 120          | 240          | 600          | 56                         | 16                | 32             | 64           | 129          | 321          |
| 31                         | --                | --             | 116          | 232          | 581          | 57                         | --                | --             | --           | 126          | 316          |
| 32                         | 28                | 56             | 113          | 225          | 563          | 58                         | --                | 31             | 62           | 124          | 310          |
| 33                         | --                | --             | 109          | 218          | 545          | 59                         | --                | --             | --           | 122          | 305          |
| 34                         | 26                | 53             | 106          | 212          | 529          | 60                         | 15                | 30             | 60           | 120          | 300          |
| 35                         | --                | --             | 103          | 206          | 514          |                            |                   |                |              |              |              |

If the furnace is equipped with a direct drive motor, make sure you have it wired to high speed tap. If it is a belt drive motor, then read the motor's nameplate amps. Then hook on an amp probe and see if it is possible to speed the blower up by adjusting the variable pulley.

If you are at the limits of the motor, then check with the furnace manufacturer to see if a larger horsepower motor can be installed and also if the blower will give you the needed CFM with a larger motor.

When you have determined that your furnace can handle the required CFM for your coil, the indoor coil must be installed and your CFM calculation must be rechecked with the coil in place.

When adding to an OIL FURNACE, you must determine what size nozzle the unit has in the burner and then install a pressure gauge in the oil delivery pumps discharge port and set the pressure at 100 psig. An example might be that we find the burner equipped with a one gallon per hour nozzle, operating at 100 psi. This nozzle will deliver one G.P.H. and a gallon of No. 2 fuel oil has approximately 140,000 BTU of heat.

The 140,000 BTU is our input and again let us assume that this furnace is operating at 70 percent efficiency. Then our BTU output is 98,000 BTU, and if we use the rule of thumb that an oil furnace should operate with an 85 degree F temperature rise, then our formula would look like this:

$$\text{CFM} = \frac{98,000 \text{ BTU/H}}{1.08 \times 85 \text{ degree F}} \quad \text{or} \quad \frac{98,000 \text{ BTU/H}}{92} = 1065 \text{ CFM}$$

When adding on to an electric furnace, we must also take one more thing into consideration and that is the heat pump coil must be installed on the return side of the electric furnace. To find out what CFM the electric furnace can deliver, we must measure the voltage and amperage of each heating element or Volts x Amp - Watts. The total Watts x 3.4 BTU = BTU Output. An example might look like this with a 15kw electric furnace.

$$\begin{aligned} 240 \text{ Volts} \times 21 \text{ Amps} &= 5,040 \text{ Watts} \\ 5,040 \text{ Watts} \times 3 \text{ Elements} &= 15,120 \text{ Watts} \\ 15,120 \text{ Watts} \times 3.4 \text{ BTU/Watt} &= 51,408 \text{ BTU} \end{aligned}$$

One word of caution, never go by nameplate rating. Always measure volts and amps.

One more item that is different with an electric furnace and that is, never obtain a supply air temperature reading in sight of the electric element (because of the radiant affect). Now our formula looks like this again:


$$\text{CFM} = \frac{51408 \text{ BTU/H}}{1.08 \times 44 \text{ degree F}} \quad \text{or} \quad \frac{51408 \text{ BTU/H}}{48} = 1071 \text{ CFM}$$

## CONDENSATE DRAIN TRAP

It is very important to provide a trap in the condensate drain line to allow a positive liquid seal in the line and assure correct drainage from the coil condensate pan.

Install condensate drain trap shown below. Use drain connection size or larger. Do not operate unit without trap. Unit must be level or slightly inclined toward drain.

FIGURE 5



## II. WIRING

### GENERAL OPERATION--HEAT PUMP/FOSSIL FUEL FURNACE

This type of system is a one-stage heating system, even though a two-stage heat wall thermostat is used. The thermostats specified for use are special thermostats for heat pumps with extra switches, signal lights, and special circuitry for heat pumps, and by design are two-stage heating thermostats. Since the extra features are also required for the special heat pump/fossil fuel systems, the same thermostats are used, but the second stage circuit is not used. This is further explained in the next paragraph.

While it would be possible to electrically connect the furnace to the second stage of the thermostat, the heat pump coil is located downstream from the furnace heat exchanger, and continuous simultaneous operation of the furnace and heat pump will result in excessive high discharge pressures and temperatures at the compressor and resultant overload tripping problems. For this reason, the control circuit wiring diagrams shown later in this manual will not allow the furnace to operate except during defrost cycles unless an outdoor thermostat is added to the circuit. The addition of an outdoor thermostat used as a changeover thermostat will switch the system from heat pump heating to furnace heating based on the outdoor temperature. At no time will continuous operation of the heat pump and furnace be allowed.

An outdoor thermostat is used as a changeover thermostat, properly set to control at or just above the balance point, will allow the most economical operation of the system. The changeover (outdoor) thermostat switches off the heat pump and on the fossil fueled furnace, based on the outdoor thermostat. There is a 5 degree F differential in the changeover (outdoor) thermostat, so when the heat pump is de-energized and the furnace is activated, the outdoor temperature must rise 5 degrees F above the set-point of the thermostat to stop the furnace and start the heat pump again. NOTE: See manual 2100-057 "Heat Pump Sizing" for procedure to determine correct balance point.

The emergency heat switch allows for manual cutoff of the heat pump and operation of the furnace at any outdoor temperature.

### NOTE ON INDOOR BLOWER OPERATION

Because of the design of the heat pump wall thermostats, and the fact that a cooling blower relay is installed in parallel with the fan side of the combination fan/limit control found on most gas or oil furnaces, the furnace blower will start as soon as the wall thermostat calls for heat. This is required for the heat pump and will also occur during the time when the heat pump is off and the furnace is operating. This is contrary to normal blower operation on a gas or oil furnace and is sometimes misunderstood, but an inherent part of the system operation. While in the gas or oil furnace mode of operation, there will still be a run-on in blower operation until the bonnet temperature cools down to the blower off setting of the fan/limit switch.

### CONTROL CIRCUIT WIRING

There are four (4) separate control diagrams for fossil fuel furnaces with heat pumps.

TABLE 4


| Heat Pump System   | Gas Furnace Control Diagram | Oil Furnace Control Diagram |
|--|-----------------------------|-----------------------------|
| 18HPQ 24UHPQA<br>24HPQ 30UHPQA<br>30HPQ 36UHPQA<br>36HPQ | 4091-200                    | 4091-201                    |
| 42HPQ<br>48HPQ<br>60HPQ                                  | 4091-202                    | 4091-203                    |

## WALL THERMOSTATS

The following wall thermostats and subbases should be used as indicated, depending on the application.

TABLE 5

| HEAT PUMP THERMOSTATS |           |  |
|-----------------------|-----------|--|
| Part No.              | Model No. | Description  |
| 8403-017              | T874R1129 | THERMOSTAT--1 stg. cool, 2 stg. heat, 1st stage fixed,<br>2nd stg. adj. heat anticipators  |
| 8404-009              | Q674L1181 | SUBBASE --System switch: Em. Heat-Heat-Off-Cool<br>Fan switch: On-Auto<br>SPECIAL FEATURE: Manual Changeover (Non-Cycling Rev. Valve)<br>Em. heat light and System check light |
| 8403-018              | T874N1024 | THERMOSTAT--1 stg. cool, 2 stg. heat, 1st stage fixed,<br>2nd stg. adj., heat anticipators   |
| 8404-010              | Q674F1261 | SUBBASE --System switch: Off-Cool-Auto-Heat-Em.Ht.<br>Fan switch: On-Auto<br>SPECIAL FEATURE: Auto system changeover, Em.<br>heat light and System check light                 |
| 8403-024              | IF58-45   | THERMOSTAT--1 stg. cool, 2 stg. heat, 1st stage fixed,<br>2nd stg. adj. heater<br>System switch: Em. Heat-Heat-Off-Cool<br>Fan Switch: On-Auto                                 |



△ SET ADJUST HEAT ANTICIPATOR (SEE FURNACE INSTALLATION INSTRUCTIONS)

△ WHEN OUTDOOR THERMOSTAT (USED AS CHANGEOVER THERMOSTAT) IS INSTALLED, REMOVE JUMPER Y-Y1.

△ IF IT DESIRED NOT TO ALLOW FURNACE TO CYCLE "ON" DURING DEFOREST, A 24V FACTORY WIRE RETURN (TERMINAL "3" OF DEFOREST RELAY AND TERMINAL "4" ON EMERGENCY HEAT RELAY ON HP0 MODELS OR TERMINAL "2" OF HEATPUMP CONTROL AND TERMINAL "10" ON TERMINAL BOARD ON UPP MODELS) MUST BE REMOVED.


△ HP0 SERIES MODEL DO NOT HAVE (4) TERMINAL AND IT IS NOT REQUIRED TO RUN (4) WIRE TO THESE MODELS.

△ IF THE FURNACE IS NOT INTERNALLY WIRED FOR AID ON AIR CONDITIONING, A FAN CENTER WILL NEED TO BE ADDED.

|              | FACTORY WIRING | FIELD WIRING |
|--------------|----------------|--------------|
| LOW VOLTAGE  | ---            | ---          |
| HIGH VOLTAGE | ---            | ---          |

HEAT PUMP W/GAS FURNACE

4091-200 A



△ SET ADJUST HEAT ANTICIPATOR (SEE FURNACE INSTALLATION INSTRUCTIONS)

△ WHEN OUTDOOR THERMOSTAT (USED AS CHANGEOVER THERMOSTAT) IS INSTALLED, REMOVE JUMPER Y-Y1.

△ IF IT DESIRED NOT TO ALLOW FURNACE TO CYCLE "ON" DURING DEFOREST, A 24V FACTORY WIRE RETURN (TERMINAL "3" OF DEFOREST RELAY AND TERMINAL "4" ON EMERGENCY HEAT RELAY ON HP0 MODELS OR TERMINAL "2" OF HEATPUMP CONTROL AND TERMINAL "10" ON TERMINAL BOARD ON UPP MODELS) MUST BE REMOVED.

△ HP0 SERIES MODEL DO NOT HAVE (4) TERMINAL AND IT IS NOT REQUIRED TO RUN (4) WIRE TO THESE MODELS.


△ LOCATE ISOLATING RELAY IN OIL FURNACE. NECESSARY TO SEPARATE 24V POWER SUPPLY OF HEATPUMP FROM 24V POWER SUPPLY BUILT INTO OIL BURNER PRIMARY CONTROL.

△ IF THE FURNACE IS NOT INTERNALLY WIRED FOR AID ON AIR CONDITIONING, A FAN CENTER WILL NEED TO BE ADDED.

|              | FACTORY WIRING | FIELD WIRING |
|--------------|----------------|--------------|
| LOW VOLTAGE  | ---            | ---          |
| HIGH VOLTAGE | ---            | ---          |

HEAT PUMP W/OIL FURNACE

4091-201 A




- △ SET ADJUST HEAT ANTICIPATOR (SEE FURNACE INSTALLATION INSTRUCTIONS)
- △ WHEN OUTDOOR THERMOSTATE (USED AS CHANGEOVER THERMOSTAT) IS INSTALLED, REMOVE JUMPER Y-Y1.
- △ IF IT DESIRED NOT TO ALLOW FURNACE TO CYCLE "ON" DURING DEFROST, REMOVE JUMPER DH-D1.
- △ LOCATE EMERGENCY HEAT RELAY IN OUTDOOR UNIT. NECESSARY TO OPERATE FURNACE IN EMERGENCY HEAT MODE.
- △ IF THE FURNACE IS NOT INTERNALLY WIRED FOR ADD ON AIR CONDITIONING, A FAN CENTER WILL NEED TO BE ADDED.

| FACTORY      | FIELD  |
|--------------|--------|
| WIRING       | WIRING |
| LOW VOLTAGE  | ---    |
| HIGH VOLTAGE | ---    |

HEAT PUMP W/GAS FURNACE

4091-202 A



- △ SET ADJUST HEAT ANTICIPATOR (SEE FURNACE INSTALLATION INSTRUCTIONS)
- △ WHEN OUTDOOR THERMOSTATE (USED AS CHANGEOVER THERMOSTAT) IS INSTALLED, REMOVE JUMPER Y-Y1.
- △ IF IT DESIRED NOT TO ALLOW FURNACE TO CYCLE "ON" DURING DEFROST, REMOVE JUMPER DH-D1.
- △ LOCATE EMERGENCY HEAT RELAY IN OUTDOOR UNIT. NECESSARY TO OPERATE FURNACE IN EMERGENCY HEAT MODE.
- △ LOCATE ISOLATING RELAY IN OIL FURNACE. NECESSARY TO SEPARATE 24V POWER SUPPLY OF HEATPUMP FROM 24V POWER SUPPLY BUILT INTO OIL BURNER PRIMARY CONTROL.
- △ IF THE FURNACE IS NOT INTERNALLY WIRED FOR ADD ON AIR CONDITIONING, A FAN CENTER WILL NEED TO BE ADDED.

| FACTORY      | FIELD  |
|--------------|--------|
| WIRING       | WIRING |
| LOW VOLTAGE  | ---    |
| HIGH VOLTAGE | ---    |

HEAT PUMP W/OIL FURNACE

4091-203 A