
SERVICE INSTRUCTIONS

MEGA-TEC™ WALL-MOUNT AIR CONDITIONER

Model W120A



NOTE: LC6000 controller is required for operation when W120A units are used.



Climate Control Solutions

Bard Manufacturing Company, Inc.
Bryan, Ohio 43506
www.bardhvac.com

Manual: 2100-671A
Supersedes: 2100-671
Date: 5-16-19

CONTENTS

General Information4

| | |
|---------------------------------------|---|
| Multi-Stage Cooling System | 4 |
| Wall-Mount Air Conditioner Units..... | 4 |
| General | 4 |
| Shipping Damage..... | 4 |
| Additional Publications..... | 4 |

Using the TEC-EYE™6

| | |
|---|----|
| TEC-EYE Hand-Held Diagnostic Tool | 6 |
| TEC-EYE Menu Structure | 7 |
| TEC-EYE Acronyms | 7 |
| Main Status Screen | 7 |
| Quick Menu | 8 |
| Setpoints | 8 |
| Information | 8 |
| A/C Circuit Information | 8 |
| Program Version | 9 |
| Alarm Log | 9 |
| Menu Screens and Password Levels..... | 9 |
| Executing a Run Test | 10 |
| Run Test Parameter Descriptions | 10 |
| Reset to Factory Defaults | 10 |

Operation11

| | |
|---|----|
| Unit On/Off | 11 |
| Alarm Adjustment | 11 |
| Acknowledging Alarms | 11 |
| Clearing Alarms..... | 11 |
| Clearing Alarm Logs and Counters | 11 |
| Exporting Alarm Logs | 11 |
| Exporting 7 Day Logs | 12 |
| Exporting Parameters | 12 |
| Zone | 12 |
| Temperature Control | 12 |
| Temperature Control Components..... | 12 |
| Return Air Temperature Sensor..... | 12 |
| Return Air Temperature Alarm..... | 12 |
| Temperature Control Operation..... | 12 |
| Orphan Mode..... | 13 |
| LC6000 Control..... | 13 |
| Cooling (with Economizer)..... | 13 |
| Cooling (without Economizer) | 13 |
| Heating..... | 13 |
| Electronic Expansion Valve (EEV)..... | 14 |
| EEV Components..... | 14 |
| Electronic Expansion Valve..... | 14 |
| EEV Instructions for Vacuum, Reclaim, Charge Unit..... | 14 |
| System Pressures | 15 |
| Suction Pressure Transducer | 15 |
| Troubleshooting the Suction Pressure Transducer..... | 15 |
| Suction Pressure Alarm..... | 16 |
| Suction Temperature Sensor..... | 16 |
| Suction Temperature Alarm | 16 |
| Evaporator Freeze Condition Alarm | 16 |
| EEV Operation..... | 17 |
| EEV Superheat Control | 17 |
| Additional EEV Alarms | 17 |
| Low Superheat Alarm | 17 |

| | |
|--|----|
| Indoor Airflow | 17 |
| Indoor Airflow Components | 17 |
| Blower | 17 |
| Blower Status Switch | 18 |
| Blower Status Alarm | 18 |
| Filters..... | 18 |
| Dirty Filter Switch | 18 |
| Dirty Filter Alarm..... | 18 |
| Filter Indicator Light | 19 |
| Indoor Airflow Operation..... | 19 |
| Blower Speed Control | 19 |
| Additional Indoor Airflow Alarms | 19 |
| Supply Air Temperature Alarm..... | 19 |
| Condenser Fan..... | 19 |
| Condenser Fan Components..... | 19 |
| Condenser Fan..... | 19 |
| Liquid Pressure Sensor..... | 20 |
| Troubleshooting the Discharge/ Liquid Pressure Transducer | 20 |
| Discharge/Liquid Pressure Transducer Alarm | 21 |
| Liquid Temperature Sensor | 21 |
| Outdoor Temperature Sensor | 21 |
| Condenser Fan Operation | 21 |
| Condenser Fan Speed Control..... | 21 |
| Compressor | 21 |
| Compressor Components | 21 |
| Compressor | 21 |
| Compressor Control Module (CCM)..... | 22 |
| Delay-on-Make Timer | 22 |
| Short Cycle Protection/ Delay-on-Break..... | 22 |
| High Pressure Detection..... | 22 |
| Test Mode..... | 23 |
| Brownout Protection w/Adjustment | 23 |
| High Pressure Safety Switch | 23 |
| Refrigerant High Pressure Alarm | 23 |
| Phase Monitor | 23 |
| Compressor Operation | 23 |
| Additional Compressor Alarms | 24 |
| Refrigerant Low Pressure Alarm..... | 24 |
| Economizer | 24 |
| Economizer Components | 24 |
| Actuator..... | 24 |
| Dust Sensor..... | 25 |
| Dust Sensor Failure Alarm..... | 25 |
| High Dust Limit Alarm | 25 |
| Damper Blade..... | 26 |
| Damper Switch | 26 |
| Damper Failed to Open Alarm..... | 26 |
| Damper Failed to Close Alarm..... | 26 |
| Outdoor Temperature and Humidity Combination Sensor | 26 |
| Outdoor Temperature Sensor Failure Alarm | 27 |
| Outdoor Humidity Sensor Failure Alarm | 27 |

| | | |
|--|-----------|--|
| Mixed Air Temperature Sensor.....27 | Figure 21 | Adjusting Suction Temperature Sensor Values16 |
| High Mixed Air Temperature Alarm.....27 | Figure 22 | Adjusting Evaporator Freeze Sensor Values17 |
| Low Mixed Air Temperature Alarm28 | Figure 23 | Putting Blower Output into Override Mode.....17 |
| Economizer Operation28 | Figure 24 | Dirty Filter Switch and Blower Status Switch.....18 |
| Economizer Operation – Minimum Position.....29 | Figure 25 | Verifying Differential Airflow Status18 |
| Miscellaneous Components30 | Figure 26 | Dirty Filter Switch and Filter Indicator Light19 |
| Supply Temperature Sensor30 | Figure 27 | Enabling Fan Override.....20 |
| Supply Temperature Sensor Failure Alarm30 | Figure 28 | Adjusting Discharge/Liquid Transducer Pressure Values20 |
| Emergency Cooling Mode30 | Figure 29 | Voltage to Pressure: Discharge/Liquid Pressure Transducer.....20 |
| Emergency Cooling – Orphan Mode30 | Figure 30 | Adjusting Discharge/Liquid Temperature Input.....21 |
| Emergency Ventilation Mode31 | Figure 31 | 8201-164 Compressor Control Module.....22 |
| Electric Heat Option31 | Figure 32 | Adjusting Compressor Delays24 |
| Electric Heat Components31 | Figure 33 | Damper Override24 |
| Electric Heating Element31 | Figure 34 | Dust Sensor25 |
| Thermal Overload.....31 | Figure 35 | Adjusting Dust Sensor Alarm Setpoint25 |
| Electric Heat Operation31 | Figure 36 | Damper Blade Position.....26 |
| Electric Reheat Dehumidification.....31 | Figure 37 | Damper Switch.....26 |
| Electric Reheat Dehumidification Operation32 | Figure 38 | Outdoor Temperature Sensor.....27 |
| Unit Disable Option.....32 | Figure 39 | Outdoor Humidity Sensor27 |
| Serial/Model Number Configuration.....33 | Figure 40 | Mixed Air Temperature Sensor27 |
| Refrigerant Information35 | Figure 41 | Economizer Setup28 |
| General35 | Figure 42 | Economizer Setup – Dry Bulb Control..... 29 |
| Topping Off System Charge35 | Figure 43 | Economizer Setup – TempHum Control 29 |
| Safety Practices.....35 | Figure 44 | Economizer Setup – Enthalpy Control29 |
| Important Installer Note.....35 | Figure 45 | Supply Air Temperature Sensor30 |
| R410-A Refrigerant Charge35 | Figure 46 | Emergency Cool – Orphan Mode30 |
| Pressure Service Ports36 | Figure 47 | Adjusting Return Air Alarm Settings31 |
| Maintenance.....37 | Figure 48 | Electric Reheat Dehumidification31 |
| Standard Maintenance Procedures.....37 | Figure 49 | Unit Disable Option32 |
| Troubleshooting38 | Figure 50 | Dehumidification Control (°F)32 |
| 8301-089 Outdoor Temperature/Humidity Sensor ..40 | Figure 51 | Serial/Model Number Configuration33 |
| 8620-296 Supply Air Sensor/Return Air Sensor/ | Figure 52 | MEGA-TEC Model Nomenclature.....34 |
| Mixed Air Sensor/Suction Sensor/Liquid Sensor.....43 | Figure 53 | Sensors and Peripheral Devices.....38 |
| 8301-057 Blower Status Switch/Dirty Filter Switch ..44 | Figure 54 | Supply and Return Air Sensors.....39 |
| Alarm Index.....45 | Figure 55 | 8301-089 Sensor DIP Switches and Terminal Block40 |
| Blower Speeds.....47 | Figure 56 | 8301-057 Air Differential Switch44 |
| | Figure 57 | Ventilation Airflow Paths.....48 |
| FIGURES AND TABLES | Table 1 | Unit Status Message7 |
| Figure 1 | Table 2 | LC6000/TEC-EYE Passwords (Defaults)10 |
| Figure 2 | Table 3 | Rated Airflow17 |
| Figure 3 | Table 4 | Indoor Blower Performance.....17 |
| Figure 4 | Table 5 | Maximum ESP of Operation: |
| Figure 5 | | Electric Heat Only18 |
| Figure 6 | Table 6 | Economizer Default Settings.....29 |
| Figure 7 | Table 7 | Cooling Capacity Limitation32 |
| Figure 8 | Table 8 | Cooling Pressures36 |
| Figure 9 | Table 9 | 8301-089 Sensor: Temperature/Resistance41 |
| Figure 10 | Table 10 | 8301-089 Sensor: Humidity/mA.....42 |
| Figure 11 | Table 11 | 8620-296 Sensor: Temperature/Resistance Curve J43 |
| Figure 12 | Table 12 | MEGA-TEC Alarm Index45 |
| Figure 13 | Table 13 | Blower Speeds47 |
| Figure 14 | | |
| Figure 15 | | |
| Figure 16 | | |
| Figure 17 | | |
| Figure 18 | | |
| Figure 19 | | |
| Figure 20 | | |

GENERAL INFORMATION

Multi-Stage Cooling System

This Bard cooling system is composed of MEGA-TEC Series wall-mounted air conditioners matched with an LC6000 lead/lag controller. The wall mounts are specifically engineered for telecom/motor control center rooms.

NOTE: *The LC6000 lead/lag controller and MEGA-TEC Series wall-mount units are designed specifically to work together. The controller cannot run other brands of systems, nor can other controllers run the MEGA-TEC Series wall-mount units. They are a complete system, and must be used together.*

Wall-Mount Air Conditioner Units

The wall-mount units operate on VAC power. The units will supply 100% of rated cooling airflow in free cooling mode with ability to exhaust the same amount through the unit itself without any additional relief openings in the shelter.

Each of these units are fully charged with refrigerant and have optional auxiliary heat.

General

The equipment covered in this manual is to be installed by trained, experienced service and installation technicians.

The refrigerant system is completely assembled and charged. All internal wiring is complete.

The unit is designed for use without duct work. Flanges are provided for transition from unit to wall grilles.

These instructions explain the recommended method to install the air cooled self-contained unit and the electrical wiring connections to the unit.

These instructions and any instructions packaged with any separate equipment required to make up the entire air conditioning system should be carefully read before beginning the installation. Note particularly any tags and/or labels attached to the equipment.

While these instructions are intended as a general recommended guide, they do not supersede any national and/or local codes in any way. Authorities having jurisdiction should be consulted before the installation is made. See **Additional Publications** for information on codes and standards.

Sizing of systems for proposed installation should be based on heat loss and heat gain calculations made according to methods of Air Conditioning Contractors of America (ACCA). The supply flange should be installed in accordance with the *Standards of the National Fire Protection Association for the Installation of Air*

Conditioning and Ventilating Systems of Other Than Residence Type, NFPA No. 90A, and Residence Type Warm Air Heating and Air Conditioning Systems, NFPA No. 90B. Where local regulations are at a variance with instructions, installer should adhere to local codes.

Shipping Damage

Upon receipt of equipment, the cartons should be checked for external signs of shipping damage. If damage is found, the receiving party must contact the last carrier immediately, preferably in writing, requesting inspection by the carrier's agent.

These units must remain in upright position at all times; do not lay on side. Do not stack units.

Additional Publications

These publications can help when installing the air conditioner. They can usually be found at the local library or purchased directly from the publisher. Be sure to consult the current edition of each standard.

National Electrical CodeANSI/NFPA 70
Standard for the Installation of Air Conditioning
and Ventilating SystemsANSI/NFPA 90A
Standard for Warm Air Heating
and Air Conditioning SystemsANSI/NFPA 90B
Load Calculation for Residential Winter
and Summer Air Conditioning ACCA Manual J

For more information, contact these publishers:

Air Conditioning Contractors of America (ACCA)
1712 New Hampshire Ave. N.W.
Washington, DC 20009
Telephone: (202) 483-9370 Fax: (202) 234-4721

American National Standards Institute (ANSI)
11 West Street, 13th Floor
New York, NY 10036
Telephone: (212) 642-4900 Fax: (212) 302-1286

**American Society of Heating, Refrigeration and Air
Conditioning Engineers, Inc. (ASHRAE)**
1791 Tullie Circle, N.E.
Atlanta, GA 30329-2305
Telephone: (404) 636-8400 Fax: (404) 321-5478

National Fire Protection Association (NFPA)
Batterymarch Park
P. O. Box 9101
Quincy, MA 02269-9901
Telephone: (800) 344-3555 Fax: (617) 984-7057

ANSI Z535.5 Definitions:

DANGER: Indicate[s] a hazardous situation which, if not avoided, will result in death or serious injury. The signal word “DANGER” is to be limited to the most extreme situations. DANGER [signs] should not be used for property damage hazards unless personal injury risk appropriate to these levels is also involved.

WARNING: Indicate[s] a hazardous situation which, if not avoided, could result in death or serious injury. WARNING [signs] should not be used for property damage hazards unless personal injury risk appropriate to this level is also involved.

CAUTION: Indicate[s] a hazardous situation which, if not avoided, could result in minor or moderate injury. CAUTION [signs] without a safety alert symbol may be used to alert against unsafe practices that can result in property damage only.

NOTICE: [this header is] preferred to address practices not related to personal injury. The safety alert symbol shall not be used with this signal word. As an alternative to “NOTICE” the word “CAUTION” without the safety alert symbol may be used to indicate a message not related to personal injury.



WARNING

Electrical shock hazard.

Have a properly trained individual perform these tasks.

Failure to do so could result in electric shock or death.

WARNING

Fire hazard.

Maintain minimum 1/4" clearance between the supply flange and combustible materials.

Failure to do so could result in fire causing damage, injury or death.

WARNING

Heavy item hazard.

Use more than one person to handle unit.

Failure to do so could result in unit damage or serious injury.

CAUTION

Cut hazard.

Wear gloves to avoid contact with sharp edges.

Failure to do so could result in personal injury.

USING THE TEC-EYE™

FIGURE 1
TEC-EYE (Bard P/N 8301-059) Display and Interface (Status Screen Shown)



- ALARM KEY**
Allows viewing of active alarms
Silences audible alarms
Resets active alarms
- MENU KEY**
Allows entry to Main Menu
- ESCAPE KEY**
Returns to previous menu level
Cancels a changed entry

- UP KEY**
Steps to next screen in the display menu
Changes (increases) the value of a modifiable field
- ENTER KEY**
Accepts current value of a modifiable field
Advances cursor
- DOWN KEY**
Steps back to previous screen in the display menu
Changes (decreases) the value of a modifiable field

TEC-EYE Hand-Held Service Tool


The TEC-EYE service tool is used to communicate with the MEGA-TEC unit logic board. By connecting directly to the logic board inside the unit control panel, it is possible to perform diagnostics on the unit, adjust certain settings and verify unit and economizer operation through a run test procedure. **The TEC-EYE service tool is required for unit setup and operation.** The TEC-EYE is supplied with the LC6000 controller but can also be ordered separately (Bard P/N 8301-059).

The menu driven interface provides users the ability to scroll through two menu levels: Quick Menu and Main Menu. The menus permit the user to easily view, control and configure the unit. See Figure 1 for TEC-EYE display and key functions.

The controller is completely programmed at the factory; the default setpoints and their ranges are easily viewed and adjusted from the TEC-EYE display. The program and operating parameters are permanently stored on FLASH-MEMORY in case of power failure.

The TEC-EYE connects to the wall-mount unit control board via an RJ11 modular phone connector as shown in Figure 2.

FIGURE 2
TEC-EYE Connection to Unit Control



When not being used, the TEC-EYE hand-held diagnostic tool should be stored inside or near the LC6000 controller. Do not let the TEC-EYE leave the shelter.

NOTE: Screenshots shown in this manual reflect default settings (when applicable).

TEC-EYE Menu Structure

- Quick Menu
 - Setpoints
 - Information
 - Alarm Log
- Main Menu
 - System Configuration
 - Advanced System Configuration
 - I/O Configuration
 - Digital Inputs
 - Digital Outputs
 - Analog Inputs
 - Analog Outputs
 - Fans/Blowers
 - Manual EEV
 - On/Off
 - Alarm Logs
 - Settings
 - Date/Time
 - Language
 - Initialization
 - Serial Ports
 - Change Password
 - Logout

In addition to the menu structure above, there are also Status and Alarm screens.

TEC-EYE Acronyms

- MAT – Mixed air temperature
- RAT – Return air temperature
- SAT – Supply air temperature
- OAT – Outdoor air temperature
- OAH – Outdoor air humidity
- Blower – Indoor blower speed
- Fan – Outdoor fan speed
- Econ – Free cooling

NOTE: *Digital refers to On/Off whereas analog is a variable input.*

Main Status Screen

The main Status screen is the default start-up screen and also the return screen after 5 minutes of no activity. The screen can be accessed at any time by pressing the ESCAPE key repeatedly.

The wall-mount unit address is displayed in the upper right corner on the main Status screen (see Figure 1). The main Status screen also shows the current date, time, mixed air temperature (MAT), return air temperature (RAT), supply air temperature (SAT), outdoor air temperature (OAT) and outdoor air humidity (OAH). Blower speed, condenser fan speed, damper position and unit status are also displayed. See Table 1 for wall-mount unit status messages.

The Quick Menu is accessible from the main Status screen. Setpoints, Information and Alarm Log are available through the Quick Menu. Pressing the UP

or DOWN keys while on the main Status screen will change the Quick Menu icon displayed (see Figure 3 on page 8). Press the ENTER key when the desired icon is displayed.

TABLE 1
Unit Status Messages

| Message | Description |
|-----------------|--|
| Waiting... | PLC is on and has not started running the application yet. |
| Orphan Mode | Unit is on and in orphan mode with no calls for heating or cooling. |
| LC Online | Unit is on and communicating with the LC6000 with no heating or cooling calls. |
| Cont. Blower | Unit is operating with continuous blower when no heating or cooling calls are present. |
| Freecooling | Unit is actively economizing. |
| Optimized Cool | Unit is mechanical cooling while actively economizing. |
| Cooling | Unit is actively mechanical cooling. |
| Heating | Unit is actively heating. |
| Passive Dehum | Unit is taking measures to decrease humidity without using extra energy. |
| Active Dehum | Unit is currently in active dehumidification mode and will be utilizing electric reheat to reduce the humidity level in the space. |
| Self Test | Unit is performing a run test. |
| Off by Alarm | Unit has major fault preventing operation. |
| Off by LC | Unit has been turned off by the supervisory controller. |
| Off by Keyboard | Unit has been turned off by the local user. |
| Emergency Vent | Unit is in Emergency Ventilation. LC6000 has an active hydrogen alarm. |
| Emergency Cool | Unit is in Emergency Cooling. Indoor temperatures have exceeded high temp alarms. |
| Emergency Off | Unit is in Emergency Off. LC6000 has an active smoke alarm. |

FIGURE 3
Quick Menu Icons



Quick Menu

Setpoints

From this screen, the local unit heating and cooling setpoints, used for orphan mode only, can be changed.


Once the supervisory controller is connected, cooling and heating setpoints will be communicated and local cooling and heating setpoints will be replaced with the communicated cooling and heating setpoints.

If at any time the wall-mount unit(s) loses communication with the LC6000 controller, the wall-mount unit(s) will go into orphan mode and operate using the last communicated setpoints.

To verify or change the wall-mount unit cooling and heating setpoints in orphan mode:

1. Connect the TEC-EYE diagnostic tool to the control board located in the unit.
2. From the Status screen, press UP or DOWN key until Quick Menu displays Setpoints icon. Press ENTER key.
3. Press ENTER key to scroll to the selected choice (see Figure 4).
4. Press UP or DOWN key on desired value until value displays correctly.
5. Press ENTER key to save and scroll to next parameter.
6. Press ESCAPE key until Main Menu screen is displayed.

FIGURE 4
Cool and Heat Setpoints



Information

The information screens are used as a quick reference to show unit A/C circuit measurements and program version.


A/C Circuit Information

MEGA-TEC Series wall-mounted air conditioners have two separate refrigeration circuits: Circuit 1 is located on the left side of the unit and circuit 2 is on the right side (see Figure 5).

Circuit 1 uses a 2 stage scroll compressor and electronic expansion valve along with high and low pressure transducers. Suction temperature is also measured to provide superheat of circuit 2. Circuit 2 uses a single stage compressor and electronic expansion valve along with high and low pressure transducers. Suction temperature is also measured to provide superheat of circuit 1.

Using both circuit 1 and circuit 2, the MEGA-TEC unit can provide 35%, 80%, and 100% cooling capacity. Separate refrigeration circuits also allow for operation of the unit at partial capacity if service is required on one circuit.


FIGURE 5
MEGA-TEC Refrigeration Circuits



A/C Circuit Information can be found in four screens within the information menu (see Figure 6). The information and measurements provided are liquid line

temperature, liquid line pressure, condensing saturated temperature, suction line temperature, suction line pressures, suction saturated temperature, super heat, subcooling and electronic expansion valve position.

FIGURE 6
A/C Circuit Measurements



Program Version

The Program Version screen displays the model number of the unit as well as all program version information for the PLC (see Figure 7). This information can be used to determine whether a software update may be required based on information found in the software change log. This change log can be found at <http://www.bardhvac.com/software-download/>.

FIGURE 7
Program Version



NOTICE

It is important to check the software version during installation to ensure that the latest version has been installed. Current software versions, change log and installation instructions are available on the Bard website at <http://www.bardhvac.com/software-download/>

Alarm Log

The alarm log screens show a log of each alarm. There will be a log for when alarm occurred and if the alarm auto clears, it will show when the alarm cleared. See page 11 for information on clearing alarms.

Menu Screens and Password Levels

- A System Config: A1-A5 User (2000)
- B Adv Sys Config: B1-B4 Technician (1313)
- C I-O Config: Technician (1313)
- D On/Off: User (2000)
- E Alarm Logs: User (1313)
- F Settings
 - Date/Time: Technician (1313)
 - Language: User (2000)
 - Serial Ports: Technician (1313)
 - Password Change
 - Initialization
 - Alarm Initialization: User (2000)
 - Default Installation: Engineer (9254)
 - Parameters Import/Export: Engineer (9254)
 - Alarm Export: User (2000)
 - Unit of Measure:
- G Logout: Used to log out of the current password level. Entering back into the menu requires password.

TABLE 2
LC6000/TEC-EYE Passwords (Defaults)

| | |
|---|------|
| User | 2000 |
| Technician | 1313 |
| Engineer | 9254 |
| Use UP or DOWN keys and ENTER key to enter password | |

The passwords listed above are the default passwords. End users can change these passwords if additional security is desired.


Executing a Run Test

This unit has the ability to perform a run test that will operate all available unit functions in order to quickly determine unit operation. Some unit parameters are adjustable.

To execute a run test:

1. Press MENU key to access the Main Menu screen.
2. Press UP or DOWN keys and ENTER key to enter TECHNICIAN password 1313.
3. Press UP or DOWN keys to scroll to **Sys Config**; press ENTER key.
4. Press UP or DOWN keys to scroll to **Run Test A10** screen.
5. Press ENTER key to scroll to **Enable** parameter (see Figure 8).
6. Press UP or DOWN key to change value to **Yes**. The run test will begin.

FIGURE 8
Executing Run Test



Run Test Parameter Descriptions

Econ Stage Time: Amount of time (in seconds) allowed for damper blade movement in each direction.


Heat/Cool Stage Time: Amount of time (in seconds) allowed for each stage of heating or cooling.

Reset to Factory Defaults

To reset to factory default settings:

1. Press MENU key to go to the Main Menu screen.
2. Use UP or DOWN keys and ENTER key to enter ENGINEER password 9254.
3. Press UP or DOWN keys to scroll to **Settings**; press ENTER key.
4. Press UP or DOWN keys to scroll to **Initialization**; press ENTER key.
5. Press UP or DOWN keys to scroll to the **Default Installation** screen.
6. Press ENTER key to scroll to **Wipe retain mem.** (see Figure 9).
7. Press UP or DOWN key to change value to **YES**; press ENTER key.
8. System will restart with default values.

FIGURE 9
Restoring Factory Default Settings



NOTE: Screenshots shown in this manual reflect default settings (when applicable).

Unit On/Off

The wall-mount unit can be turned on and off from the TEC-EYE. Turning the unit off with the following instructions will disable all unit operation.

To turn the unit on or off:

1. Press MENU key to go to the Main Menu screen.
2. Press UP or DOWN keys and ENTER key to enter USER password 2000.
3. Press UP or DOWN keys to scroll to **On/Off**; press ENTER key.
4. Press UP or DOWN keys to change value from On to Off or from Off to On.
5. Press ESCAPE key several times to return to Main Menu screen.

The wall-mount unit may also be turned off by certain events such as the unit disable input, blower offline, fan offline, panel switch open or the return air temperature sensor failure when not connected to the LC6000.

The unit will also be turned off if the unit loses communication with the expansion board, blower motor, condenser fan motor or panel switch for blower or condenser fan compartment.

Alarm Adjustment

Acknowledging Alarms

Alarm conditions activate a red LED indicator that backlights the ALARM function key. As an option, an alarm condition may also be enunciated by an audible alarm signal. An alarm is acknowledged by pressing the ALARM key. This calls up alarm display screen(s) that provide a text message detailing the alarm condition(s).

Clearing Alarms

Alarms can only be cleared after the alarm condition has been corrected. To clear a single alarm, press and hold the ALARM key for 3 seconds while viewing a specific alarm screen. To clear all alarms, navigate to the screen at the end of the alarm list (shown in Figure 10) and press and hold the ALARM key for 3 seconds.

FIGURE 10
Clearing All Alarms




Clearing Alarm Logs and Counters

To clear the alarm log and alarm counters:

1. Press MENU key to go to the Main Menu screen.
2. Use UP or DOWN keys and ENTER key to enter USER password 2000.
3. Press UP or DOWN keys to scroll to **Settings**; press ENTER key.
4. Press UP or DOWN keys to scroll to **Initialization**; press ENTER key. (**Alarm initialization** screen will be displayed.)
5. Press ENTER key to scroll to **Delete alarm logs?** (see Figure 11).
6. Press UP or DOWN key to change value to **YES**; press ENTER key.
7. Press ENTER key to scroll to **Clear AutoReset counters?**
8. Press UP or DOWN key to value to **YES**; press ENTER key.

FIGURE 11
Clearing Alarm Logs and Counters



Exporting Alarm Logs

See latest version of Supplemental Instructions manual 7960-825 for information on exporting alarm logs.

Exporting 7 Day Logs

See latest version of Supplemental Instructions manual 7960-826 for information on exporting 7 day I/O logs.

Exporting Parameters

See latest version of Supplemental Instructions manual 7960-827 for information on exporting parameters.


Zone

When paired with a supervisory controller that uses zones to control groups of wall units, this unit uses the zone setting to relay to the supervisory controller what zone it is set to operate in. Up to three zones can be established with up to 14 units in a single zone. (The LC6000 supervisory controller can control up to a total of 14 units.)

To change the zone:

1. Press MENU key to access the Main Menu screen.
2. Press UP or DOWN keys and ENTER key to enter TECHNICIAN password 1313.
3. Press UP or DOWN keys to scroll to **Sys Config**; press ENTER key.
4. Press UP or DOWN keys to scroll to **Unit Setup A1** screen.
5. Press ENTER key to scroll to **Zone** (see Figure 12).
6. Press UP or DOWN keys to change to the desired value (1, 2 or 3).
7. Press ENTER key to save value.

FIGURE 12
Changing Zone



Temperature Control

Temperature Control Components


Return Air Temperature Sensor

The unit is equipped with a return air temperature sensor to monitor the space temperature when the unit is in orphan mode. The return air sensor is located in the upper part of the return opening in such a way that it is exposed to the entering airstream. An alarm signal will be sent to the LC controller if the return air temperature sensor is disconnected. The temperature is measured with a 10k ohm NTC thermistor.

This sensor can be verified and adjusted by:

1. Press MENU key to go to the Main Menu screen.
2. Press UP or DOWN keys and ENTER key to enter TECHNICIAN password 1313.
3. Press UP or DOWN keys to scroll to **I/O Config**; press ENTER key.
4. Press UP or DOWN keys to scroll to **Analog Inputs**; press ENTER key.
5. Press UP or DOWN keys to scroll to **Analog Ins 1/19**.
6. Verify the measurement displayed on screen is accurate (see Figure 13).
7. If the measurement needs to be adjusted, apply an offset value by pressing ENTER to scroll to **Offset**.
8. Press UP or DOWN keys to adjust the offset.
9. The update will not take effect until the cursor is moved out of the **Offset** parameter.
10. Once adjusted, press the ESCAPE key several times to return to Main Menu screen.

FIGURE 13
Adjusting Return Air Temperature Sensor



Return Air Temperature Alarm


When the return air temperature sensor value is out of range (-41.0 to 303.0°F), the controller will generate a sensor failure alarm to indicate the sensor is not working properly.

This alarm is fixed and cannot be adjusted.

Temperature Control Operation

The unit utilizes differentials while in orphan mode to control the space temperature. The differential values all reference the setpoint therefore allowing the control band to be easily changed using the setpoint. To change specific staging characteristics, each differential can be modified individually. There are separate setpoints and differentials for cooling and heating. Specific to the cooling differentials, the economizer will always be utilized first on a cooling call unless outdoor conditions are not acceptable for free cooling. In this case, the compressor will be activated at stage 1 in place of the economizer. All remaining stages will be shifted until the economizer becomes available again.

To change or view the unit setpoint:

1. From the Status screen, press UP or DOWN key until Quick Menu displays Setpoints icon (). Press ENTER key.
2. Press ENTER key to scroll to **Cool Setpoint** or **Heat Setpoint** (see Figure 4 on page 8).
3. Press UP or DOWN keys to change the value to desired heating and/or cooling setpoint.

Orphan Mode

MEGA-TEC Series wall-mount units have the capability to run without the LC6000 controller attached—this feature is called orphan mode. This keeps the shelter between 60°F and 77°F (factory default settings) by the use of the factory-installed return air sensor in each wall-mount unit. In orphan mode, no auxiliary temperature measurement devices are required for operation. The wall-mount unit automatically uses a continuous blower setting to circulate room air into the return air inlet and uses the return air temperature sensor to control room temperature.

If at any time the wall-mount unit(s) loses communication with the LC6000 controller, the wall-mount unit(s) will go into orphan mode and operate using the last communicated setpoints.

To change default setpoints, refer to **Setpoints** on page 8.

During installation, the ability to run in orphan mode allows deactivation of one of the existing, older wall-mount units, while keeping the shelter cool with the other unit still operating. Once the first of the Bard wall-mount units is installed and powered on, it will

operate in orphan mode—keeping the climate inside the shelter stable and the installers comfortable while the remainder of the older equipment is removed and the remaining Bard wall-mount units and LC6000 controller are installed.

Additionally, should any or all of the MEGA-TEC Series wall-mount units lose communication with the LC6000 controller (such as during maintenance), they will continue to serve the shelter’s needs until a repair can be made.

LC6000 Control

When the unit is connected to a LC6000 supervisory controller, the cooling and heating stages will be controlled by the LC6000. For more information on LC6000 staging, see latest version of LC6000 Service Instructions 2100-669.

Cooling (with Economizer)

If equipped with an economizer, the unit is equipped with 1 stage of free cooling and 3 stages of mechanical cooling for a total of 4 cooling stages (see Figure 14).

Cooling (without Economizer)

In a situation where the unit is either not equipped with an economizer or is equipped with an economizer but the outdoor conditions are not favorable for economizer operation, the staging will use Stage 1, 2 or 3 differentials (see Figure 15 on page 14).

Heating

The unit can be equipped with 0, 1 or 2 stages of electric heat (see Figure 16 on page 14).

FIGURE 14
Cooling (with Economizer)




FIGURE 15
Cooling (without Economizer)





FIGURE 16
Heating



Electronic Expansion Valve (EEV)

EEV Components

Electronic Expansion Valve

The electronic expansion valve is a stepper motor that is controlled with a step output from the controller. The valve is capable of 480 steps represented by a 0-100% signal on the controller. The motor drives a needle valve that regulates the flow of refrigerant.

EEV Instructions for Vacuum, Reclaim, Charge Unit

The electronic expansion valve moves to the 20% open position when the unit is not actively cooling. The valve may need to be manually positioned for service or troubleshooting. The valve can be positioned by using a menu override.


To manually override the valve:

NOTE: The unit must be off to perform this override.

1. Press MENU key to go to the Main Menu screen.
2. Press UP or DOWN keys and ENTER key to enter TECHNICIAN password 1313.
3. Press UP or DOWN keys to scroll to **I/O Config**; press ENTER key.

4. Press UP or DOWN keys to scroll to **Manual EEV**; press ENTER key.
5. Press UP or DOWN keys to scroll to **EEV Circuit 1** or **EEV Circuit 2**.
6. Press ENTER key to scroll to **Service Pos** (see Figure 17).
7. Press UP or DOWN keys to adjust to the desired value.
8. Press ENTER key to scroll to **Enable**.
9. Press UP or DOWN key to change **Off** to **On**.
10. Press ENTER key to save.

FIGURE 17
Overriding EEV Output




The valve can also be opened or closed using the EEV service tool (Bard Part # 2151-021). This magnetic EEV service tool (shown in Figure 18) is used to manually open the EEV. To do this, remove the EEV stator coil (red color with retaining nut on top), slide the magnetic tool over the shaft where the stator was removed and turn in a clockwise direction to open the valve to the full open position (directional arrows are provided on the tool). Opening the valve to the full open position will aid in the refrigerant reclamation and evacuation processes.

With the stator removed, the resistance should be 40 ohms +/- 10%. There are two sets of three wires that will have this resistance.


After removing the EEV service tool, reapply the EEV stator coil and retaining nut. Upon powering the unit back up, the control board will automatically drive the EEV back to the fully shut position, and then back to the 20% open position prior to starting the compressor back up. Once the compressor starts, the control board will again modulate the EEV position to control the system superheat.

FIGURE 18
Electronic Expansion Valve (EEV) and Service Tool



System Pressures

To view system pressure and temperatures during this process:

1. From the Status screen, press UP or DOWN key until Quick Menu displays Unit Information icon (). Press ENTER key.
2. Press UP or DOWN keys to scroll to **A/C Circuit 1 Info** and **A/C Circuit 2 Info** screens (see A/C Circuit Measurements on page 8).

Suction Pressure Transducer


The unit has pressure transducers installed on the suction line between the evaporator coil and compressor (one on refrigerant circuit 1 and one on refrigerant circuit 2). The transducer is used for system monitoring of suction system pressures. The sensor is

used with the suction temperature sensor to provide a real time superheat calculation that determines the EEV position.

This sensor can be verified and adjusted by:

1. Press MENU key to go to the Main Menu screen.
2. Press UP or DOWN keys and ENTER key to enter TECHNICIAN password 1313.
3. Press UP or DOWN keys to scroll to **I/O Config**; press ENTER key.
4. Press UP or DOWN keys to scroll to **Analog Inputs**; press ENTER key.
5. Press UP or DOWN keys to scroll to **Analog Ins 6/19** (for circuit 1) or **Analog Ins 8/19** (for circuit 2).
6. Verify the measurement displayed on screen is accurate (see Figure 19).
7. If the measurement needs to be adjusted, apply an offset value by pressing ENTER to scroll to **Offset**.
8. Press UP or DOWN keys to adjust the offset.
9. The update will not take effect until the cursor is moved out of the **Offset** parameter.
10. Once adjusted, press the ESCAPE key several times to return to Main Menu screen.

FIGURE 19
Adjusting Suction Sensor/Transducer Pressure Values



Troubleshooting the Suction Pressure Transducer

0-250 psig

-5v Nominal, .5 – 4.5v Actual


4v/250 psig = .016 volts per 1 psig

Example: 125 psig x .016 + .5 volts = 2.5 volts

Formula for Tech:

Measured Pressure x .016 + Voltage Offset = Expected Transducer Signal Voltage (see Figure 20 on page 16).

FIGURE 20
Voltage to Pressure: Suction Pressure Transducer



Suction Pressure Alarm

When the suction pressure transducer value is measured out of range (0-250 PSIG) and the compressor has been operating for longer than 1 minute, the controller will generate a sensor failure alarm to indicate the sensor is not working properly.

This alarm cannot be adjusted.


Suction Temperature Sensor

The suction temperature sensor is used to calculate superheat. The EEV uses this value to control the EEV. The temperature is measured with a 10k ohm NTC thermistor.

The suction temperature sensor measurement can be verified and adjusted by:

1. Press MENU key to go to the Main Menu screen.
2. Press UP or DOWN keys and ENTER key to enter TECHNICIAN password 1313.
3. Press UP or DOWN keys to scroll to **I/O Config**; press ENTER key.
4. Press UP or DOWN keys to scroll to **Analog Inputs**; press ENTER key.
5. Press UP or DOWN keys to scroll to **Analog Ins 10/19** (for circuit 1) or **Analog Ins 11/19** (for circuit 2).
6. Verify the measurement displayed on screen is accurate (see Figure 21).
7. If the measurement needs to be adjusted, apply an offset value by pressing ENTER to scroll to **Offset**.
8. Press UP or DOWN keys to adjust the offset.
9. The update will not take effect until the cursor is moved out of the **Offset** parameter.

FIGURE 21
Adjusting Suction Temperature Sensor Values



Suction Temperature Alarm

When the suction temperature sensor value is out of range (-41.0 to 303.0°F), the controller will generate a sensor failure alarm to indicate the sensor is not working properly.

This alarm cannot be adjusted.


Evaporator Freeze Condition Alarm

The freeze condition alarm uses a temperature sensor attached to the evaporator coil to determine if the evaporator is cold enough to potentially start building ice. The controller will generate this alarm when the compressor is running and the coil temperature is below 32°F for 2 minutes. While the alarm is active, the compressor will be deactivated and the blower speed will be set to 80%. The evaporator temperature needs to warm back up to the reset temperature of 55°F or 5 minutes must pass before the alarm will clear and the compressor will be permitted to run again.

The evaporator freeze sensor measurement can be verified and adjusted by:

1. Press MENU key to go to the Main Menu screen.
2. Press UP or DOWN keys and ENTER key to enter TECHNICIAN password 1313.
3. Press UP or DOWN keys to scroll to **I/O Config**; press ENTER key.
4. Press UP or DOWN keys to scroll to **Analog Inputs**; press ENTER key.
5. Press UP or DOWN keys to scroll to **Analog Ins 13/19** (for circuit 1) or **Analog Ins 14/19** (for circuit 2).
6. Verify the measurement displayed on screen is accurate (see Figure 22).
7. If the measurement needs to be adjusted, apply an offset value by pressing ENTER to scroll to **Offset**.
8. Press UP or DOWN keys to adjust the offset.
9. The update will not take effect until the cursor is moved out of the **Offset** parameter.

FIGURE 22
Adjusting Evaporator Freeze Sensor Values



EEV Operation

EEV Superheat Control

The electronic expansion valve (EEV) will open or close to maintain 10° of superheat while the compressor is running. When the compressor is not running, the valve will close to the 20% open default position.

Low superheat protection will be active once the superheat value is at or below 5°F. At this point, the control will aggressively close the valve so that superheat is maintained.

Additional EEV Alarms

Low Superheat Alarm

This alarm will become active when the calculated superheat goes below 5°F. This alarm will clear itself when the condition is no longer present.

This alarm cannot be adjusted.

Indoor Airflow

Indoor Airflow Components

Blower

The unit is equipped with a blower that is driven by an electronically commutated motor (ECM). The blower is controlled by a 0-100% signal through Modbus communication. The motor controller converts this signal to a PWM signal. The blower on the W120A model uses a 22" (560 mm) diameter wheel and operates between 550-1150 rpm.

The blower output can be put into an override mode for verification or troubleshooting.

To put the blower into override:

1. Press MENU key to go to the Main Menu screen.
2. Press UP or DOWN keys and ENTER key to enter TECHNICIAN password 1313.
3. Press UP or DOWN keys to scroll to **I/O Config**; press ENTER key.
4. Press UP or DOWN keys to scroll to **Fans / Blowers**; press ENTER key.

5. Press UP or DOWN keys to scroll to **Blower 1**.
6. Press ENTER key to scroll to **Blower Overrides?** (see Figure 23).
7. Press UP or DOWN key to change **No** to **Go**. The override will begin and the screen will change to the override screen (see Figure 23).

The override will last for 5 minutes or until the **Blower Overrides** parameter is set to **No** again.

FIGURE 23
Putting Blower Output into Override Mode





TABLE 3
Rated Airflow

| | Nominal Rated CFM | | Nominal Rated ESP |
|-------|-------------------|------|-------------------|
| | High | Low | |
| W120A | 4000 | 2800 | 0.30 |

TABLE 4
Indoor Blower Performance

| | ESP (Inch H ₂ O) | Dry Coil | Wet Coil |
|-------|-----------------------------|----------|----------|
| W120A | 0.30 | 4160 | 3890 |

TABLE 5
Maximum ESP of Operation
Electric Heat Only

| Model | Static Pressure* |
|-------|------------------|
| -B0Z | .50" |
| -B09 | .50" |
| -B18 | .50" |
| -C0Z | .50" |
| -C09 | .50" |
| -C18 | .50" |

* Unit is rated for free blow non-ducted operation with SG-10W Supply Grille and RG-10W Return Grille.

Blower Status Switch

The unit is equipped with a differential pressure airflow switch to monitor the blower (see Figure 24). If the blower is turned on and the switch doesn't close to indicate there is differential pressure between the inlet and outlet of the blower, an alarm will be generated. For switch settings, see Figure 24.

Differential airflow status can be viewed by:

1. Press MENU key to go to the Main Menu screen.
2. Press UP or DOWN keys and ENTER key to enter TECHNICIAN password 1313.
3. Press UP or DOWN keys to scroll to **I/O Config**; press ENTER key.
4. Press UP or DOWN keys to scroll to **Digital Inputs**; press ENTER key.
5. Reference **Airflw 1** row and **Val** column (see Figure 25).

FIGURE 24
Dirty Filter Switch and Blower Status Switch




FIGURE 25
Verifying Differential Airflow Status

| Digital Ins | | | 1/2 |
|-------------|-----|-----|-----|
| Channel | En | Dir | Val |
| Disable | Yes | N/C | Off |
| CCM1 | Yes | N/O | Off |
| CCM2 | Yes | N/O | Off |
| Airflw 1 | Yes | N/O | On |
| Airflw 2 | No | N/O | On |
| Filter 1 | Yes | N/O | Off |

Blower Status Alarm

When the blower is on for 45 seconds and no airflow is detected by the airflow switch, the compressor and heating operations will be disabled. The system will wait 5 minutes before trying again. After three consecutive no airflow events, the system will generate an alarm and lockout requiring a user reset.

Filters

The unit is equipped with four (4) 20" x 24" x 2" MERV 8 filters (two per coil). The filters lift and slide into position making them easy to service. The filters can be serviced by opening the "hinged" front access panel and locking it into position. Then lift and slide into position as needed.

Dirty Filter Switch

These units are equipped with a differential pressure switch to indicate when the filter(s) needs to be replaced (see Figure 24). The dirty filter switch measures the pressure difference across the filter through silicone tubing routed to the blower and evaporator areas of the unit.

The switch circuit consists of a *normally open* filter pressure switch. The switch will open when the pressure differential goes above the setting indicated on the dial. When the pressure difference returns below the setting on the dial, the switch will close.


Adjustment of dirty filter switch may be necessary to ensure proper operation. See Figure 26 to aid in setting the filter switch to operate at different percentages of filter blockage.

Dirty Filter Alarm

The wall-mount unit is equipped with a differential pressure switch input to the controller. When the switch indicates a dirty filter, the controller will generate an alarm. The alarm will latch once triggered requiring a technician to acknowledge the alarm after replacing filters. Additionally, an indicator light will be turned on with the alarm and turned off when the alarm clears.

The threshold of this alarm is adjusted by changing the settings on the switch (see Figure 26).

FIGURE 26
Dirty Filter Switch and Filter Indicator Light



Filter Indicator Light

The wall-mount unit is equipped with a 24v indicator light mounted on side of unit that displays the current status of the filter (see Figure 26). When the light is on, the filter needs to be replaced. Once the filter(s) has been changed and the alarm has been cleared, the indicator light will turn off.

Indoor Airflow Operation

Blower Speed Control

The blower is capable of changing speeds to best match the requirements of the system depending on which mode the system is in.

The unit will automatically switch to the required speed for each mode. High sensible mode and dehumidification mode are both communicated separately from the LC. For more information on the high sensible command from LC, please see LC6000 Service Instructions 2100-669.

Additional Indoor Airflow Alarms

Supply Air Temperature Alarm

When the supply air temperature sensor value is out of range (-41.0 to 303.0°F), the controller will generate a sensor failure alarm to indicate the sensor is not working properly.

This alarm is fixed and cannot be adjusted.

Condenser Fan

Condenser Fan Components

Condenser Fan

The unit is equipped with a condenser fan that is driven by an electronically commutated motor (ECM). This fan is controlled by a 0-100% command using modbus serial communication. The fan operates between 100-1200 rpm.


To enable fan override:

1. Press MENU key to go to the Main Menu screen.
2. Press UP or DOWN keys and ENTER key to enter TECHNICIAN password 1313.

3. Press UP or DOWN keys to scroll to **I/O Config**;
press ENTER key.
4. Press UP or DOWN keys to scroll to **Fans / Blowers**;
press ENTER key.
5. Press UP or DOWN keys to scroll to **Condenser Fan 1** (see Figure 27).
6. Press ENTER key to scroll to the **Fan Overrides?**
7. Press UP or DOWN keys to change the value from **No** to **Go**. The override will begin and the screen will change to the override screen (see Figure 27).

The override will last for 5 minutes or until the **Fan Overrides** parameter is set to **No** again.

FIGURE 27
Enabling Fan Override



Liquid Pressure Sensor


The unit has a pressure transducer installed on the liquid line between the condenser and electronic expansion valve (EEV). The transducer is used for condenser fan speed control and for monitoring of system operation. The liquid line transducer is also referred to as the discharge pressure sensor.

The discharge/liquid pressure sensor input can be verified and adjusted by:

1. Press MENU key to go to the Main Menu screen.
2. Press UP or DOWN keys and ENTER key to enter TECHNICIAN password 1313.
3. Press UP or DOWN keys to scroll to **I/O Config**;
press ENTER key.
4. Press UP or DOWN keys to scroll to **Analog Inputs**;
press ENTER key.

5. Press UP or DOWN keys to scroll to **Analog Ins 7/19** (for circuit 1) or **Analog Ins 9/19** (for circuit 2).
6. Verify the measurement displayed on screen is accurate (see Figure 28).
7. If the measurement needs to be adjusted, apply an offset value by pressing the ENTER key to scroll to **Offset**.
8. Press UP or DOWN keys to adjust the offset. The update will not take effect until the cursor is moved out of the offset parameter.
9. Once adjusted, the ESCAPE key several times to return to Main Menu screen.

FIGURE 28
Adjusting Discharge/Liquid Transducer Pressure Values



Troubleshooting the Discharge/Liquid Pressure Transducer

0-650 psig

.5 to 4.5v


$4.5 - .5 + 4 \text{ volt range} / 650 \text{ psig} = .00615 \text{ volts per 1 psig}$

Example: $325 \text{ psig} \times .00615 + .5 \text{ v} = 2.5 \text{ volts}$

Formula for Tech:

$\text{Measured Pressure} \times .00615 + \text{Voltage Offset} = \text{Expected Transducer Signal Voltage}$ (see Figure 29).

FIGURE 29
Voltage to Pressure:
Discharge/Liquid Pressure Transducer



Discharge/Liquid Pressure Transducer Alarm

When the discharge pressure sensor value is out of range (0-650 PSIG), the controller will generate a sensor failure alarm to indicate the sensor is not working properly.

This alarm is fixed and cannot be adjusted.


Liquid Temperature Sensor

The unit is equipped with a liquid line temperature sensor to monitor the temperature of the liquid refrigerant leaving the condenser and entering the EEV. The temperature is measured with a 10k ohm NTC thermistor.

The liquid temperature sensor can be verified and adjusted by:

1. Press MENU key to go to the Main Menu screen.
2. Press UP or DOWN keys and ENTER key to enter TECHNICIAN password 1313.
3. Press UP or DOWN keys to scroll to **I/O Config**; press ENTER key.
4. Press UP or DOWN keys to scroll to **Analog Inputs**; press ENTER key.
5. Press UP or DOWN keys to scroll to **Analog Ins 16/19** (for circuit 1) or **Analog Ins 17/19** (for circuit 2).
6. Reference the **Value** to verify the temperature (see Figure 30).
7. If an offset needs to be applied, press ENTER key to scroll to **Offset**.
8. Press UP or DOWN keys to change the offset to desired value.
9. Press ENTER key to save.
10. Press ESCAPE key several times to return to Main Menu screen.

FIGURE 30
Adjusting Discharge/Liquid Temperature Input



Outdoor Temperature Sensor

The unit is equipped with a combination outdoor temperature and humidity sensor. The temperature is measured with a 10k ohm NTC thermistor. See page 26 for more information.

Condenser Fan Operation

Condenser Fan Speed Control

The fan will speed up or slow down to attempt to maintain a discharge pressure. The unit will allow the discharge pressure setpoint to increase for high ambient scenarios or decrease for low ambient scenarios. Because the control is dependent on the discharge pressure sensor, the controller will alter its operation if the sensor is not enabled or failed. When the liquid pressure transducer is not enabled or considered failed by the controller, a nominal speed of 74% will be used during a compressor call.

Compressor

Compressor Components

Compressor

Three Phase Scroll Compressor Start Up Information

Scroll compressors, like several other types of compressors, will only compress in one rotational direction. Direction of rotation is not an issue with single phase compressors since they will always start and run in the proper direction.

However, three phase compressors will rotate in either direction depending upon phasing of the power. Since there is a 50-50 chance of connecting power in such a way as to cause rotation in the reverse direction, verification of proper rotation must be made. Verification of proper rotation direction is made by observing that suction pressure drops and discharge pressure rises when the compressor is energized. Reverse rotation also results in an elevated sound level over that with correct rotation, as well as substantially reduced current draw compared to tabulated values.

Verification of **proper rotation** must be made at the time the equipment is put into service. If improper rotation is corrected at this time, there will be no negative impact on the durability of the compressor. However, reverse operation for over 1 hour may have a negative impact on the bearing due to oil pump out.

NOTE: *If compressor is allowed to run in reverse rotation for an extended period of time, the compressor's internal protector will trip.*

All three phase compressors are wired identically internally. As a result, once the correct phasing is determined for a specific system or installation, connecting properly phased power leads to the same Fusite terminal should maintain proper rotation direction.

The direction of rotation of the compressor may be changed by reversing any two line connections to the wall-mount unit.

Compressor Control Module (CCM)

- Delay-on-Make Timer
- Short Cycle Protection/Delay-on-Break
- Test Mode
- High Pressure Detection
- Brownout Protection with Adjustment

The LPC terminals are jumpered in this application. Instead, the low pressure transducer is used for low pressure monitoring.

Delay-on-Make Timer

In the event of power loss, a delay-on-make timer is included to be able to delay startup of the compressor. This is desired when more than one unit is on a structure so that all of the units do not start at the same time which could happen after a power loss or building shutdown. The delay-on-make time period is 2 minutes plus 10% of the delay-on-break time period. To ensure that all of the units do not start at the same time, adjust the delay-on-break timer on each unit to a slightly different delay time.

Short Cycle Protection/Delay-on-Break


An anti-short cycle timer is included to prevent short cycling the compressor. This is adjustable from 30 seconds to 5 minutes via the adjustment knob (see Figure 31). Once a compressor call is lost, the time period must expire before a new call will be initiated.

10% of this time is also considered on the delay-on-make timer (see **Delay-on-Make Timer**).

High Pressure Detection

High pressure switch monitoring allows for a lockout condition in a situation where the switch is open. If the high pressure switch opens, the CCM will de-energize the compressor. If the switch closes, it will then restart the compressor after the delay-on-break setting has expired on the device. If the switch trips again during the same Y call, the compressor will be de-energized. The ALR terminal will be energized, signaling the unit control board that a high pressure event has occurred (see **Refrigerant High Pressure Alarm** on page 23).

FIGURE 31
8201-164 Compressor Control Module



* Turn on only one switch for that specific ignore time setting

Test Mode

By rapidly rotating the potentiometer (POT) clockwise (see Figure 31), all timing functions will be removed for testing.

The conditions needed for the unit to enter test mode are as follows: POT must start at a time less than or equal to the 40 second mark. The POT must then be rapidly rotated to a position greater than or equal to the 280 second mark in less than ¼ second. Normal operation will resume after power is reset or after the unit has been in test mode for at least 5 minutes.

Brownout Protection with Adjustment

Brownout protection may be necessary if the utility power or generator power has inadequate power to prevent the voltage from dropping when the compressor starts. This is rare but can happen if the generator is undersized at the site or if the site is in a remote location far from the main power grid. Under normal circumstances, allowing the brownout to be ignored for a time period should not be needed. The 8201-164 is shipped with all the DIP switches in the 'off' or 'do not ignore' position (see Figure 31).

If ignoring the brownout is needed because of the above conditions, three preset timers can be set by DIP switches in order to delay signaling a power brownout for a specific length of time after compressor contactor is energized. This allows the compressor a time period to start even if the voltage has dropped and allows the voltage to recover. This delay only happens when the CC terminal energizes. The delay can be set to 500 milliseconds (A DIP switch), 1000 milliseconds (B DIP switch) or 1500 milliseconds (C DIP switch); time is not cumulative—only the longest setting will apply. If the voltage recovers during the brownout time period, the compressor will start.

If a brownout condition is detected by the 8201-164, the troubleshooting light will flash blue. The light will continue to flash until the cooling call is satisfied or power is removed from the Y terminal. This condition does not prevent operation, it only indicates that a brownout condition was present at some point during the cooling call. If a brownout condition is detected, CC will be de-energized and will retry after the delay-on-make timer is satisfied; this process will continue until call is satisfied.

If user chooses the 'do not ignore' position when the site has inadequate utility or generator power, this could lead to the compressor never starting. The control will see the brownout immediately and not start.

A common scenario and one that has been seen in the field is when a unit or units switches from utility power to generator power. With slower transfer switches, the time delay between the utility power and generator power didn't cause a problem. The units lost power, shut off and came back on line normally. With the introduction of almost instantaneous transfer switches,

the millisecond long power glitch can be enough that the compressor will start to run backwards. In this scenario, the CCM will catch this and restart the units normally.

High Pressure Safety Switch

All units have a high pressure switch as a safety device. This device will open when pressure in the system reaches 650 PSIG. The sensor is directly connected to the dedicated compressor control module (see **High Pressure Detection** on page 22).

Refrigerant High Pressure Alarm

When the wall-mount unit receives a signal from the compressor control module (CCM) indicating a high pressure event, the wall-mount unit will generate an alarm. Upon receiving the alarm, the wall-mount unit will remove the "Y" call from the CCM, resetting the status of the CCM. The alarm will stay present on the wall-mount unit until manually cleared with TEC-EYE hand-held diagnostic tool.

In addition to the CCM, the discharge pressure transducer is used to prevent a high pressure event. When the discharge pressure is above the discharge pressure alarm setpoint (set 30 pounds below high pressure switch, which is 650), the system will disable stage 2 of mechanical cooling.

Phase Monitor

Used only on three phase equipment, the phase monitor is a compressor protection device that will prohibit operation of the compressor if the device senses a possible reverse-rotation situation due to incorrect phasing. On a call for compressor (and only compressor), the device will check incoming phase, check for severe voltage imbalance and check for proper frequency. Under nominal conditions, a green LED light will show on the face of the monitor. If there is improper phasing, voltage imbalance or frequency deviation, the device will show a red LED light and prohibit compressor operation.

If a fault condition occurs, reverse two of the supply leads to the unit. **Do not reverse any of the unit factory wires as damage may occur.**

Compressor Operation

The compressor will be enabled when the unit (in orphan mode) or LC provide a cooling stage 1 call. The compressor call from the controller has several delays that may affect the start or stop time of the compressor in regards to the cooling demand. The compressor has a minimum on time of 180 seconds to prevent short cycling the compressor. The compressor also has a minimum off time of 120 seconds to prevent start ups before the pressure in the refrigeration system equalizes. When the second stage is engaged, it also has a minimum run time of 120 seconds to allow the system to stabilize before returning to single stage or shutting down.

These delays can be changed by:

1. Press MENU key to go to the Main Menu screen.
2. Press UP or DOWN keys and ENTER key to enter TECHNICIAN password 1313.
3. Press UP or DOWN keys to scroll to **Adv System Config**; press ENTER key.
4. Press UP or DOWN keys to scroll to **Comp. Safety B2**; press ENTER key.
5. Press ENTER key to scroll to **Min On Time** or **Min Off Time** (see Figure 32).
6. Press UP or DOWN keys to change the value.
7. Press ENTER key to save value and move the cursor to next parameter or top of screen.
8. Press ESCAPE key several times to return to Main Menu screen.

The address-based delay only applies to the wall-mount unit when in orphan mode. The controller will delay the unit compressor based on the value entered on screen B2 multiplied by the unit address. This is intended to keep multiple units from starting their compressors at the same time when there is a quick change in the load. When connected to the LC, this is taken care of by LC logic.

FIGURE 32
Adjusting Compressor Delays



Additional Compressor Alarms

Refrigerant Low Pressure Alarm

When the suction pressure transducer indicates a pressure value less than the low pressure alarm setpoint of 40 PSIG and there is an active call for cooling, the controller will disable the compressor (after a 120-second delay). **NOTE:** The second call will be delayed based on the delay off value mentioned in the compressor section. The controller will try to run the refrigeration system two (2) times within 900 seconds before the alarm will lock the compressor out. This alarm needs to be manually cleared before compressor operation will resume.

Economizer

Economizer Components

Actuator


The actuator rotates up to 90° based on a 2-10v signal sent to it by the controller. This component is what opens and closes the damper blade. The unit is equipped with three dampers powered by three separate actuators. The left intake damper (damper 1) and the right intake damper (damper 3) are each powered by a 44 in-lb actuator. The exhaust damper (damper 2) is powered by a 90 in-lb actuator. All dampers are spring return and will close the damper if power is lost.

To verify the output from the controller to the actuator:

1. Press MENU key to go to the Main Menu screen.
2. Press UP or DOWN keys and ENTER key to enter TECHNICIAN password 1313.
3. Press UP or DOWN keys to scroll to **Analog Outputs**; press ENTER key.
4. Press UP or DOWN keys to scroll to **Damper System 1/5**.
5. To override the current position, press ENTER key to scroll to **System OV Pos** (see Figure 33).
6. Press UP or DOWN keys to change the value to the desired output.
7. Press ENTER key to save the value and move cursor to **Enable Sys. OV**.
8. Press UP or DOWN keys to change the value from **No** to **Yes**.
9. The damper position will update with the new override value and the damper will travel to that position.

NOTE: This override will last for 5 minutes or until the **Enable Sys. OV** is changed back to **No**.

FIGURE 33
Damper Override



Dust Sensor


The unit has a dust sensor installed near the outdoor air inlet. The dust sensor checks for excessive particulates in the outdoor air, and will close the economizer if the dust is excessive. The sensor uses a PWM signal converted to 0-5v output to the controller.

To ensure proper performance, cleaning may be required. Vacuuming or blowing the dust off the sensor with forced air is recommended. **Avoid inserting any objects into the sensor.**

The dust sensor can be verified by:

1. Press MENU key to go to the Main Menu screen.
 2. Press UP or DOWN keys and ENTER key to enter TECHNICIAN password 1313.
 3. Press UP or DOWN keys to scroll to **I/O Config**; press ENTER key.
 4. Press UP or DOWN keys to scroll to **Analog Inputs**; press ENTER key.
 5. Press UP or DOWN keys to scroll to **Analog Ins 15/19**.
 6. Reference the **Value** for the current sensor reading (see Figure 34).
 7. To apply an offset to the current reading, press ENTER key to scroll to **Offset**.
 8. Press UP or DOWN keys to adjust the value to the desired value.
 9. Press ENTER key to save the value and move cursor to next parameter.
- NOTE:** The sensor can be disabled if required for troubleshooting.
10. With the cursor on the **Enable** parameter, press UP or DOWN keys to change the value from **On** to **Off**.
 11. Press ENTER key to save.

FIGURE 34
Dust Sensor



Dust Sensor Failure Alarm

When the sensor reads a value that is outside of the acceptable 0 to 100% range, an alarm will be generated indicating the sensor has failed. This alarm is just a notification and will not disable any other features on the controller.

This alarm is fixed and cannot be adjusted.

High Dust Limit Alarm


When dust content in the air is high and is a risk to prematurely reducing airflow through the filters, the unit will restrict the use of the economizer. The controller has adjustable software setpoints to indicate dust levels are too high and to disable the economizer operation for 5 minutes. Once the conditions are no longer present, the alarm will automatically clear.

To adjust the dust sensor alarm setpoint:

1. Press MENU key to go to the Main Menu screen.
2. Press UP or DOWN keys and ENTER key to enter USER password 2000.
3. Press UP or DOWN keys to scroll to **System Config**; press ENTER key.
4. Press UP or DOWN keys to scroll to **Dust Configuration A4**.
5. Press ENTER key to scroll to **Alarm Set** (see Figure 35).
6. Press UP or DOWN keys to change to the desired value.
7. Press ENTER key to save the value.

NOTE: When the temperature outside is measured at or below 0°F, the dust sensor alarm will be disabled to allow economizer operation.

FIGURE 35
Adjusting Dust Sensor Alarm Setpoint




Damper Blade

The system utilizes three damper blades to bring in outdoor air and exhaust space air for economizer operation. Damper 1 is left intake, damper 2 is exhaust and damper 3 is right intake. Damper blades are made of sheet metal and are integrated into the equipment.

To view damper blade position:

1. Press MENU key to go to the Main Menu screen.
2. Press UP or DOWN keys and ENTER key to enter TECHNICIAN password 1313.
3. Press UP or DOWN keys to scroll to **I/O Config**; press ENTER key.
4. Press UP or DOWN keys to scroll to **Analog Outputs**; press ENTER key.
5. Press UP or DOWN keys to scroll to **Damper Intake Lt 2/5** (see Figure 36), **Damper Intake Rt 3/5** or **Damper Exhaust 1**.

FIGURE 36
Damper Blade Position




Damper Switch

The economizer utilizes three magnetic switches (one on each damper blade) to determine if the damper is operating correctly. This switch will be closed when the damper is closed and open when the damper is open.

To verify the status of the switch:

1. Press MENU key to go to the Main Menu screen.
2. Press UP or DOWN keys and ENTER key to enter TECHNICIAN password 1313.
3. Press UP or DOWN keys to scroll to **I/O Config**; press ENTER key.
4. Press UP or DOWN keys to scroll to **Digital Inputs**; press ENTER key.
5. Press UP or DOWN keys to scroll to **Digital Ins 2/2**.
6. Reference the values for **Damper 1**, **Damper 2**, **Damper 3** and **Damper 4** (see Figure 37).
7. The input will display **ON** when the damper is closed (reflecting closed circuit on damper switch) and will display **OFF** when the damper is open (reflecting open circuit on damper switch).

FIGURE 37
Damper Switch

A screenshot of a control panel display showing a table of digital inputs. The title is "Digital Ins 2/2". The table has four columns: Channel, En, Dir, and Val. The rows are: Filter 2 (Yes, N/O, Off), Panel Sw (Yes, N/O, Off), Damper 1 (Yes, N/O, On), Damper 2 (Yes, N/O, On), Damper 3 (Yes, N/O, On), and Damper 4 (Yes, N/O, On).

| Channel | En | Dir | Val |
|----------|-----|-----|-----|
| Filter 2 | Yes | N/O | Off |
| Panel Sw | Yes | N/O | Off |
| Damper 1 | Yes | N/O | On |
| Damper 2 | Yes | N/O | On |
| Damper 3 | Yes | N/O | On |
| Damper 4 | Yes | N/O | On |

Damper Failed to Open Alarm

When the controller commands the economizer damper actuator to a position other than 0% and the damper switch indicates the damper is not open, after a delay of 20 seconds the controller will generate a damper failed to open alarm. This alarm is just a notification and will not disable any features on the controller.

The alarm must be cleared by a user reset.

Damper Failed to Close Alarm

When the controller commands the economizer damper actuator to the 0% position and the damper switch indicates the damper is not closed, after a delay of 300 seconds the controller will generate a damper failed to close alarm. This alarm is just a notification and will not disable any features on the controller.

The alarm must be cleared by a user reset.

Outdoor Temperature and Humidity Combination Sensor


The unit is equipped with a combination outdoor temperature and humidity sensor to monitor outdoor conditions for the economizer operation. The temperature is measured with a 10k ohm NTC thermistor. The humidity is measured with a humidity sensor that outputs a 4-20mA signal to the controller.

The outdoor temperature can be verified by:

1. Press MENU key to go to the Main Menu screen.
2. Press UP or DOWN keys and ENTER key to enter TECHNICIAN password 1313.
3. Press UP or DOWN keys to scroll to **I/O Config**; press ENTER key.
4. Press UP or DOWN keys to scroll to **Analog Inputs**; press ENTER key.
5. Press UP or DOWN keys to scroll to **Analog Ins 4/19**.
6. Reference the **Value** to see the input of the sensor (see Figure 38).
7. To apply an offset, press ENTER key to scroll to **Offset**.
8. Press UP or DOWN keys to change to the desired value.

- Press ENTER key to save the value.


FIGURE 38
Outdoor Temperature Sensor



The outdoor humidity can be verified by:

- Press MENU key to go to the Main Menu screen.
- Press UP or DOWN keys and ENTER key to enter TECHNICIAN password 1313.
- Press UP or DOWN keys to scroll to **I/O Config**; press ENTER key.
- Press UP or DOWN keys to scroll to **Analog Inputs**; press ENTER key.
- Press UP or DOWN keys to scroll to **Analog Ins 5/19**.
- Reference the **Value** to see the input of the sensor (see Figure 39).
- To apply an offset, press ENTER key to scroll to **Offset**.
- Press UP or DOWN keys to change to the desired value.
- Press ENTER key to save the value.

FIGURE 39
Outdoor Humidity Sensor



Outdoor Temperature Sensor Failure Alarm

When the sensor reads a value that is outside of the acceptable -41 to 303.0° range, an alarm will be generated indicating the sensor has failed. This alarm condition will disable the economizer.

This alarm is fixed and cannot be adjusted.

Outdoor Humidity Sensor Failure Alarm

When the sensor reads a value that is outside of the acceptable 0 to 100% RH range, an alarm will be generated indicating the sensor has failed. This alarm condition will disable the economizer when the mode is set to temperature and humidity or enthalpy.

This alarm is fixed and cannot be adjusted.


Mixed Air Temperature Sensor

The unit is equipped with a mixed air temperature sensor to monitor the mixed air temperature. The mixed air is measured where the economizer mixes return air and outdoor air. This measurement is used to determine if the economizer is controlling correctly. The sensor is a 10k ohm NTC Thermistor.

The mixed air temperature can be verified by:

- Press MENU key to go to the Main Menu screen.
- Press UP or DOWN keys and ENTER key to enter TECHNICIAN password 1313.
- Press UP or DOWN keys to scroll to **I/O Config**; press ENTER key.
- Press UP or DOWN keys to scroll to **Analog Inputs**; press ENTER key.
- Press UP or DOWN keys to scroll to **Analog Ins 18/19**.
- Reference the **Value** to see the input of the sensor (see Figure 40).
- To apply an offset, press ENTER key to scroll to **Offset**.
- Press UP or DOWN keys to change to the desired value.
- Press ENTER key to save the value.

FIGURE 40
Mixed Air Temperature Sensor



High Mixed Air Temperature Alarm

To keep the economizer from bringing in air that is too warm, an alarm will be generated when the mixed air is 2° above the return air temperature for 300 seconds. This alarm will not be generated if the mixed air temperature sensor has failed. The alarm can only be

activated during a free cooling call. The alarm is a user reset and must be cleared by the end user.

Low Mixed Air Temperature Alarm

To keep the economizer from bringing in air that is too cold, an alarm will be generated when the mixed air temperature is 5°F below the mixed air temperature control setpoint for 300 seconds. If this alarm is active, the economizer will be disabled for the current cooling call. This alarm will reference the mixed air temperature control setpoint to ensure that when the mixed air setpoint changes, the alarm dynamically changes with it. This alarm will not be generated if the mixed air temperature sensor has failed. The alarm can only be activated during a free cooling call and requires a user reset.

Economizer Operation

See Figure 57 on page 48 for ventilation airflow paths.

The economizer has four types of operation. The first mode is "None" where the economizer is never utilized, except for emergency purposes. The second mode is "Dry Bulb" where the outdoor temperature is the only consideration for economizer use on a free cooling call. The third mode is "TempHum" where the outdoor temperature and humidity are considered for economizer use on a free cooling call. The fourth mode is "Enthalpy" where the outdoor temperature, humidity and calculated dew point are considered for economizer operation on a free cooling call.

To change the economizer type:

1. Press MENU key to go to the Main Menu screen.
2. Press UP or DOWN keys and ENTER key to enter USER password 2000.
3. Press UP or DOWN keys to scroll to **System Config**; press ENTER key.
4. Press UP or DOWN keys to scroll to **Economizer Setup A2**; press ENTER key.
5. Press ENTER key to scroll to **Type** (see Figure 41).
6. Press UP or DOWN keys to change the **Type** desired value to **None**, **Dry Bulb**, **TempHum** or **Enthalpy**.
7. Press ENTER key to save the value and scroll to the next parameter.

FIGURE 41
Economizer Setup



NOTE: The following parameters are for the temperature consideration for economizer use. Applies to **Dry Bulb**, **TempHum** and **Enthalpy** type.

8. The cursor should now be on the **Mixed Air Tamp** parameter.
9. Press UP or DOWN keys to change the parameter to the desired value.
10. Press ENTER key to save the value and scroll to the next parameter.
11. The cursor should now be on **Delay** parameter.
12. Press UP or DOWN keys to change the parameter to the desired value.
13. Press ENTER key to save the value and move to the next parameter.
14. The cursor is now on the **Min Position** parameter.
15. Press UP or DOWN keys to change the parameter to the desired value (see **Economizer Operation – Minimum Position** on page 29 for more information).
16. Press ENTER key to save the value.
17. Press the DOWN key to navigate to the **A3** screen.

NOTE: The **A3** screen will not display if economizer mode is set to **None**. Also, the contents of the screen will change depending on which type is chosen: **Dry Bulb** (Figure 42), **TempHum** (Figure 43) or **Enthalpy** (Figure 44). The following menu shows the **Enthalpy** content which also contains parameters that would be shown on **Dry Bulb** (temperature only) and **TempHum** (temperature and humidity only).

18. Press ENTER key to scroll to **OA Temp Set** (on **Drybulb Control** and **Temp/Hum Control A3** screens, this parameter will be titled **Outdoor Set**).
19. Press UP or DOWN keys to change the temperature setpoint to desired value.
20. Press ENTER key to save the value and scroll to **Off Diff**.
21. Press UP or DOWN keys to adjust the outdoor temperature differential for which the economizer is re-enabled.
22. Press ENTER key to save the value and scroll to **OA Hum Set**.
23. Press UP or DOWN keys to adjust the humidity setpoint to desired value.
24. Press ENTER key to save the value and scroll to **On Diff**.
25. Press UP or DOWN keys to adjust the outdoor humidity differential for which the economizer is re-enabled.
26. Press ENTER key to save the value and scroll to **Dew Pt. Set**.

FIGURE 42
Economizer Setup – Dry Bulb Control




FIGURE 43
Economizer Setup – Temp/Hum Control





FIGURE 44
Economizer Setup – Enthalpy Control



27. Press UP or DOWN keys to adjust the outdoor dew point setpoint for economizer operation to the desired value.
28. Press ENTER key to save the value and scroll to **On Diff**.
29. Press UP or DOWN keys to adjust the dew point differential for which the economizer is re-enabled.
30. Press ENTER key to save the value.
31. Press ESCAPE key several times to return to Main Menu screen.

See Table 6 for default settings for economizer operation.

When the economizer is activated during a free cooling call only, using any of the previously mentioned modes, a 0-10v analog signal will be sent to the economizer actuator. The actuator will then open and close the damper blades to maintain a mixed air temperature of 55°F. When the mixed air temperature increases, the damper will open and when the mixed air temperature decreases, the damper will close.

The economizer may be disabled by the LC if the system determines it needs to enter dehumidification mode. More information about the dehumidification sequence can be found in the latest revision of LC6000 Service Instructions 2100-669. In addition to dehum mode, the economizer may be disabled for 5 minutes (adjustable) if the dust sensor indicates the outdoor air may cause particulate buildup in the air filters. After the time has expired and on a call for cooling, the economizer will open again to sample the air. The wall-mount unit will either return to normal operation or remain locked out for another 5 minutes.

Economizer Operation – Minimum Position

The economizer has an option to set minimum position for the economizer. The minimum position will only be active while the blower is operating. To enable minimum position all the time, continuous blower must be activated for the wall unit in the LC6000. See latest version of LC6000 Service Instructions 2100-669 for continuous blower configuration.

TABLE 6
Economizer Default Settings

| Mode | | Consideration | Economizer Available for Cooling | Economizer Not Available for Cooling | |
|-----------|-----------------|---------------|----------------------------------|--|--|
| Temp Only | Temp & Humidity | Enthalpy* | Temperature | When the outdoor air temperature is below 70°F | When the outdoor air temperature is above 75°F |
| | | | Humidity | When the outdoor humidity is below 80% | When the outdoor humidity is above 80% |
| | | | Dew Point | When the outdoor dew point is below 55°F | When the outdoor dew point is above 60°F |

* In Enthalpy mode, outdoor temperature, humidity and calculated dew point are all considered for economizer operation.

To set the minimum position value:

1. Press MENU key to go to the Main Menu screen.
2. Press UP or DOWN keys and ENTER key to enter USER password 2000.
3. Press UP or DOWN keys to scroll to **System Config**; press ENTER key.
4. Press UP or DOWN keys to scroll to **Economizer Setup A2**.
5. Press ENTER key to scroll to **Min Position** (see Figure 41 on page 28).
6. Press UP or DOWN keys to change to the desired value.

Miscellaneous Components


Supply Temperature Sensor

The unit is equipped with a supply air temperature sensor to monitor the leaving air temperature of the unit. The temperature is measured with a 10k ohm NTC thermistor.

The supply air temperature can be verified by:

1. Press MENU key to go to the Main Menu screen.
2. Press UP or DOWN keys and ENTER key to enter TECHNICIAN password 1313.
3. Press UP or DOWN keys to scroll to **I/O Config**; press ENTER key.
4. Press UP or DOWN keys to scroll to **Analog Inputs**; press ENTER key.
5. Press UP or DOWN keys to scroll to **Analog Ins 2/19**.
6. Reference the **Value** to see the input of the sensor (see Figure 45).
7. To apply an offset, press ENTER key to scroll to **Offset**.
8. Press UP or DOWN keys to change to the desired value.
9. Press ENTER key to save the value.

FIGURE 45
Supply Air Temperature Sensor



Supply Temperature Sensor Failure Alarm

When the sensor reads a value that is outside of the acceptable -41.0 to 303.0° range, an alarm will be generated indicating the sensor has failed.

This alarm is fixed and cannot be adjusted.

Emergency Cooling Mode

If the shelter temperature is above the high temperature alarm setpoint on the LC, the unit will be commanded into emergency cooling mode. In this mode, the unit will operate the economizer regardless of the economizer setup, as long as the outdoor temperature is below the indoor temperature. This will stay active until the LC returns the unit to normal operation.


Emergency Cooling – Orphan Mode

When the unit is not connected to the LC6000 and operating in orphan mode, the unit still has the capability to operate in emergency cooling mode. By default this feature is not enabled.

To enable emergency cooling in orphan mode:

1. Press MENU key to go to the Main Menu screen.
2. Press UP or DOWN keys and ENTER key to enter TECHNICIAN password 1313.
3. Press UP or DOWN keys to scroll to **Adv System Config**; press ENTER key.
4. Press UP or DOWN keys to scroll to **Emer. Cool B5**.
5. Press ENTER key to scroll to **Use emergency cool in Orphan Mode?** (see Figure 46).
6. Press UP or DOWN keys to change the value.

FIGURE 46
Emergency Cool – Orphan Mode




When this feature is used instead of using the zone sensor, an alarm will be triggered by the high return air temperature alarm.

To adjust the return air temperature settings:

1. Press MENU key to go to the Main Menu screen.
2. Press UP or DOWN keys and ENTER key to enter USER password 2000.

3. Press UP or DOWN keys to scroll to **System Config**; press ENTER key.
4. Press UP or DOWN keys to scroll to **Return Air Alarm A5**.
5. Press ENTER key to scroll to **Enable, Lower Limit** or **Upper Limit** (see Figure 47).
6. Press UP or DOWN keys to disable the alarm or change the limit values.

FIGURE 47
Adjusting Return Air Alarm Settings



Emergency Ventilation Mode

If the emergency ventilation input at the LC is active, the system will go into emergency ventilation mode. In emergency ventilation mode, the economizers on the wall units will be commanded to 100%. This mode is only available when connected to the LC.

NOTE: All units will receive the emergency ventilation command. Wall units not equipped with economizers will still engage the blower.

Electric Heat Option

Electric Heat Components

Electric Heating Element

The unit can be optionally equipped with 9kw or 18kw of heat. The 9kw is a single stage heating element. The 18kw option comes equipped with two 9kw heating elements that operate in two stage. The heating elements are located downstream of the evaporator coils and can be accessed through the upper control panel door.

Thermal Overload

The heater assembly has a thermal overload wired in series with the heating element. This device has a cycling limit which opens at 130°F and resets at 80°F. The limit is also equipped with a redundant thermal fuse that will open at 150°F.

Electric Heat Operation

The heat strip will be activated on a call for heat. This call can be generated by the LC or the wall-mount unit operating in orphan mode.

Electric Reheat Dehumidification

The MEGA-TEC wall-mount unit can be ordered with optional electric reheat dehumidification. This feature is indicated by the letter "E" in the 6th character of the model number. Electric reheat dehumidification is only available as a factory-installed option that must be ordered with the unit. It cannot be installed in the field on an existing unit.


To verify the dehumidification capability of a unit and/or disable the dehumidification operation:

1. Press MENU key to go to the Main Menu screen.
2. Press UP or DOWN keys and ENTER key to enter USER password 2000.
3. Press UP or DOWN keys to scroll to **System Config**; press ENTER key.
4. Press UP or DOWN keys to scroll to **Dehum Config A9** (see Figure 48).

NOTE: Capability on this menu will show the unit's dehumidification capability based on the model number entered into the wall-mount unit's controller. This parameter will show either **Not Available** or **Electric Reheat**.

5. Press ENTER key to scroll to **Enable**.
6. Press UP or DOWN keys to change the value from **Yes** to **No**.

FIGURE 48
Electric Reheat Dehumidification



An electric reheat capable unit will allow for concurrent operation of compressor and electric heat. This allows the compressor to operate which will remove moisture from the indoor air while the electric heat keeps the space temperature from dropping during this operation. The cooling capacity of the MEGA TEC is much greater than its capacity to heat with either the 9kw or 18kw option. In order to extend the compressor run times and prevent the unit from overcooling the space, the cooling capacity will be limited during dehumidification operation (see Table 7 on page 32).

TABLE 7
Cooling Capacity Limitation

| Heat Option | Limitation | Heat Capacity* | Cooling Capacity* |
|-------------|---------------------------|----------------|-------------------|
| 9 Kw | Compressor 1 Part Load | 30,709 | 39,600 |
| 18 Kw | Compressor 1 Full Load | 61,418 | 60,000 |

Electric Reheat Dehumidification Operation


The unit will utilize electric reheat dehumidification when it receives an active dehumidification call from the LC6000 supervisory controller. During the active dehumidification call, the unit status message will show “Active Dehum”. An LC6000 equipped with and indoor humidity sensor is required to utilize dehumidification.

When the command is received from the LC6000, the wall unit will engage the compressor to begin removing moisture from the space and turn on the electric heat to extend the run time of the cooling cycle while mitigating the cooling done by the compressor. If/when the return temperature falls to 2° above heating setpoint, the compressor will be disabled until the temperature is increased to 2° below the cooling setpoint and then compressor will be re-energized (see Figure 50). If/when the temperature reaches 4° below the cooling setpoint, the electric heating elements will be energized. The electric heating elements will be disabled 2° below the cooling setpoint. The system will continue the dehumidification process until either the heating or cooling setpoint are reached again or the active dehumidification command from the LC6000 has been removed.

A heating or cooling call will disable the dehumidification call. Dehumidification can only take place when the system is not actively heating or cooling.

For more information on dehumidification staging, see latest version of LC6000 Service Instructions manual 2100-669.

FIGURE 50
Dehumidification Control (°F)




Unit Disable Option

The unit is equipped with an input that can be used to turn off the unit.

The unit disable input can be verified and adjusted by:

1. Press MENU key to go to the Main Menu screen.
2. Press UP or DOWN keys and ENTER key to enter TECHNICIAN password 1313.
3. Press UP or DOWN keys to scroll to **I/O Config**; press ENTER key.
4. Press UP or DOWN keys to scroll to **Digital Inputs**; press ENTER key.
5. Press UP or DOWN keys to scroll to **Digital Ins 1/2**.
6. Reference **Disable** row and **En** column (see Figure 49).
7. Press ENTER key to scroll to **Disable En** value.
8. Press UP or DOWN key to change value.
9. Press ENTER key to scroll to **Dir**.
10. Press UP or DOWN key to change direction (**N/O** or **N/C**), if applicable.
11. Press ESCAPE key several times to return to Main Menu screen.

FIGURE 49
Unit Disable Option



Serial/Model Number Configuration

MEGA-TEC wall-mount units configure some settings based on the model number that is input into the unit. The model and serial number are entered at the factory, and should be retained during a software update. However, after a software update, it is best practice to verify that the model and serial number is still present and accurate. If the model and/or serial number is missing or incorrect they will need to be re-entered.

To update serial/model numbers:

1. Press MENU key to go to the Main Menu screen.
2. Press UP or DOWN keys and ENTER key to enter ENGINEER password 9254.
3. Press UP or DOWN keys to scroll to **Adv. Sys. Config**; press ENTER key.
4. Press UP or DOWN keys to scroll to **Unit Setup B1** (see Figure 51).
5. Press ENTER key to advance the cursor to the digit that needs changed in the serial/model number.
6. Press UP or DOWN keys to change value of the digit.
7. Continue Steps 5 and 6 until the serial/model number(s) are correct and reflect the number on the product label.

For more information on the options and settings available for specific model numbers, see the model number breakdown in Figure 52 on page 34.

FIGURE 51
Serial/Model Number Configuration





FIGURE 52
MEGA-TEC Wall-Mount Unit Model Nomenclature



NOTICE

These units require R-410A refrigerant and polyol ester oil.

General

1. Use separate service equipment to avoid cross contamination of oil and refrigerants.
2. Use recovery equipment rated for R-410A refrigerant.
3. Use manifold gauges rated for R-410A (800 PSI/250 PSI low).
4. R-410A is a binary blend of HFC-32 and HFC-125.
5. R-410A is nearly azeotropic—similar to R-22 and R-12. Although nearly azeotropic, charge with liquid refrigerant.
6. R-410A operates at 40-70% higher pressure than R-22, and systems designed for R-22 cannot withstand this higher pressure.
7. R-410A has an ozone depletion potential of zero, but must be reclaimed due to its global warming potential.
8. R-410A compressors use polyol ester oil.
9. Polyol ester oil is hygroscopic; it will rapidly absorb moisture and strongly hold this moisture in the oil.
10. A liquid line dryer must be used—even a deep vacuum will not separate moisture from the oil.
11. Limit atmospheric exposure to 15 minutes.
12. If compressor removal is necessary, always plug compressor immediately after removal. Purge with small amount of nitrogen when inserting plugs.

Topping Off System Charge

If a leak has occurred in the system, Bard Manufacturing recommends reclaiming, evacuating (see criteria above) and charging to the nameplate charge. If done correctly, topping off the system charge can be done without problems.

With R-410A, there are no significant changes in the refrigerant composition during multiple leaks and recharges. R-410A refrigerant is close to being an azeotropic blend (it behaves like a pure compound or single component refrigerant). The remaining refrigerant charge in the system may be used after leaks have occurred. “Top-off” the charge by utilizing the pressure charts on the inner control panel cover as a guideline.

REMEMBER: When adding R-410A refrigerant, it must come out of the charging cylinder/tank as a liquid to avoid any fractionation and to insure optimal system performance. Refer to instructions for the cylinder that is being utilized for proper method of liquid extraction.

Safety Practices

1. Never mix R-410A with other refrigerants.
2. Use gloves and safety glasses. Polyol ester oils can be irritating to the skin, and liquid refrigerant will freeze the skin.
3. Never use air and R-410A to leak check; the mixture may become flammable.
4. Do not inhale R-410A—the vapor attacks the nervous system, creating dizziness, loss of coordination and slurred speech. Cardiac irregularities, unconsciousness and ultimately death can result from breathing this concentration.
5. Do not burn R-410A. This decomposition produces hazardous vapors. Evacuate the area if exposed.
6. Use only cylinders rated DOT4BA/4BW 400.
7. Never fill cylinders over 80% of total capacity.
8. Store cylinders in a cool area, out of direct sunlight.
9. Never heat cylinders above 125°F.
10. Never trap liquid R-410A in manifold sets, gauge lines or cylinders. R-410A expands significantly at warmer temperatures. Once a cylinder or line is full of liquid, any further rise in temperature will cause it to burst.

Important Installer Note

For improved start-up performance, wash the indoor coil with a dishwashing detergent.

R410-A Refrigerant Charge

This wall-mount unit was charged at the factory with the quantity of refrigerant listed on the serial plate. AHRI capacity and efficiency ratings were determined by testing with this refrigerant charge quantity.

Table 8 on page 36 shows nominal pressures for the units. The use of pressure gauges should not be necessary as the measurements are available through the TEC-EYE hand-held diagnostic tool. Since many installation specific situations can affect the pressure readings, this information should only be used by certified technicians as a guide for evaluating proper system performance. They shall not be used to adjust charge. If charge is in doubt, reclaim, evacuate and recharge the wall-mount unit to the serial plate charge.

Pressure Service Ports

High and low pressure service ports are installed on all wall-mount units so that the system operating pressures can be observed. Pressures are shown in Table 8.

This unit employs high-flow Coremax valves instead of the typical Schrader type valves.

WARNING! Do NOT use a Schrader valve core removal tool with these valves. Use of such a tool could result in eye injuries or refrigerant burns!

To change a Coremax valve without first removing the refrigerant, a special tool is required which can be obtained at www.fastestinc.com/en/SCCA07H. See the replacement parts manual for replacement core part numbers.

TABLE 8
Cooling Pressures

| Cooling Air Temperature Entering Outdoor Coil °F | | | | | | | | | | | | | |
|--|-----------------|-----------|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|
| Model | Return Air Temp | Pressure | 75 | 80 | 85 | 90 | 95 | 100 | 105 | 110 | 115 | 120 | 125 |
| W120A* Stage 3¹ | 75° DB | Low Side | 125 | 126 | 127 | 128 | 129 | 130 | 132 | 133 | 135 | 137 | 137 |
| | 62° WB | High Side | 312 | 334 | 357 | 379 | 403 | 427 | 451 | 476 | 501 | 527 | 553 |
| | 80° DB | Low Side | 134 | 135 | 136 | 137 | 138 | 139 | 141 | 142 | 144 | 146 | 147 |
| | 67° WB | High Side | 320 | 343 | 366 | 389 | 413 | 438 | 463 | 488 | 514 | 540 | 567 |
| | 85° DB | Low Side | 139 | 140 | 141 | 142 | 143 | 144 | 146 | 147 | 149 | 151 | 152 |
| | 72° WB | High Side | 331 | 355 | 379 | 403 | 427 | 453 | 479 | 505 | 532 | 559 | 587 |
| W120A* Stage 2² | 75° DB | Low Side | 136 | 137 | 137 | 138 | 140 | 141 | 142 | 144 | 145 | 147 | 148 |
| | 62° WB | High Side | 289 | 308 | 330 | 352 | 374 | 398 | 423 | 448 | 474 | 501 | 528 |
| | 80° DB | Low Side | 145 | 146 | 147 | 148 | 150 | 151 | 152 | 154 | 155 | 157 | 158 |
| | 67° WB | High Side | 296 | 316 | 338 | 361 | 384 | 408 | 434 | 459 | 486 | 514 | 542 |
| | 85° DB | Low Side | 150 | 151 | 152 | 153 | 155 | 156 | 157 | 159 | 160 | 162 | 164 |
| | 72° WB | High Side | 306 | 327 | 350 | 374 | 397 | 422 | 449 | 475 | 503 | 532 | 561 |
| W120A* Stage 1³ | 75° DB | Low Side | 125 | 127 | 128 | 130 | 131 | 133 | 135 | 136 | 137 | 139 | 141 |
| | 62° WB | High Side | 311 | 332 | 355 | 377 | 402 | 427 | 452 | 479 | 506 | 534 | 563 |
| | 80° DB | Low Side | 134 | 136 | 137 | 139 | 140 | 142 | 144 | 145 | 147 | 149 | 151 |
| | 67° WB | High Side | 319 | 341 | 364 | 387 | 412 | 438 | 464 | 491 | 519 | 548 | 577 |
| | 85° DB | Low Side | 139 | 141 | 142 | 144 | 145 | 147 | 149 | 150 | 152 | 154 | 156 |
| | 72° WB | High Side | 330 | 353 | 377 | 401 | 426 | 453 | 480 | 508 | 537 | 567 | 597 |

Low side pressure ± 4 PSIG
High side pressure ± 10 PSIG

- ¹ Stage 3 is circuit 1 *fully loaded* and circuit 2 *on*.
- ² Stage 2 is circuit 1 *unloaded* and circuit 2 *on*.
- ³ Stage 1 is circuit 1 *unloaded* and circuit 2 *off*.

Tables are based upon **rated CFM** (airflow) across the evaporator coil. If there is any doubt as to correct operating charge being in the system, the charge should be removed and system evacuated and recharged to serial plate charge weight.

NOTE: Pressure table based on high speed condenser fan operation. If condensing pressures appear elevated check condenser fan wiring. See "Condenser Fan Operation" on page 20.

Standard Maintenance Procedures

WARNING

Electrical shock hazard.

Disconnect all power supplies before servicing.

Failure to do so could result in electric shock or death.

CAUTION

Cut hazard.

Wear gloves to avoid contact with sharp edges.

Failure to do so could result in personal injury.

1. Disable system from LC6000 controller (see latest revision of LC6000 Service Instructions 2100-669).
2. Turn off AC breakers at wall-mount units.
3. Check inlet sides of condenser and evaporator coils for obstructions/debris—clean if necessary using a quality manufactured coil cleaning product specific for the evaporator or condenser coil.
 - Condenser coil: For inlet-side cleaning, remove condenser grilles. For outlet-side cleaning, remove condenser fan panel. Unbolt fan from mounting brackets and slide fan outward until lower locking arm drops into position. Pivot fan by lifting fan locking arm. Follow the coil cleaner manufacturer's directions for necessary safety gear and precautions, as well as for application and use. More than one application may be necessary. Rinse thoroughly.
 - Evaporator coil: Open filter access panels and remove filters. Apply specific evaporator cleaner directly to the inlet side of coil, being very careful not to overspray into insulation or surrounding panels and wiring. For outlet-side cleaning, remove supply grille and clean from that direction. Residual cleaner and dissolved debris should drip into the drain pan and leave the unit through the condensate hose. More than one application may be necessary. Rinse thoroughly.
4. Manually spin fan and blower motors to ensure they turn freely. All motors are permanently lubricated, so no oil is necessary.
5. Inspect free cooling damper actuator and linkage.
6. Install new air filters.
7. Inspect the control panel of the system.
 - Look for insect or rodent activity and remove any nesting materials.
 - Manually push contactor closed, observe for movement—contactor points should have minimal discoloration, no spalling or other signs of arcing. Replace if doubtful.
 - Check field and factory wiring for tightness and look for signs of overheating (discoloration of terminals or wire insulation).
8. Ensure that supply and return registers are not obstructed, and more importantly, are not recycling the air to one another. Adjust supply louvers if necessary to direct discharge air away from any direct route to the return grille.
9. Re-assemble wall-mount unit, remembering to fasten fan to mounting brackets. Turn breakers back on.
10. Enable system to LC6000 controller (see latest revision of LC6000 Service Instructions 2100-669).
11. Repeat steps for additional wall-mount units.

TROUBLESHOOTING

FIGURE 53
Sensors and Peripheral Devices





FIGURE 54
Supply and Return Air Sensors

Rear View



8301-089 Outdoor Temperature/Humidity Sensor

FIGURE 55
8301-089 Sensor DIP Switches and Terminal Block




TABLE 9
8301-089 Sensor: Temperature/Resistance

| Temperature | | Resistance | Temperature | | Resistance | Temperature | | Resistance | Temperature | | Resistance |
|-------------|-------|------------|-------------|-------|------------|-------------|------|------------|-------------|------|------------|
| F | C | Ω | F | C | Ω | F | C | Ω | F | C | Ω |
| -25 | -31.7 | 148,452.94 | 13 | -10.6 | 48,892.46 | 51 | 10.6 | 18,337.51 | 89 | 31.7 | 7679.76 |
| -24 | -31.1 | 143,910.37 | 14 | -10.0 | 47,571.97 | 52 | 11.1 | 17,898.38 | 90 | 32.2 | 7515.86 |
| -23 | -30.6 | 139,521.46 | 15 | -9.4 | 46,291.29 | 53 | 11.7 | 17,471.09 | 91 | 32.8 | 7355.94 |
| -22 | -30.0 | 135,280.55 | 16 | -8.9 | 45,049.09 | 54 | 12.2 | 17,055.30 | 92 | 33.3 | 7199.88 |
| -21 | -29.4 | 131,182.22 | 17 | -8.3 | 43,844.12 | 55 | 12.8 | 16,650.65 | 93 | 33.9 | 7047.59 |
| -20 | -28.9 | 127,221.25 | 18 | -7.8 | 42,675.14 | 56 | 13.3 | 16,256.82 | 94 | 34.4 | 6898.95 |
| -19 | -28.3 | 123,392.63 | 19 | -7.2 | 41,540.99 | 57 | 13.9 | 15,873.48 | 95 | 35.0 | 6753.88 |
| -18 | -27.8 | 119,691.54 | 20 | -6.7 | 40,440.51 | 58 | 14.4 | 15,500.34 | 96 | 35.6 | 6612.28 |
| -17 | -27.2 | 116,113.37 | 21 | -6.1 | 39,372.62 | 59 | 15.0 | 15,137.09 | 97 | 36.1 | 6474.05 |
| -16 | -26.7 | 112,653.66 | 22 | -5.6 | 38,336.26 | 60 | 15.6 | 14,783.44 | 98 | 36.7 | 6339.11 |
| -15 | -26.1 | 109,308.15 | 23 | -5.0 | 37,330.40 | 61 | 16.1 | 14,439.11 | 99 | 37.2 | 6207.37 |
| -14 | -25.6 | 106,072.72 | 24 | -4.4 | 36,354.06 | 62 | 16.7 | 14,103.83 | 100 | 37.8 | 6078.74 |
| -13 | -25.0 | 102,943.44 | 25 | -3.9 | 35,406.29 | 63 | 17.2 | 13,777.34 | 101 | 38.3 | 5953.15 |
| -12 | -24.4 | 99,916.50 | 26 | -3.3 | 34,486.17 | 64 | 17.8 | 13,459.38 | 102 | 38.9 | 5830.51 |
| -11 | -23.9 | 96,988.26 | 27 | -2.8 | 33,592.81 | 65 | 18.3 | 13,149.70 | 103 | 39.4 | 5710.75 |
| -10 | -23.3 | 94,155.21 | 28 | -2.2 | 32,725.36 | 66 | 18.9 | 12,848.07 | 104 | 40.0 | 5593.78 |
| -9 | -22.8 | 91,413.97 | 29 | -1.7 | 31,883.00 | 67 | 19.4 | 12,554.26 | 105 | 40.6 | 5479.55 |
| -8 | -22.2 | 88,761.30 | 30 | -1.1 | 31,064.92 | 68 | 20.0 | 12,268.04 | 106 | 41.1 | 5367.98 |
| -7 | -21.7 | 86,194.07 | 31 | -0.6 | 30,270.36 | 69 | 20.6 | 11,989.19 | 107 | 41.7 | 5258.99 |
| -6 | -21.1 | 83,709.29 | 32 | 0.0 | 29,498.58 | 70 | 21.1 | 11,717.51 | 108 | 42.2 | 5152.53 |
| -5 | -20.6 | 81,304.06 | 33 | 0.6 | 28,748.85 | 71 | 21.7 | 11,452.79 | 109 | 42.8 | 5048.52 |
| -4 | -20.0 | 78,975.60 | 34 | 1.1 | 28,020.48 | 72 | 22.2 | 11,194.83 | 110 | 43.3 | 4946.91 |
| -3 | -19.4 | 76,721.24 | 35 | 1.7 | 27,312.81 | 73 | 22.8 | 10,943.45 | 111 | 43.9 | 4847.63 |
| -2 | -18.9 | 74,538.41 | 36 | 2.2 | 26,625.18 | 74 | 23.3 | 10,698.45 | 112 | 44.4 | 4750.62 |
| -1 | -18.3 | 72,424.61 | 37 | 2.8 | 25,956.98 | 75 | 23.9 | 10,459.65 | 113 | 45.0 | 4655.83 |
| 0 | -17.8 | 70,377.48 | 38 | 3.3 | 25,307.60 | 76 | 24.4 | 10,226.90 | 114 | 45.6 | 4563.20 |
| 1 | -17.2 | 68,394.70 | 39 | 3.9 | 24,676.45 | 77 | 25.0 | 10,000.00 | 115 | 46.1 | 4472.67 |
| 2 | -16.7 | 66,474.07 | 40 | 4.4 | 24,062.97 | 78 | 25.6 | 9778.81 | 116 | 46.7 | 4384.19 |
| 3 | -16.1 | 64,613.46 | 41 | 5.0 | 23,466.62 | 79 | 26.1 | 9563.15 | 117 | 47.2 | 4297.71 |
| 4 | -15.6 | 62,810.82 | 42 | 5.6 | 22,886.87 | 80 | 26.7 | 9352.89 | 118 | 47.8 | 4213.18 |
| 5 | -15.0 | 61,064.17 | 43 | 6.1 | 22,323.22 | 81 | 27.2 | 9147.86 | 119 | 48.3 | 4130.55 |
| 6 | -14.4 | 59,371.62 | 44 | 6.7 | 21,775.16 | 82 | 27.8 | 8947.93 | 120 | 48.9 | 4049.77 |
| 7 | -13.9 | 57,731.32 | 45 | 7.2 | 21,242.23 | 83 | 28.3 | 8752.95 | 121 | 49.4 | 3970.79 |
| 8 | -13.3 | 56,141.52 | 46 | 7.8 | 20,723.96 | 84 | 28.9 | 8562.79 | 122 | 50.0 | 3893.58 |
| 9 | -12.8 | 54,600.50 | 47 | 8.3 | 20,219.91 | 85 | 29.4 | 8377.31 | 123 | 50.6 | 3818.08 |
| 10 | -12.2 | 53,106.64 | 48 | 8.9 | 19,729.65 | 86 | 30.0 | 8196.39 | 124 | 51.1 | 3744.26 |
| 11 | -11.7 | 51,658.35 | 49 | 9.4 | 19,252.76 | 87 | 30.6 | 8019.91 | 125 | 51.7 | 3672.07 |
| 12 | -11.1 | 50,254.11 | 50 | 10.0 | 18,788.84 | 88 | 31.1 | 7847.74 | | | |

TABLE 10
8301-089 Sensor: Humidity/mA

| RH% | mA Output | RH% | mA Output | RH% | mA Output |
|------------|------------------|------------|------------------|------------|------------------|
| 0 | 4.000 mA | 34 | 9.440 mA | 68 | 14.880 mA |
| 1 | 4.160 mA | 35 | 9.600 mA | 69 | 15.040 mA |
| 2 | 4.320 mA | 36 | 9.760 mA | 70 | 15.200 mA |
| 3 | 4.480 mA | 37 | 9.920 mA | 71 | 15.360 mA |
| 4 | 4.640 mA | 38 | 10.080 mA | 72 | 15.520 mA |
| 5 | 4.800 mA | 39 | 10.240 mA | 73 | 15.680 mA |
| 6 | 4.960 mA | 40 | 10.400 mA | 74 | 15.840 mA |
| 7 | 5.120 mA | 41 | 10.560 mA | 75 | 16.000 mA |
| 8 | 5.280 mA | 42 | 10.720 mA | 76 | 16.160 mA |
| 9 | 5.440 mA | 43 | 10.880 mA | 77 | 16.320 mA |
| 10 | 5.600 mA | 44 | 11.040 mA | 78 | 16.480 mA |
| 11 | 5.760 mA | 45 | 11.200 mA | 79 | 16.640 mA |
| 12 | 5.920 mA | 46 | 11.360 mA | 80 | 16.800 mA |
| 13 | 6.080 mA | 47 | 11.520 mA | 81 | 16.960 mA |
| 14 | 6.240 mA | 48 | 11.680 mA | 82 | 17.120 mA |
| 15 | 6.400 mA | 49 | 11.840 mA | 83 | 17.280 mA |
| 16 | 6.560 mA | 50 | 12.000 mA | 84 | 17.440 mA |
| 17 | 6.720 mA | 51 | 12.160 mA | 85 | 17.600 mA |
| 18 | 6.880 mA | 52 | 12.320 mA | 86 | 17.760 mA |
| 19 | 7.040 mA | 53 | 12.480 mA | 87 | 17.920 mA |
| 20 | 7.200 mA | 54 | 12.640 mA | 88 | 18.080 mA |
| 21 | 7.360 mA | 55 | 12.800 mA | 89 | 18.240 mA |
| 22 | 7.520 mA | 56 | 12.960 mA | 90 | 18.400 mA |
| 23 | 7.680 mA | 57 | 13.120 mA | 91 | 18.560 mA |
| 24 | 7.840 mA | 58 | 13.280 mA | 92 | 18.720 mA |
| 25 | 8.000 mA | 59 | 13.440 mA | 93 | 18.880 mA |
| 26 | 8.160 mA | 60 | 13.600 mA | 94 | 19.040 mA |
| 27 | 8.320 mA | 61 | 13.760 mA | 95 | 19.200 mA |
| 28 | 8.480 mA | 62 | 13.920 mA | 96 | 19.360 mA |
| 29 | 8.640 mA | 63 | 14.080 mA | 97 | 19.520 mA |
| 30 | 8.800 mA | 64 | 14.240 mA | 98 | 19.680 mA |
| 31 | 8.960 mA | 65 | 14.400 mA | 99 | 19.840 mA |
| 32 | 9.120 mA | 66 | 14.560 mA | 100 | 20.000 mA |
| 33 | 9.280 mA | 67 | 14.720 mA | | |


**8620-296 Supply Air Sensor/Return Air Sensor/Mixed Air Sensor/Suction Sensor/
Liquid Sensor**

TABLE 11
8620-296 Sensor: Temperature/Resistance Curve J

| Temperature °F | Resistance Ω | Temperature °F | Resistance Ω | Temperature °F | Resistance Ω | Temperature °F | Resistance Ω |
|-------------------|-----------------|-------------------|-----------------|-------------------|-----------------|-------------------|-----------------|
| -25.0 | 196871 | 13.0 | 56985 | 53.0 | 19374 | 89.0 | 7507 |
| -24.0 | 190099 | 14.0 | 55284 | 52.0 | 18867 | 90.0 | 7334 |
| -23.0 | 183585 | 15.0 | 53640 | 53.0 | 18375 | 91.0 | 7165 |
| -22.0 | 177318 | 16.0 | 52051 | 54.0 | 17989 | 92.0 | 7000 |
| -21.0 | 171289 | 17.0 | 50514 | 55.0 | 17434 | 93.0 | 6840 |
| -20.0 | 165487 | 18.0 | 49028 | 56.0 | 16984 | 94.0 | 6683 |
| -19.0 | 159904 | 19.0 | 47590 | 57.0 | 16547 | 95.0 | 6531 |
| -18.0 | 154529 | 20.0 | 46200 | 58.0 | 16122 | 96.0 | 6383 |
| -17.0 | 149355 | 21.0 | 44855 | 59.0 | 15710 | 97.0 | 6239 |
| -16.0 | 144374 | 22.0 | 43554 | 60.0 | 15310 | 98.0 | 6098 |
| -15.0 | 139576 | 23.0 | 42295 | 61.0 | 14921 | 99.0 | 5961 |
| -14.0 | 134956 | 24.0 | 41077 | 62.0 | 14544 | 100.0 | 5827 |
| -13.0 | 130506 | 25.0 | 39898 | 63.0 | 14177 | 101.0 | 5697 |
| -12.0 | 126219 | 26.0 | 38757 | 64.0 | 13820 | 102.0 | 5570 |
| -11.0 | 122089 | 27.0 | 37652 | 65.0 | 13474 | 103.0 | 5446 |
| -10.0 | 118108 | 28.0 | 36583 | 66.0 | 13137 | 104.0 | 5326 |
| -9.0 | 114272 | 29.0 | 35548 | 67.0 | 12810 | 105.0 | 5208 |
| -8.0 | 110575 | 30.0 | 34545 | 68.0 | 12492 | 106.0 | 5094 |
| -7.0 | 107010 | 31.0 | 33574 | 69.0 | 12183 | 107.0 | 4982 |
| -6.0 | 103574 | 32.0 | 32634 | 70.0 | 11883 | 108.0 | 4873 |
| -5.0 | 100260 | 33.0 | 31723 | 71.0 | 11591 | 109.0 | 4767 |
| -4.0 | 97064 | 34.0 | 30840 | 72.0 | 11307 | 110.0 | 4663 |
| -3.0 | 93981 | 35.0 | 29986 | 73.0 | 11031 | 111.0 | 4562 |
| -2.0 | 91008 | 36.0 | 29157 | 74.0 | 10762 | 112.0 | 4464 |
| -1.0 | 88139 | 37.0 | 28355 | 75.0 | 10501 | 113.0 | 4367 |
| 0.0 | 85371 | 38.0 | 27577 | 76.0 | 10247 | 114.0 | 4274 |
| 1.0 | 82699 | 39.0 | 26823 | 77.0 | 10000 | 115.0 | 4182 |
| 2.0 | 80121 | 40.0 | 26092 | 78.0 | 9760 | 116.0 | 4093 |
| 3.0 | 77632 | 41.0 | 25383 | 79.0 | 9526 | 117.0 | 4006 |
| 4.0 | 75230 | 42.0 | 24696 | 80.0 | 9299 | 118.0 | 3921 |
| 5.0 | 72910 | 43.0 | 24030 | 81.0 | 9077 | 119.0 | 3838 |
| 6.0 | 70670 | 44.0 | 23384 | 82.0 | 8862 | 120.0 | 3757 |
| 7.0 | 68507 | 45.0 | 22758 | 83.0 | 8653 | 121.0 | 3678 |
| 8.0 | 66418 | 46.0 | 22150 | 84.0 | 8449 | 122.0 | 3601 |
| 9.0 | 64399 | 47.0 | 21561 | 85.0 | 8250 | 123.0 | 3526 |
| 10.0 | 62449 | 48.0 | 20989 | 86.0 | 8057 | 124.0 | 3452 |
| 11.0 | 60565 | 49.0 | 20435 | 87.0 | 7869 | | |
| 12.0 | 58745 | 50.0 | 19896 | 88.0 | 7686 | | |

8301-057 Blower Status Switch/Dirty Filter Switch


FIGURE 56
8301-057 Air Differential Switch



Terminals

- 1 – Normally Closed
- 2 – Normally Open
- 3 – Common

NOTE: Contact position is in resting state.



Connect hose to P2

Alarm Index

TABLE 12
MEGA-TEC Alarm Index

| Index | Description |
|-------|---|
| 0 | Error in the number of retain memory writings |
| 1 | Error in retain memory writings |
| 2 | Circuit 1 Return Air Temperature Sensor Alarm |
| 3 | Circuit 1 High Return Air Temperature Alarm |
| 4 | Circuit 2 Return Air Temperature Sensor Alarm |
| 5 | Circuit 2 High Return Air Temperature Alarm |
| 6 | Circuit 1 Mixed Air Temperature Sensor Alarm |
| 7 | Circuit 1 Mixed Air High Temperature |
| 8 | Circuit 1 Mixed Air Low Temperature |
| 9 | Circuit 2 Mixed Air Temperature Sensor Alarm |
| 10 | Circuit 2 Mixed Air High Temperature |
| 11 | Circuit 2 Mixed Air Low Temperature |
| 12 | Circuit 1 Supply Air Temperature Sensor Alarm |
| 13 | Circuit 1 High Supply Air Temperature Alarm |
| 14 | Circuit 1 Low Supply Air Temperature Alarm |
| 15 | Circuit 2 Supply Air Temperature Sensor Alarm |
| 16 | Circuit 2 High Supply Air Temperature Alarm |
| 17 | Circuit 2 Low Supply Air Temperature Alarm |
| 18 | Outdoor Air Temperature Sensor Alarm |
| 19 | Outdoor Air Humidity Sensor Alarm |
| 20 | Circuit 1 Dust Sensor Alarm |
| 21 | Circuit 1 Dust Sensor High Dust Detection Alarm |
| 22 | Circuit 2 Dust Sensor Alarm |
| 23 | Circuit 2 Dust Sensor High Dust Detection Alarm |
| 24 | Circuit 1 Liquid Line Temp Sensor Alarm |
| 25 | Circuit 2 Liquid Line Temp Sensor Alarm |
| 26 | Circuit 1 Liquid Line Pressure Sensor Alarm |
| 27 | Circuit 2 Liquid Line Pressure Sensor Alarm |
| 28 | Circuit 1 Discharge Temp Sensor Alarm |
| 29 | Circuit 2 Discharge Temp Sensor Alarm |
| 30 | Circuit 1 Discharge Pressure Sensor Alarm |
| 31 | Circuit 2 Discharge Pressure Sensor Alarm |
| 32 | Circuit 1 Suction Temperature Sensor Alarm |
| 33 | Circuit 2 Suction Temperature Sensor Alarm |
| 34 | Circuit 1 Suction Pressure Sensor Alarm |
| 35 | Circuit 2 Suction Pressure Sensor Alarm |
| 36 | Circuit 1 Low Pressure |
| 37 | Circuit 2 Low Pressure |
| 38 | Circuit 1 High Pressure |
| 39 | Circuit 2 High Pressure |
| 40 | Circuit 1 Damper Failed to Open |
| 41 | Circuit 1 Damper Failed to Close |

| Index | Description |
|-------|--|
| 42 | Circuit 2 Damper Failed to Close |
| 43 | Circuit 2 Damper Failed to Open |
| 44 | Circuit 3 Damper Failed to Open |
| 45 | Circuit 3 Damper Failed to Close |
| 46 | Circuit 4 Damper Failed to Open |
| 47 | Circuit 4 Damper Failed to Close |
| 48 | Circuit 1 Freeze Temperature Sensor Alarm |
| 49 | Circuit 2 Freeze Temperature Sensor Alarm |
| 50 | Circuit 1 Freeze Condition |
| 51 | Circuit 2 Freeze Condition |
| 52 | Circuit 1 Blower Fail Alarm |
| 53 | Circuit 2 Blower Fail Alarm |
| 54 | Dirty Filter 1 Alarm |
| 55 | Dirty Filter 2 Alarm |
| 56 | Dirty Filter 3 Alarm |
| 57 | Dirty Filter 4 Alarm |
| 58 | Circuit 1 Dirty Condenser Coil Alarm |
| 59 | Circuit 2 Dirty Condenser Coil Alarm |
| 60 | Emergency Ventilation Mode Active |
| 61 | Emergency Cooling Mode Active |
| 62 | Extreme High Return Temp Alarm (Heat Cutout) |
| 63 | Unit Disable/Smoke Detector Alarm |
| 64 | Circuit 1 Power Loss Detected |
| 65 | Circuit 2 Power Loss Detected |
| 66 | Circuit 1 Low SuperHeat |
| 67 | Circuit 1 Low Evaporation Pressure |
| 68 | Circuit 1 High Evaporation Pressure |
| 69 | Circuit 1 High Condenser Temperature |
| 70 | Circuit 1 Low Suction Pressure |
| 71 | Circuit 1 EEV Motor Error |
| 72 | Circuit 1 Self Tuning Error |
| 73 | Circuit 1 Emergency Close |
| 74 | Circuit 1 High Delta Temperature |
| 75 | Circuit 1 High Delta Pressure |
| 76 | Circuit 1 Range Error |
| 77 | Circuit 1 Service Position Percent |
| 78 | Circuit 1 Valve ID |
| 79 | Circuit 2 Low SuperHeat |
| 80 | Circuit 2 Low Evaporation Pressure |
| 81 | Circuit 2 High Evaporation Pressure |
| 82 | Circuit 2 High Condenser Temperature |
| 83 | Circuit 2 Low Suction Pressure |

Continued on page 46

Alarm Index (continued from page 45)

| Index | Description |
|--------------|--|
| 84 | Circuit 2 EEV Motor Error |
| 85 | Circuit 2 Self Tuning Error |
| 86 | Circuit 2 Emergency Close |
| 87 | Circuit 2 High Delta Temperature |
| 88 | Circuit 2 High Delta Pressure |
| 89 | Circuit 2 Range Error |
| 90 | Circuit 2 Service Position Percent |
| 91 | Circuit 2 Valve ID |
| 92 | Th-Tune Device Offline |
| 93 | Th-Tune Temperature Probe Alarm |
| 94 | Th-Tune Humidity Probe Alarm |
| 95 | Th-Tune Clock Board Alarm |
| 96 | c.pCOe Offline |
| 97 | Offline EBM Blower 1 |
| 98 | |
| 99 | Offline EBM Blower 2 |
| 100 | |
| 101 | Offline EBM Fan 1 |
| 102 | |
| 103 | Offline EBM Fan 2 |
| 104 | |
| 105 | Circuit 1 Low Return Air Temperature Alarm |
| 106 | Circuit 2 Low Return Air Temperature Alarm |
| 107 | Panel Switch |

Blower Speeds

TABLE 13
Blower Speeds

| Mode | Nominal | High Sensible | Enhanced Latent |
|-----------------|----------------|----------------------|------------------------|
| Free Cooling | 57 | N/A | N/A |
| Cooling Stage 1 | 42 | 48.5 | 32.6 |
| Cooling Stage 2 | 57 | 63 | 43.8 |
| Cooling Stage 3 | 57 | 63 | 43.8 |
| Heating Stage 1 | 57 | N/A | N/A |
| Heating Stage 2 | 57 | N/A | N/A |
| Emergency Vent | 100 | N/A | N/A |
| Freeze Alarm | 80 | N/A | N/A |

FIGURE 57
Ventilation Airflow Paths

