



Climate Control Solutions

Bard Manufacturing Company, Inc.  
Bryan, Ohio 43506

## SIDE TRIM EXTENSION INSTALLATION INSTRUCTIONS

**QSTX42A-X-S10, QSTX42A-V-S10, QSTX42A-4-S10**  
**QSTX42A-V-S13, QSTX42A-4-S13**  
**QSTX42A-V-S16, QSTX42A-4-S16**  
**QSTX42A-X-S13, QSTX42A-X-S16**

TRIM KIT MODEL	DIMENSION SUITED FOR
Trim pieces factory shipped with QA/QH Models	Will fill gaps when the dimension from the back of the Q-Tec unit up to the interior finished wall up to 4".
QSTX42A-X-S10 (Beige) QSTX42A-4-S10 (Buckeye Gray) QSTX42A-V-S10 (Vinyl)	Will fill gaps when the dimension from the back of the Q-Tec unit up to the interior finished wall up to 9.5".
QSTX42A-X-S13 (Beige) QSTX42A-4-S13 (Buckeye Gray) QSTX42A-V-S13 (Vinyl)	Will fill gaps when the dimension from the back of the Q-Tec unit up to the interior finished wall up to 12.5".
QSTX42A-X-S16 (Beige) QSTX42A-4-S16 (Buckeye Gray) QSTX42A-V-S16 (Vinyl)	Will fill gaps when the dimension from the back of the Q-Tec unit up to the interior finished wall up to 15.5".

1. The Q-Tec unit should be installed and attached to the sleeve with instructions supplied with the unit. Discard Side Trim and Bottom Trim Extension pieces supplied with unit if not used.
2. Position Side Trim pieces to the wall & against the side of the unit. Top trim piece may be cut off to suit ceiling height.
3. Attach Trim pieces to the wall with field supplied screws. No attachment to the unit is required.

