
SUPPLEMENTAL INSTRUCTIONS

Blank Off Plate Kit

Model: BOPLATE-5

Blank off plates are installed on the inside of the side grilles and over the exhaust opening in the condenser partition. The plates cover the air inlet and room exhaust openings, which restricts any outside air from entering the unit or room air from leaving the conditioned space. The blank off plate option may be utilized in applications where outside air intake is not required by state or local codes.

Blank off plate kit includes:

- 543-222 intake blank off plate (2)
- 543-220 exhaust blank off plate (1)
- 1012-086 screw type AB HXWHD#10-16X1/2 (6)
- 7960-852 supplemental instructions

Field-supplied tools needed:

- Personal protection equipment, including gloves and safety glasses
- 5/16" nut driver



Climate Control Solutions

Bard Manufacturing Company, Inc.
Bryan, Ohio 43506
www.bardhvac.com

Manual: 7960-893
Supersedes: **NEW**
Date: 8-4-20

Installation

WARNING

Electrical shock hazard.

Disconnect remote electrical power supply or supplies before servicing.

Failure to do so could result in electric shock or death.

WARNING

Exposed moving parts.

Disconnect electrical power before servicing.

Failure to do so could result in severe injury or amputation.

CAUTION

Cut hazard.

Wear gloves to avoid contact with sharp edges.

Failure to do so could result in personal injury.

Disconnect all power to unit (see Figure 1).

FIGURE 1
Disconnect Power



IMPORTANT: Sheet metal has sharp edges. The use of personal protective equipment (PPE) is required.

Remove left and right side grilles (see Figure 2).

FIGURE 2
Remove Side Grilles



Remove installed vent and discard. Retain screws to use when installing blank off plates.

Install left and right side intake blank off plates (see Figure 3).

Install exhaust blank off plate through return or through right side intake opening (see Figure 3).

FIGURE 3
Install Left and Right Side Intake Blank Off Plates and Exhaust Blank Off Plate

