



USE COPPER OR ALUMINUM WIRE

- ① Add jumper Rc to Rh. Set heat anticipators at .40A
- ② Remove jumper for 2-stage heat.
- ③ Set heat anticipators for W1 and W2 at .40A.

Single Package Air Conditioner  
4 and 5 Ton  
w/18kw

ry Wiring ———  
Wiring - - - - -