



⚠ See alternate thermostat sheet.
Set heat anticipator at .40A.

USE COPPER OR ALUMINUM WIRE

Single Package
Air Conditioner
4 and 5 Ton

Factory Wiring ———
Field Wiring - - - - -