



- 1 Reroute jumper from X2-W2 to X2-1.
- 2 Set heat anticipators at .40A for W1 and W2.

Fused Disconnect Switch

USE COPPER OR ALUMINUM WIRE

Single Package Heat Pump
4 and 5 Ton
w/10Kw

Factory Wiring ———
Field Wiring - - - - -