



USE COPPER OR ALUMINUM WIRE

- ⚠️ Capacitor provides off-cycle crankcase heat.
- ⚠️ See alternate thermostat sheet. Set heat anticipator at .40A.
- ⚠️ For 208V operation move this wire to 208V transformer tap.

230/208-60-1

Models  
20W/1  
w/4 or 5Kw

FACTORY WIRING	FIELD WIRING
Low Voltage ———	-----
High Voltage ———	-----

4007-121A