



USE COPPER OR ALUMINUM WIRE

- ⚠️ 1 Capacitor provides off-cycle crankcase heat.
- ⚠️ 2 See alternate thermostat sheet. Set heat anticipator at .40A.



230/208-60-1

MODELS
20WA1 & 24WA2
w/4 or 5kw

Factory Wiring _____
Field Wiring - - - - -