


USE COPPER OR ALUMINUM WIRE

- ⚠ Capacitor provides off-cycle crankcase heat.
- ⚠ See alternate thermostat sheet. Set heat anticipator at .40A.



230/208-60-1

Models
20WA1 & 24WA2
w/8 or 10kw

Factory Wiring ———
Field Wiring - - - - -