



USE COPPER OR ALUMINUM WIRE

- 1 Capacitor provides off-cycle crankcase heat.
- 2 See alternate thermostat sheet. Set heat anticipator at .40A.

Models  
20WA1 & 24WA2  
4 or 5Kw

Factory Wiring ———  
Field Wiring - - - - -