



USE COPPER OR ALUMINUM WIRE

- ⚠ Capacitor provides off-cycle crankcase heat.
- ⚠ See alternate thermostat sheet. Set heat anticipator at .40A.
- ⚠ For 208V operation move this wire to 208V transformer tap.

230/208-60-1

Models  
20WA1 & 24WA2  
w/4 or 5Kw

Factory Wiring ———  
Field Wiring - - - - -