



USE COPPER OR ALUMINUM WIRE

- ⚠️ 1 Capacitor provides off-cycle crankcase heat.
- ⚠️ 2 Set heat anticipator at .40A.
- ⚠️ 3 Do not connect jumper until transformer phasing has been checked. Refer to Step 8 on page 5 of 2100-084, also see diagram 7 on page 16.
- ⚠️ 4 For 208V operation move this wire to 208V transformer tap.

Model/Cat. No.
24WA2/05A21
Unit 2 of 2

Factory Wiring _____
Field Wiring - - - - -