



Factory Wiring ———
 Field Wiring - - - -

⚠ Add jumper Rc to Rh

⚠ Set heat anticipator for W1 at .40A.

⚠ FOR LOW SPEED OPERATION, DISCONNECT THE BLACK MOTOR LEAD AND CONNECT IT TO THE ORANGE MOTOR LEAD. CONNECT THE RED MOTOR LEAD TO BLOWER RELAY TERMINAL NUMBER 1.

USE COPPER OR ALUMINUM WIRE