



T874N1024/
Q674F1261

or
T874R1129/
Q674L1181

FACTORY WIRING	FIELD WIRING
Low Voltage ———	-----
High Voltage ———	-----

▲ For 208V operation move this wire to 208V transformer tap.

USE COPPER OR ALUMINUM WIRE