



⚠ If there is an X1 and X2 terminal on Q674L1181, jumper them together and connect from C to either one.

	FACTORY WIRING	FIELD WIRING
Low Voltage	—	- - -
High Voltage	—	- - -

USE COPPER OR ALUMINUM WIRE

⚠ For 208V operation move this wire to 208V transformer tap.