



- ① Reroute jumper from X2-W2 to X2-E.
- ② Set heat anticipators at .40A.

Factory Wiring ———
Field Wiring - - - -

USE COPPER OR ALUMINUM WIRE

230/208-60-3

Model
48WH1