



⚠ If there is an X1 and X2 terminal on Q674L1181, jumper them together and connect from C to either one.

USE COPPER OR ALUMINUM WIRE	FACTORY WIRING	FIELD WIRING
	Low Voltage ———	-----
	High Voltage - - - - -	-----

⚠ For 208V operation move this wire to 208V transformer tap 4014-211F