



- 1 Reroute jumper from X2-W2 to X2-E.
 - 2 Set heat anticipators at .40A.
 - 3 Remove this jumper if outdoor stat is used. Wire stat between terminals W2 and F.
- Factory Wiring _____
Field Wiring - - - - -

Model
48WH1
w/12 or 15 Kw

USE COPPER OR
ALUMINUM WIRE

230/208-60-3

4014-230 Rev C