



- 1 Reroute jumper from X2-W2 to X2-E.
  - 2 Set heat anticipators at .40A.
  - 3 Remove this jumper if outdoor stat is used. Wire stat between terminals W2 and F.
- Factory Wiring ———  
Field Wiring - - - - -

USE COPPER OR ALUMINUM WIRE

Model  
48WH1  
w/18Kw

230/208-60-3

4014-240 Rev. C