



1 Reroute jumper from X2-W2 to X2-E.

2 Set heat anticipators at .40A

3 Remove this jumper if outdoor stat is used. Wire stat between terminals W2 and F.

USE COPPER OR ALUMINUM WIRE

MODEL 48WH1 w/18 Kw

Factory Wiring ———
Field Wiring - - - - -

460V 60Hz JPh

4014-310C