



- ⚠ IF THERE IS AN X1 AND X2 TERMINAL ON Q674L1181, JUMPER THEM TOGETHER AND CONNECT FROM C TO EITHER ONE.
- ⚠ FOR 208V OPERATION MOVE THIS WIRE TO 208V TRANSFORMER TAP.

FUSE A - 60A TIME DELAY
 FUSE B - 60A STANDARD
 ALL FUSES CLASS K5

| | FACTORY WIRING | FIELD WIRING |
|--------------|----------------|--------------|
| Low Voltage | _____ | ----- |
| High Voltage | _____ | ----- |

USE COPPER OR ALUMINUM WIRE