



Wall-Mount™ Heat Pumps

Specification Sheets

Document #	Description
S3381	CH3S1-CH5S1 'Quiet-Climate2' Specification (R-410A)
F1912	CH3S1-CH5S1 Series Engineering Specification Guide(R-410A) (F1912-Word.doc)
S3416	S26H1-S61H1 'Quiet-Climate1' Specification (R-410A)
F1911	S26H1-S61H1 Series Engineering Specification Guide(R-410A) (F1911-Word.doc)
7960-593	S26H1D-S61H1D Dehumidification 'Quiet-Climate1' Specification (R-410A)
S3398	W18H1-W60H1 Series Specification (R-410A)
F1910	W18H1-W60H1 Series Engineering Specification Guide(R-410A) (F1910-Word.doc)
7960-576	W24H1-W60H1 Series Dehumidification Performance Data (R-410A)
S3417	W26H1 – W61H1 'High Efficiency' Series Specification (R-410A) (W26H1 – W61H1 ~ For Use In Western Region Applications)
F1759	SH 'Quiet-Climate1' Engineering Specification Guide (R-22)
F1761	SH 'Quiet-Climate1' Dehumidification Performance Data (R-22)
S3359	SH261-SH612 'Quiet-Climate1' 'High Efficiency' Series Specification (R-22)
F1382	WH Engineering Specification Guide (R-22)
F1743	WH Dehumidification Performance Data (R-22)
S3210	WH184-WH605 Series Specification (R-22)
F1722	Wall-Mount™ Ventilation Overview
Color Link	Wall-Mount Cabinet Finishes
Grille Link	Supply & Return Air Grille Submittal Information
TechniCoat Link	Phenolic Coated Coil Option Information
Thermostat Link	Bard Thermostat Information & Installation Instructions
Case Study Link	Bard Project Case Studies
Serial Number Link	Bard Serial Number Nomenclature Matrix
Warranty Link	Bard Limited Warranty (USA, Canada & Mexico)
2100-034	Wall-Mount User Information Manual



Wall-Mount™ Heat Pumps

CH 'Quiet Climate2' Series Wall-Mount™ H/P Units - R-410A

Model	Literature Assembly	Installation Manual	Parts Manual	Wiring Diagram
CH3S1-A	911-0441	2100-455	2110-556	4096-133(D)
CH3S1-B	911-0441	2100-455	2110-556	4096-234(E)
CH3S1-C	911-0441	2100-455	2110-556	4096-335(E)
CH4S1-A	911-0441	2100-455	2110-556	4096-133(D)
CH4S1-B	911-0441	2100-455	2110-556	4096-234(E)
CH4S1-C	911-0441	2100-455	2110-556	4096-335(E)
CH5S1-A	911-0441	2100-455	2110-556	4096-133(D)
CH5S1-B	911-0441	2100-455	2110-556	4096-234(E)
CH5S1-C	911-0441	2100-455	2110-556	4096-335(E)

S**H 'QuietClimate1' Series Wall-Mount™ H/P Units – R-410A

Model	Literature Assembly	Installation Manual	Parts Manual	Wiring Diagram
S26H1-A	911-0514	2100-527	2110-579	4096-140(A)
S26H1-B	911-0514	2100-527	2110-579	4096-242(A)
S26H1-C	911-0514	2100-527	2110-579	4096-341(B)
S31H1-A	911-0515	2100-527	2110-579	4096-140(A)
S31H1-B	911-0515	2100-527	2110-579	4096-242(A)
S31H1-C	911-0515	2100-527	2110-579	4096-341(B)
S38H1-A	911-0515	2100-527	2110-578	4096-140(A)
S38H1-B	911-0515	2100-527	2110-578	4096-242(A)
S38H1-C	911-0515	2100-527	2110-578	4096-341(B)
S43H1-A	911-0515	2100-527	2110-578	4096-140(A)
S43H1-B	911-0515	2100-527	2110-578	4096-242(A)
S43H1-C	911-0515	2100-527	2110-578	4096-341(B)
S49H1-A	911-0515	2100-527	2110-578	4096-140(A)
S49H1-B	911-0515	2100-527	2110-578	4096-242(A)
S49H1-C	911-0515	2100-527	2110-578	4096-341(B)



Wall-Mount™ Heat Pumps

S**H 'QuietClimate1' Series Wall-Mount™ H/P Units – R-410A

Model	Literature Assembly	Installation Manual	Parts Manual	Wiring Diagram
S61H1-A	911-0515	2100-527	2110-578	4096-140(A)
S61H1-B	911-0515	2100-527	2110-578	4096-242(A)
S61H1-C	911-0515	2100-527	2110-578	4096-341(B)

S**H1D Dehumidification Series Wall-Mount™ H/P Units–R-410A

Model	Literature Assembly	Installation Manual	Parts Manual	Wiring Diagram
S26H1DA	911-0514	2100-527	2110-579	4096-151
S26H1DB	911-0514	2100-527	2110-579	4096-251
S26H1DC	911-0514	2100-527	2110-579	4096-351
S31H1DA	911-0514	2100-527	2110-579	4096-151
S31H1DB	911-0514	2100-527	2110-579	4096-251
S31H1DC	911-0514	2100-527	2110-579	4096-351
S38H1DA	911-0515	2100-527	2110-578	4096-150
S38H1DB	911-0515	2100-527	2110-578	4096-250
S38H1DC	911-0515	2100-527	2110-578	4096-350
S43H1DA	911-0515	2100-527	2110-578	4096-150
S43H1DB	911-0515	2100-527	2110-578	4096-250
S43H1DC	911-0515	2100-527	2110-578	4096-350
S49H1DA	911-0515	2100-527	2110-578	4096-150
S49H1DB	911-0515	2100-527	2110-578	4096-250
S49H1DC	911-0515	2100-527	2110-578	4096-350
S61H1DA	911-0515	2100-527	2110-578	4096-150
S61H1DB	911-0515	2100-527	2110-578	4096-250
S61H1DC	911-0515	2100-527	2110-578	4096-350
Supplemental S**H Series Dehum Information				7960-593



Wall-Mount™ Heat Pumps

W**H Series Wall-Mount™ H/P Units – R-410A

Model	Literature Assembly	Installation Manual	Parts Manual	Wiring Diagram
W18H1-A	911-0498	2100-511	2110-573	4096-141
W24H1-A	911-0498	2100-511	2110-573	4096-140
W24H1-B	911-0498	2100-511	2110-573	4096-242
W24H1-C	911-0498	2100-511	2110-573	4096-341
W30H1-A	911-0499	2100-511	2110-572	4096-140
W30H1-B	911-0499	2100-511	2110-572	4096-242
W30H1-C	911-0499	2100-511	2110-572	4096-341
W36H1-A	911-0499	2100-511	2110-572	4096-140
W36H1-B	911-0499	2100-511	2110-572	4096-242
W36H1-C	911-0499	2100-511	2110-572	4096-341
W42H1-A	911-0500	2100-511	2110-571	4096-139
W42H1-B	911-0500	2100-511	2110-571	4096-240
W42H1-C	911-0500	2100-511	2110-571	4096-339
W48H1-A	911-0500	2100-511	2110-571	4096-139
W48H1-B	911-0500	2100-511	2110-571	4096-240
W48H1-C	911-0500	2100-511	2110-571	4096-339
W60H1-A	911-0500	2100-511	2110-571	4096-139
W60H1-B	911-0500	2100-511	2110-571	4096-240
W60H1-C	911-0500	2100-511	2110-571	4096-339
W**H Low Voltage Control Circuit Wiring			2100-516	



Wall-Mount™ Heat Pumps

W**H Dehumidification Series Wall-Mount™ H/P Units – R-410A

Model	Literature Assembly	Installation Manual	Parts Manual	Wiring Diagram
W24H1DA	911-0499	2100-511	2110-573	4096-143
W24H1DB	911-0499	2100-511	2110-573	4096-244
W24H1DC	911-0499	2100-511	2110-573	4096-342
W30H1DA	911-0499	2100-511	2110-572	4096-143
W30H1DB	911-0499	2100-511	2110-572	4096-244
W30H1DC	911-0499	2100-511	2110-572	4096-342
W36H1DA	911-0499	2100-511	2110-572	4096-143
W36H1DB	911-0499	2100-511	2110-572	4096-244
W36H1DC	911-0499	2100-511	2110-572	4096-342
W42H1DA	911-0500	2100-511	2110-572	4096-144
W42H1DB	911-0500	2100-511	2110-572	4096-246
W42H1DC	911-0500	2100-511	2110-572	4096-345
W48H1DA	911-0500	2100-511	2110-571	4096-144
W48H1DB	911-0500	2100-511	2110-571	4096-246
W48H1DC	911-0500	2100-511	2110-571	4096-345
W60H1DA	911-0500	2100-511	2110-571	4096-144
W60H1DB	911-0500	2100-511	2110-571	4096-246
W60H1DC	911-0500	2100-511	2110-571	4096-345
W**H*D Low Voltage Control Circuit Wiring			2100-516	



Wall-Mount™ Heat Pumps

S**H 'Quiet Climate1' Series Wall-Mount™ H/P Units – R-22

Model	Literature Assembly	Installation Manual	Parts Manual	Wiring Diagram
SH261-A	911-0383	2100-409	2110-538	4096-115(B)
SH261-B	911-0383	2100-409	2110-538	4096-233(A)
SH261-C	911-0383	2100-409	2110-538	4096-334(A)
SH311-A	911-0383	2100-409	2110-538	4096-115(B)
SH311-B	911-0383	2100-409	2110-538	4096-233(A)
SH311-C	911-0383	2100-409	2110-538	4096-334(A)
SH381-A	911-0384	2100-410	2110-539	4096-124(A)
SH381-B	911-0384	2100-410	2110-539	4096-225(B)
SH381-C	911-0384	2100-410	2110-539	4096-325(C)
SH431-A	911-0384	2100-410	2110-539	4096-125(A)
SH431-B	911-0384	2100-410	2110-539	4096-226(B)
SH431-C	911-0384	2100-410	2110-539	4096-326(C)
SH491-A	911-0384	2100-410	2110-539	4096-125(A)
SH491-B	911-0384	2100-410	2110-539	4096-226(B)
SH491-C	911-0384	2100-410	2110-539	4096-326(C)
SH612-A	911-0468	2100-481	2110-561	4096-136
SH612-B	911-0468	2100-481	2110-561	4096-236
SH612-C	911-0468	2100-481	2110-561	4096-337



Wall-Mount™ Heat Pumps

SH Dehumidification Series Wall-Mount™ H/P Units - R-22

Model	Literature Assembly	Installation Manual	Parts Manual	Wiring Diagram
SH261DA	911-0382	2100-408	2110-543	4096-126(C)
SH261DB	911-0382	2100-408	2110-543	4096-239(E)
SH261DC	911-0382	2100-408	2110-543	4096-331(C)
SH311DA	911-0382	2100-408	2110-543	4096-126(C)
SH311DB	911-0382	2100-408	2110-543	4096-239(E)
SH311DC	911-0382	2100-408	2110-543	4096-331(C)
SH381DA	911-0402	2100-413	2110-541	4096-128(D)
SH381DB	911-0402	2100-413	2110-541	4096-228(E)
SH381DC	911-0402	2100-413	2110-541	4096-330(E)
SH431DA	911-0402	2100-413	2110-541	4096-127(D)
SH431DB	911-0402	2100-413	2110-541	4096-229(E)
SH431DC	911-0402	2100-413	2110-541	4096-328(E)
SH491DA	911-0402	2100-413	2110-541	4096-127(D)
SH491DB	911-0402	2100-413	2110-541	4096-230(E)
SH491DC	911-0402	2100-413	2110-541	4096-329(F)
SH611DA	911-0403	2100-414	2110-542	4096-127(D)
SH611DB	911-0403	2100-414	2110-542	4096-230(E)
SH611DC	911-0403	2100-414	2110-542	4096-329(F)



Wall-Mount™ Heat Pumps

WH Series Wall-Mount™ Heat Pump Units – R-22

Model	Literature Assembly	Installation Manual	Parts Manual	Wiring Diagram
WH184-A	911-0413	2100-423	2110-549	4096-115(B)
WH185-A	911-0482	2100-501	2110-567	4096-138
WH242-A	911-0482	2100-501	2110-567	4096-110(D)
WH242-B	911-0482	2100-501	2110-567	4096-210(G)
WH242-C	911-0482	2100-501	2110-567	4096-310(F)
WH303-A	911-0477	2100-489	2110-565	4096-110(D)
WH303-B	911-0477	2100-489	2110-565	4096-210(G)
WH303-C	911-0477	2100-489	2110-565	4096-310(F)
WH363-A	911-0477	2100-489	2110-565	4096-110(D)
WH363-B	911-0477	2100-489	2110-565	4096-210(G)
WH363-C	911-0477	2100-489	2110-565	4096-310(F)
WH421-A	911-0373	2100-399	2110-537	4096-110(D)
WH421-B	911-0373	2100-399	2110-537	4096-210(G)
WH421-C	911-0373	2100-399	2110-537	4096-310(F)
WH423-A	911-0475	2100-487	2110-563	4096-110(D)
WH423-B	911-0475	2100-487	2110-563	4096-210(G)
WH423-C	911-0475	2100-487	2110-563	4096-310(F)
WH483-A	911-0475	2100-487	2110-563	4096-113(B)
WH483-B	911-0475	2100-487	2110-563	4096-213(D)
WH483-C	911-0475	2100-487	2110-563	4096-313(G)
WH602-A	911-0373	2100-399	2110-537	4096-113(B)
WH602-B	911-0373	2100-399	2110-537	4096-213(D)
WH602-C	911-0373	2100-399	2110-537	4096-313(G)
WH604-A	911-0475	2100-487	2110-563	4096-113(B)
WH604-B	911-0475	2100-487	2110-563	4096-213(D)
WH604-C	911-0475	2100-487	2110-563	4096-313(G)



Wall-Mount™ Heat Pumps

WH Dehum Series Wall-Mount™ Heat Pump Units – R-22

Model	Literature Assembly	Installation Manual	Parts Manual	Wiring Diagram
WH243DA	911-0434	2100-441	2110-553	4096-130(C)
WH243DB	911-0434	2100-441	2110-553	4096-231(D)
WH243DC	911-0434	2100-441	2110-553	4096-332(C)
WH303DA	911-0478	2100-490	2110-566	4096-130(C)
WH303DB	911-0478	2100-490	2110-566	4096-231(D)
WH303DC	911-0478	2100-490	2110-566	4096-332(C)
WH363DA	911-0478	2100-490	2110-566	4096-130(C)
WH363DB	911-0478	2100-490	2110-566	4096-231(D)
WH363DC	911-0478	2100-490	2110-566	4096-332(C)
WH422DA	911-0436	2100-443	2110-555	4096-130(C)
WH422DB	911-0436	2100-443	2110-555	4096-231(D)
WH422DC	911-0436	2100-443	2110-555	4096-332(C)
WH423DA	911-0476	2100-488	2110-564	4096-130(C)
WH423DB	911-0476	2100-488	2110-564	4096-231(D)
WH423DC	911-0476	2100-488	2110-564	4096-332(C)
WH484DA	911-0476	2100-488	2110-564	4096-131(C)
WH484DB	911-0476	2100-488	2110-564	4096-232(D)
WH484DC	911-0476	2100-488	2110-564	4096-333(C)
WH603DA	911-0436	2100-443	2110-555	4096-131(C)
WH603DB	911-0436	2100-443	2110-555	4096-232(D)
WH603DC	911-0436	2100-443	2110-555	4096-333(C)
WH604DA	911-0476	2100-488	2110-564	4096-131(C)
WH604DB	911-0476	2100-488	2110-564	4096-232(D)
WH604DC	911-0476	2100-488	2110-564	4096-333(C)



Wall-Mount™ Heat Pumps

WH Low-Ampacity Series Wall-Mount™ Heat Pump Units – R-22

Model	Literature Assembly	Installation Manual	Parts Manual	Wiring Diagram
WH242LA	911-0413	2100-423	2110-549	4096-112(B)
WH301LA	911-0160	2100-193	2110-517	4096-112(B)
WH301LB	911-0160	2100-193	2110-517	4096-212(D)
WH361LA	911-0160	2100-193	2110-517	4096-112(B)
WH361LB	911-0160	2100-193	2110-517	4096-212(D)
WH421LA	911-0373	2100-399	2110-537	4096-112(B)
WH421LB	911-0373	2100-399	2110-537	4096-212(D)
WH421LC	911-0373	2100-399	2110-537	4096-314(C)
WH483LA	911-0373	2100-399	2110-537	4096-114(A)
WH483LB	911-0373	2100-399	2110-537	4096-214(C)
WH483LC	911-0373	2100-399	2110-537	4096-315(D)
WH602LA	911-0373	2100-399	2110-537	4096-114(A)
WH602LB	911-0373	2100-399	2110-537	4096-214(C)
WH602LC	911-0373	2100-399	2110-537	4096-315(D)
Supplemental WH Low-Ampacity Electrical Ratings			7960-483	