



Package Air Conditioners

Specification Sheets

Package Air Conditioner Specifications

Document #	Tonnage	Description
S3422		Company Brochure
S3383	2.0 – 5.0	PA13 Series Air Conditioners (13 SEER)
S3331		P12 Series Air Conditioner (12 SEER)
TBR	5.0 – 6.0	Package Variable Capacity ECU (60hz/50hz)
S3337		P10 – P11 Series Air Conditioner (10-11 SEER)
Thermostat Link		Bard Thermostat Information & Installation Instructions
Serial Number Link		Bard Serial Number Nomenclature Matrix
Warranty Link		Bard Limited Warranty (USA, Canada & Mexico)

PA13 Series Package Air Conditioner Units R-410A (13 SEER)

Model	Literature Assembly	Installation Manuals	Parts Manuals	Wiring Diagrams
PA13242-A	911-0453	2100-467	2110-216	4109-100
PA13302-A	911-0453	2100-467	2110-216	4109-100
PA13362-A	911-0453	2100-467	2110-216	4109-100
PA13362-B	911-0453	2100-467	2110-216	4109-200
PA13422-A	911-0460	2100-467	2110-218	4109-102
PA13422-B	911-0460	2100-467	2110-218	4109-202
PA13482-A	911-0460	2100-467	2110-218	4109-103
PA13482-B	911-0460	2100-467	2110-218	4109-202
PA13602-A	911-0460	2100-467	2110-218	4109-103
PA13602-B	911-0460	2100-467	2110-218	4109-203
		2100-034		

User Information Guide



Package Air Conditioners

PA13 Series Optional Electric Heat Packages (13 SEER Units)

Model	Literature Assembly	Installation Manuals	Parts Manuals	Wiring Diagrams
EHP323-A05		2100-472	2110-308	4111-100
EHP323-A10		2100-472	2110-308	4111-101
EHP323-A15		2100-472	2110-308	4111-102
EHP323-B09		2100-472	2110-308	4111-200
EHP323-B15		2100-472	2110-308	4111-201
EHP513-A05		2100-474	2110-309	4111-100
EHP513-A10		2100-474	2110-309	4111-101
EHP513-A15		2100-474	2110-309	4111-102

PA13 Series Optional Electric Heat Packages (13 SEER Units)

Model	Literature Assembly	Installation Manuals	Parts Manuals	Wiring Diagrams
EHP513-B09		2100-474	2110-309	4111-200
EHP513-B15		2100-474	2110-309	4111-202
EHP513-C09		2100-474	2110-309	4111-300
EHP513-C15		2100-474	2110-309	4111-301

PA13 Series Package Unit Accessories

Model	Literature Assembly	Installation Manuals	Parts Manuals	Wiring Diagrams
RHP313-A		7960-538		
RHP513-A		7960-538		
ERVR-A3D-X	911-0439	2100-445	2110-956	4056-179
ERVR-C3D-X	911-0439	2100-445	2110-956	4056-179



Package Air Conditioners

Package Variable Capacity ECU (60/50hz) (R-410A) (Right Hand Access)

Model	Literature Assembly	Installation Manuals	Parts Manuals	Wiring Diagrams
-------	---------------------	----------------------	---------------	-----------------

P60RV1-R
P72RV1-S
P72RV1-T

8403-066 ECU Series Controller Installation Operation & Quick Start
8403-066 ECU Series Controller Advanced Programming & Features

Package Variable Capacity ECU (60/50hz) (R-410A) (Left Hand Access)

Model	Literature Assembly	Installation Manuals	Parts Manuals	Wiring Diagrams
-------	---------------------	----------------------	---------------	-----------------

P60LV1-R
P72LV1-S
P72LV1-T

8403-066 ECU Series Controller Installation Operation & Quick Start
8403-066 ECU Series Controller Advanced Programming & Features