



QH ~ Q-Tec™ Heat Pump Units

Specification Sheets

Document #	Tonnage	Description
S3407	2.0 – 5.0	Q24H-Q60H Series II Air-To-Air Heat Pump Specification R-410A
F1914	2.0 – 5.0	Q24H-Q60H Series Engineering Specification Guide ~ R-410A (F1914-Word.doc)
7960-582	2.0 – 5.0	Q24H-Q60H Dehumidification Series Performance Data R-410A
S3349	2.0 – 5.0	QH Series II Air-To-Air Heat Pumps Specification R-22
F1744	2.0 – 5.0	QH Dehumidification Series Performance Data R-22
F1849 Color Link TechniCoat Link Case Study Link Serial Number Link Warranty Link		QSP Series Q-tec Sound Plenum Q-tec Cabinet & Outdoor Grille Finishes Phenolic Coated Coil Option Information Bard Project Case Studies Bard Serial Number Nomenclature Matrix Bard Limited Warranty (USA, Canada & Mexico)

Q**H Series Q-Tec Heat Pump Units ~ R-410A

Model	Literature Assembly	Installation Manual	Parts Manual	Wiring Diagram
Q24H1-A	911-0507	2100-519	2110-574	4100C116(B)
Q24H1-B	911-0507	2100-519	2110-574	4100C216(B)
Q24H1-C	911-0507	2100-519	2110-574	4100C316(B)
Q30H1-A	911-0507	2100-519	2110-574	4100C116(B)
Q30H1-B	911-0507	2100-519	2110-574	4100C216(B)
Q30H1-C	911-0507	2100-519	2110-574	4100C316(B)
Q36H1-A	911-0507	2100-519	2110-574	4100C116(B)
Q36H1-B	911-0507	2100-519	2110-574	4100C216(B)
Q36H1-C	911-0507	2100-519	2110-574	4100C316(B)
Q42H1-A	911-0507	2100-519	2110-574	4100C116(B)
Q42H1-B	911-0507	2100-519	2110-574	4100C216(B)
Q42H1-C	911-0507	2100-519	2110-574	4100C316(B)
Q48H1-A	911-0507	2100-519	2110-574	4100C116(B)
Q48H1-B	911-0507	2100-519	2110-574	4100C216(B)
Q48H1-C	911-0507	2100-519	2110-574	4100C316(B)
Q60H1-A	911-0507	2100-519	2110-574	4100C118
Q60H1-B	911-0507	2100-519	2110-574	4100C218(A)
Q60H1-C	911-0507	2100-519	2110-574	4100C318
		2100-034		Q-Tec User Information Manual



QH ~ Q-Tec™ Heat Pump Units

Q**H*D Dehumidification Series Q-Tec Heat Pump Units ~ R-410A

Model	Literature Assembly	Installation Manual	Parts Manual	Wiring Diagram
Q24H1DA	911-0510	2100-521	2110-575	4100C117
Q24H1DB	911-0510	2100-521	2110-575	4100C217
Q24H1DC	911-0510	2100-521	2110-575	4100C317
Q30H1DA	911-0510	2100-521	2110-575	4100C117
Q30H1DB	911-0510	2100-521	2110-575	4100C217
Q30H1DC	911-0510	2100-521	2110-575	4100C317
Q36H1DA	911-0510	2100-521	2110-575	4100C117
Q36H1DB	911-0510	2100-521	2110-575	4100C217
Q36H1DC	911-0510	2100-521	2110-575	4100C317
Q42H1DA	911-0510	2100-521	2110-575	4100C117
Q42H1DB	911-0510	2100-521	2110-575	4100C217
Q42H1DC	911-0510	2100-521	2110-575	4100C317
Q48H1DA	911-0510	2100-521	2110-575	4100C117
Q48H1DB	911-0510	2100-521	2110-575	4100C217
Q48H1DC	911-0510	2100-521	2110-575	4100C317
Q60H1DA	911-0510	2100-521	2110-575	4100C119
Q60H1DB	911-0510	2100-521	2110-575	4100C219A
Q60H1DC	911-0510	2100-521	2110-575	4100C319
		2100-034	Q-Tec User Information Manual	



QH ~ Q-Tec™ Heat Pump Units

QH Series Q-Tec Heat Pump Units ~ R-22

Model	Literature Assembly	Installation Manual	Parts Manual	Wiring Diagram
QH243-A	911-0410	2100-420	2110-547	4100C105
QH243-B	911-0410	2100-420	2110-547	4100C207
QH243-C	911-0410	2100-420	2110-547	4100C307
QH302-A	911-0410	2100-420	2110-547	4100C105
QH302-B	911-0410	2100-420	2110-547	4100C207
QH302-C	911-0410	2100-420	2110-547	4100C307
QH362-A	911-0410	2100-420	2110-547	4100C105
QH362-B	911-0410	2100-420	2110-547	4100C207
QH362-C	911-0410	2100-420	2110-547	4100C307
QH422-A	911-0410	2100-420	2110-547	4100C105
QH422-B	911-0410	2100-420	2110-547	4100C207
QH422-C	911-0410	2100-420	2110-547	4100C307
QH482-A	911-0410	2100-420	2110-547	4100C105
QH482-B	911-0410	2100-420	2110-547	4100C207
QH482-C	911-0410	2100-420	2110-547	4100C307
QH602-A	911-0410	2100-420	2110-547	4100C105
QH602-B	911-0410	2100-420	2110-547	4100C207
QH602-C	911-0410	2100-420	2110-547	4100C307
		2100-034	Q-Tec User Information Manual	



QH ~ Q-Tec™ Heat Pump Units

QH Dehumidification Series Q-Tec Heat Pump Units ~ R-22

Model	Literature Assembly	Installation Manual	Parts Manual	Wiring Diagram
QH244DA	911-0427	2100-435	2110-550	4100C114
QH244DB	911-0427	2100-435	2110-550	4100C214
QH244DC	911-0427	2100-435	2110-550	4100C314
QH303DA	911-0427	2100-435	2110-550	4100C114
QH303DB	911-0427	2100-435	2110-550	4100C214
QH303DC	911-0427	2100-435	2110-550	4100C314
QH363DA	911-0427	2100-435	2110-550	4100C114
QH363DB	911-0427	2100-435	2110-550	4100C214
QH363DC	911-0427	2100-435	2110-550	4100C314
QH423DA	911-0427	2100-435	2110-550	4100C114
QH423DB	911-0427	2100-435	2110-550	4100C214
QH423DC	911-0427	2100-435	2110-550	4100C314
QH483DA	911-0427	2100-435	2110-550	4100C114
QH483DB	911-0427	2100-435	2110-550	4100C214
QH483DC	911-0427	2100-435	2110-550	4100C314
QH603DA	911-0427	2100-435	2110-550	4100C114
QH603DB	911-0427	2100-435	2110-550	4100C214
QH603DC	911-0427	2100-435	2110-550	4100C314
		2100-034	Q-Tec User Information Manual	



QH ~ Q-Tec™ Heat Pump Units

QH Low-Ampacity Series Q-Tec Heat Pump Units ~ R-22

Model	Literature Assembly	Installation Manual	Parts Manual	Wiring Diagram
QH302LA	911-0410	2100-379	2110-533	4100C106
QH302LB	911-0410	2100-379	2110-533	4100C208
QH302LC	911-0410	2100-379	2110-533	4100C308
QH362LA	911-0410	2100-379	2110-533	4100C106
QH362LB	911-0410	2100-379	2110-533	4100C208
QH362LC	911-0410	2100-379	2110-533	4100C308
QH422LA	911-0410	2100-379	2110-533	4100C106
QH422LB	911-0410	2100-379	2110-533	4100C208
QH422LC	911-0410	2100-379	2110-533	4100C308
QH482LA	911-0410	2100-379	2110-533	4100C106
QH482LB	911-0410	2100-379	2110-533	4100C208
QH482LC	911-0410	2100-379	2110-533	4100C308
QH602LA	911-0410	2100-379	2110-533	4100C106
Supplemental QH Series Low-Ampacity Electrical Information				7960-371(C)
		2100-034	Q-Tec User Information Manual	

QH & Q**H Series Ventilation Option Installation Manuals

- [2100-305](#) QCRV-4 / QCRV-P Commercial Room Ventilator
- [2100-310](#) QERV-A4B Energy Recovery Ventilator

QH & Q**H Series Accessory Installation Manuals

- [2100-289](#) QSW42A, QWS42A-16, QWS42A-19, QWS42A-20, QWS42A-23, QWS42A-30 Series Wall Sleeve
- [2100-319](#) QWS48A, QWS48A-16, QWS48A-19, QWS48A-20, QWS48A-23, QWS48A-30 Series Wall Sleeve
- [7960-356](#) QLG Standard Outdoor Louver
- [2100-446](#) QWS42A-H19 Series **Hurricane** Wall Sleeve
- [QLG-30-4H](#) **Hurricane Outdoor Louver**
- [2100-434](#) QWS48A-H19 Series **Hurricane** Wall Sleeve
- [QLG-35-4H](#) **Hurricane Outdoor Louver**
- [7960-571](#) QCDS48A Condensate Drain Kit (**QH & Q**H Series Only**)



QH ~ Q-Tec™ Heat Pump Units

[2100-394](#)

QCDS48H Heated Condensate Drain Kit (** QH & Q**H Series Only**)

QH & Q**H Series Accessory Installation Manuals

[7960-359](#)

QPB Plenum Boxes

[7960-438](#)

QCX Cabinet Extensions

[7960-444](#)

QSTX42 Side Trim Extension Kit

[7960-441](#)

QPBX42-9-* QPBX48-9-* Top Fill System

[7960-442](#)

QPBX42-10-* QPBX48-10-* Top Fill System

[7960-452](#)

QPBHW Free Blow & Ducted Hot Water Plenum Boxes

[7960-545](#)

QPBHW-MOD Free Blow & Ducted Hot Water Plenum Boxes (Modulating)

QH & Q**H Series Accessory Installation Manuals

[7960-518](#)

QSP Sound Plenum Installation Instructions