



QH ~ Q-Tec™ Heat Pump Units

Specification Sheets

Document #	Tonnage	Description
S3407	2.0 – 5.0	Q24H-Q60H Series II Air-To-Air Heat Pump Specification R-410A
F1914	2.0 – 5.0	Q24H-Q60H Series Engineering Specification Guide ~ R-410A (F1914-Word.doc)
7960-582	2.0 – 5.0	Q24H-Q60H Dehumidification Series Performance Data R-410A
MIS-2941		QLG Series Wall Louver Grille Specifications
S3349	2.0 – 5.0	QH Series II Air-To-Air Heat Pumps Specification R-22
F1744	2.0 – 5.0	QH Dehumidification Series Performance Data R-22
F1849		QSP Series Q-Tec Sound Plenum
Color Link		Q-Tec Cabinet & Outdoor Grille Finishes
TechniCoat Link		Phenolic Coated Coil Option Information
Case Study Link		Bard Project Case Studies
Serial# Link		Bard Serial Number Nomenclature Matrix
Warranty Link		Bard Limited Warranty (USA, Canada & Mexico)

Q**H Series Q-Tec Heat Pump Units ~ R-410A

Model	Literature Assembly	Installation Manual	Parts Manual	Wiring Diagram
Q24H1-A	911-0507	2100-519	2110-574	4100C116
Q24H1-B	911-0507	2100-519	2110-574	4100C216
Q24H1-C	911-0507	2100-519	2110-574	4100C316
Q30H1-A	911-0507	2100-519	2110-574	4100C116
Q30H1-B	911-0507	2100-519	2110-574	4100C216
Q30H1-C	911-0507	2100-519	2110-574	4100C316
Q36H1-A	911-0507	2100-519	2110-574	4100C116
Q36H1-B	911-0507	2100-519	2110-574	4100C216
Q36H1-C	911-0507	2100-519	2110-574	4100C316
Q42H1-A	911-0507	2100-519	2110-574	4100C116
Q42H1-B	911-0507	2100-519	2110-574	4100C216
Q42H1-C	911-0507	2100-519	2110-574	4100C316
Q48H1-A	911-0507	2100-519	2110-574	4100C116
Q48H1-B	911-0507	2100-519	2110-574	4100C216
Q48H1-C	911-0507	2100-519	2110-574	4100C316
Q60H1-A	911-0507	2100-519	2110-574	4100C118
Q60H1-B	911-0507	2100-519	2110-574	4100C218
Q60H1-C	911-0507	2100-519	2110-574	4100C318
		2100-034		Q-Tec User Information Manual



QH ~ Q-Tec™ Heat Pump Units

Q**H*D Dehumidification Series Q-Tec Heat Pump Units ~ R-410A

Model	Literature Assembly	Installation Manual	Parts Manual	Wiring Diagram
Q24H1DA	911-0510	2100-521	2110-575	4100C117
Q24H1DB	911-0510	2100-521	2110-575	4100C217
Q24H1DC	911-0510	2100-521	2110-575	4100C317
Q30H1DA	911-0510	2100-521	2110-575	4100C117
Q30H1DB	911-0510	2100-521	2110-575	4100C217
Q30H1DC	911-0510	2100-521	2110-575	4100C317
Q36H1DA	911-0510	2100-521	2110-575	4100C117
Q36H1DB	911-0510	2100-521	2110-575	4100C217
Q36H1DC	911-0510	2100-521	2110-575	4100C317
Q42H1DA	911-0510	2100-521	2110-575	4100C117
Q42H1DB	911-0510	2100-521	2110-575	4100C217
Q42H1DC	911-0510	2100-521	2110-575	4100C317
Q48H1DA	911-0510	2100-521	2110-575	4100C117
Q48H1DB	911-0510	2100-521	2110-575	4100C217
Q48H1DC	911-0510	2100-521	2110-575	4100C317
Q60H1DA	911-0510	2100-521	2110-575	4100C119
Q60H1DB	911-0510	2100-521	2110-575	4100C219
Q60H1DC	911-0510	2100-521	2110-575	4100C319
		2100-034	Q-Tec User Information Manual	



QH ~ Q-Tec™ Heat Pump Units

Q**H Series Ventilation Option Installation Manuals

- [2100-305](#) QCRV-4 / QCRV-P Commercial Room Ventilator
[2100-310](#) QERV-A4B Energy Recovery Ventilator

Q**H Series Accessory Installation Manuals

- [2100-289](#) QSW42A, QWS42A-16, QWS42A-19, QWS42A-20, QWS42A-23, QWS42A-30 Series Wall Sleeve
- [2100-319](#) QWS48A, QWS48A-16, QWS48A-19, QWS48A-20, QWS48A-23, QWS48A-30 Series Wall Sleeve
- [7960-356](#) QLG Standard Outdoor Louver Installation Instructions
- [2100-446](#) QWS42A-H19 Series **Hurricane** Wall Sleeve
[QLG-30-4H](#) **Hurricane Outdoor Louver**
- [2100-434](#) QWS48A-H19 Series **Hurricane** Wall Sleeve
[QLG-35-4H](#) **Hurricane Outdoor Louver**
- [7960-571](#) QCDS48A Condensate Drain Kit (**QH & Q**H Series Only**)
[2100-394](#) QCDS48H Heated Condensate Drain Kit (**QH & Q**H Series Only**)
- [7960-359](#) QPB Plenum Boxes
[7960-438](#) QCX Cabinet Extensions
[7960-444](#) QSTX42 Side Trim Extension Kit
[7960-441](#) QPBX42-9-* QPBX48-9-* Top Fill System
[7960-442](#) QPBX42-10-* QPBX48-10-* Top Fill System
[7960-452](#) QPBHW Free Blow & Ducted Hot Water Plenum Boxes
[7960-545](#) QPBHW-MOD Free Blow & Ducted Hot Water Plenum Boxes (Modulating)
- [7960-518](#) QSP Sound Plenum Installation Instructions