



NOTE:  
 BARD 8403-066 CONTROLLER  
 MUST BE USED WITH THESE  
 UNITS. A THERMOSTAT WILL NOT WORK.

Control Panel

Condenser Section

Wires Connect if Option Not Used

	Factory	Field	Optional
High Voltage	-----	-----	-----
Low Voltage	-----	-----	-----

**WARNING**  
 USE COPPER CONDUCTORS  
 ONLY SUITABLE FOR AT LEAST  
 75° C.

**DANGER**  
 ELECTRICAL SHOCK HAZARD  
 DISCONNECT POWER BEFORE  
 SERVICING.

4095-275 C