



Damper Motor
See Chart Below

REMOVE JUMPERS
TO CONNECT UNIT
SHUTDOWN RELAY

- LT LIQUID TEMPERATURE
- AFS AIR FLOW SWITCH
- DFS DIRTY FILTER SWITCH
- OATH OUTDOOR TEMP. AND HUMID. SENSOR
- SP SUCTION PRESSURE TRANSDUCER
- LP LIQUID PRESSURE TRANSDUCER
- SAT SUPPLY AIR TEMPERATURE
- RAT RETURN AIR TEMPERATURE
- ST SUCTION TEMPERATURE
- BS BLADE SWITCH
- DFL DIRTY FILTER LIGHT
- TB TERMINAL BLOCK
- HPS HIGH PRESSURE SWITCH
- CCH CRANKCASE HEATER
- EEV ELECTRONIC EXPANSION VALVE

DAMPER MOTOR					
Belimo Motor			Honeywell Motor		
Wire Color	Terminal Number	Symbol	Wire Color	Terminal Number	Symbol
BK/W	1	-	BK/W	2	GND
R/W	2	+	R/W	1	24 VAC
BR/W	3	Y	BR/W	3	2-10 VDC

	Factory	Field	Optional
High Voltage		---	---
Low Voltage		---	---
D-10VDC	---		