

Shipping Crate Matrix	Wall Mount Unit Dimensions			Crate Part #	Shipping Crate Dimensions			Shipping Crate Weight
	Unit Width	Unit Depth	Unit Height		Crate Width	Crate Depth	Crate Height	
C24H2 - High Efficiency Step Capacity H/P	38.2	17.13	70.56	8620-232	43	22.5	76.5	124
C24H1 - High Efficiency Step Capacity H/P	38.2	17.13	70.56	8620-232	43	22.5	76.5	124
C30H2 - High Efficiency Step Capacity H/P	38.2	17.13	70.56	8620-232	43	22.5	76.5	124
C30H1 - High Efficiency Step Capacity H/P	38.2	17.13	70.56	8620-232	43	22.5	76.5	124
C36H1 - High Efficiency Step Capacity H/P	42.08	22.43	84.88	8620-234	47	27.5	90.5	170
C42H1 - High Efficiency Step Capacity H/P	42.08	22.43	84.88	8620-234	47	27.5	90.5	170
C48H1 - High Efficiency Step Capacity H/P	42.08	22.43	93	8620-250	47	27.5	94.5	220
C60H1 - High Efficiency Step Capacity H/P	42.08	22.43	93	8620-250	47	27.5	94.5	220
D35A2P - DUAL-TEC -48VDC Rt. Hand Free Cooling	42.08	22.43	84.88	Not Available**				
D36A2P - DUAL-TEC -48VDC Rt. Hand Free Cooling	42.08	22.43	84.88	Not Available**				
D48A2P - DUAL-TEC -48VDC Rt. Hand Free Cooling	42.08	22.43	93	Not Available**				
D35L2P - DUAL-TEC -48VDC Lt. Hand Free Cooling	42.08	22.43	84.88	Not Available**				
D36L2P - DUAL-TEC -48VDC Lt. Hand Free Cooling	42.08	22.43	84.88	Not Available**				
D48L2P - DUAL-TEC -48VDC Lt. Hand Free Cooling	42.08	22.43	93	Not Available**				
H72AB - 10EER Right Hand Air Conditioners	42.08	22.43	93	8620-250	47	27.5	94.5	220
	42.08	29.43	93	8620-278, With "Y" or "Z" Economizer With Factory Installed 7" Hood*	46	33.5	99	240
H72LB - 10EER Right Hand Air Conditioners	42.08	22.43	93	8620-250	47	27.5	94.5	220
	42.08	29.43	93	8620-278, With "Y" or "Z" Economizer With Factory Installed 7" Hood*	46	33.5	99	240
HR35BP - FUSION-TEC Air Conditioner	36.86	27.33	71.61	Not Available				
HR36AP - FUSION-TEC Air Conditioner	42	29.8	76	Not Available				
HR36BP - FUSION-TEC Air Conditioner	42	29.8	76	Not Available				
HR58AP - FUSION-TEC Air Conditioner	42	29.8	76	Not Available				
HR58BP - FUSION-TEC Air Conditioner	42	29.8	76	Not Available				
K36A2 - SASO 11.5EER High Eff. Rt. Hand A/C	42.08	22.43	84.88	8620-234	47	27.5	90.5	170
K48A2 - SASO 11.5EER High Eff. Rt. Hand A/C	42.08	22.43	93	8620-250	47	27.5	94.5	220
K60A2 - SASO 11.5EER High Eff. Rt. Hand A/C	42.08	22.43	93	8620-250	47	27.5	94.5	220
K36L2 - SASO 11.5EER High Eff. Lt. Hand A/C	42.08	22.43	84.88	8620-234	47	27.5	90.5	170
K48L2 - SASO 11.5EER High Eff. Lt. Hand A/C	42.08	22.43	93	8620-250	47	27.5	94.5	220
K60L2 - SASO 11.5EER High Eff. Lt. Hand A/C	42.08	22.43	93	8620-250	47	27.5	94.5	220
T24H1 - High Eff. Single Stage Quiet Climate H/P	38.2	17.13	70.56	8620-232	43	22.5	76.5	124
T30H1 - High Eff. Single Stage Quiet Climate H/P	38.2	17.13	70.56	8620-232	43	22.5	76.5	124
T36H1 - High Eff. Single Stage Quiet Climate H/P	42.08	22.43	84.88	8620-234	47	27.5	90.5	170
T42H1 - High Eff. Single Stage Quiet Climate H/P	42.08	22.43	84.88	8620-234	47	27.5	90.5	170
T48H1 - High Eff. Single Stage Quiet Climate H/P	42.08	22.43	93	8620-250	47	27.5	94.5	220
T60H1 - High Eff. Single Stage Quiet Climate H/P	42.08	22.43	93	8620-250	47	27.5	94.5	220
T30S2 - High Eff. Step Capacity Quiet Climate H/P	38.2	17.13	70.56	8620-232	43	22.5	76.5	124
T30S1 - High Eff. Step Capacity Quiet Climate H/P	38.2	17.13	70.56	8620-232	43	22.5	76.5	124
T36S1 - High Eff. Step Capacity Quiet Climate H/P	42.08	22.43	84.88	8620-234	47	27.5	90.5	170
T42S1 - High Eff. Step Capacity Quiet Climate H/P	42.08	22.43	84.88	8620-234	47	27.5	90.5	170
T48S1 - High Eff. Step Capacity Quiet Climate H/P	42.08	22.43	93	8620-250	47	27.5	94.5	220
T60S1 - High Eff. Step Capacity Quiet Climate H/P	42.08	22.43	93	8620-250	47	27.5	94.5	220
W12AA - 10EER Right Hand Air Conditioners	30.13	14.63	48	Not Available				
W12AB - 11EER Right Hand Air Conditioners	30.13	14.63	48	Not Available				
W17A2 - 9EER Right Hand Air Conditioners	33.3	17.13	70.56	8620-231	38	22.5	76.5	110
W18A2 - 9EER Right Hand Air Conditioners	33.3	17.13	70.56	8620-231	38	22.5	76.5	110
W18AA - 10EER Right Hand Air Conditioners	33.3	17.125	74.563	8620-263	38	22.5	80.5	
	33.3	24.13	74.563	8620-275, With "Y" or "Z" Economizer With Factory Installed 7" Hood*	37	28.5	80	
W18AB - 11EER Right Hand Air Conditioners	33.3	17.125	74.563	8620-263	38	22.5	80.5	
	33.3	24.13	74.563	8620-275, With "Z" Economizer With Factory Installed 7" Hood*	37	28.5	80	

Shipping Crate Matrix	Wall Mount Unit Dimensions			Crate Part #	Shipping Crate Dimensions			Shipping Crate Weight
	Unit Width	Unit Depth	Unit Height		Crate Width	Crate Depth	Crate Height	
W24A2 - 9EER Right Hand Air Conditioners	33.3	17.13	70.56	8620-231	38	22.5	76.5	110
W24AA - 10EER Right Hand Air Conditioners	33.3	24.13	74.563	8620-263	38	22.5	80.5	
W24AB - 11EER Right Hand Air Conditioners	33.3	17.125	74.563	8620-275, With "Y" or "Z" Economizer With Factory Installed 7" Hood*	37	28.5	80	
W30A2 - 9EER Right Hand Air Conditioners	33.3	24.13	74.563	8620-263	38	22.5	80.5	
W30AA - 10EER Right Hand Air Conditioners	33.3	24.13	74.563	8620-275, With "Z" Economizer With Factory Installed 7" Hood*	37	28.5	80	
W30AB - 11EER Right Hand Air Conditioners	38.2	17.13	70.56	8620-232	43	22.5	76.5	124
W30AA - 10EER Right Hand Air Conditioners	38.2	17.125	74.563	8620-262	43	22.5	80.5	132
W30AB - 11EER Right Hand Air Conditioners	38.2	24.13	74.563	8620-276, With "Y" or "Z" Economizer With Factory Installed 7" Hood*	42	28.5	80	
W30AB - 11EER Right Hand Air Conditioners	38.2	17.125	74.563	8620-262	43	22.5	80.5	132
W30AB - 11EER Right Hand Air Conditioners	38.2	24.13	74.563	8620-276, With "Z" Economizer With Factory Installed 7" Hood*	42	28.5	80	
W36A2 - 9EER Right Hand Air Conditioners	38.2	17.13	70.56	8620-232	43	22.5	76.5	124
W36AA - 10EER Right Hand Air Conditioners	38.2	17.125	74.563	8620-262	43	22.5	80.5	132
W36AB - 11EER Right Hand Air Conditioners	38.2	24.13	74.563	8620-276, With "Y" or "Z" Economizer With Factory Installed 7" Hood*	42	28.5	80	
W36AB - 11EER Right Hand Air Conditioners	38.2	17.125	74.563	8620-262	43	22.5	80.5	132
W36AB - 11EER Right Hand Air Conditioners	38.2	24.13	74.563	8620-276, With "Z" Economizer With Factory Installed 7" Hood*	42	28.5	80	
W42A2 - 9EER Right Hand Air Conditioners	42.08	22.43	84.88	8620-234	47	27.5	90.5	170
W42AA - 10EER Right Hand Air Conditioners	42.08	22.43	84.88	8620-234	47	27.5	90.5	170
W42AC - 11EER Right Hand Air Conditioners	42.08	29.43	84.88	8620-277, With "Y" or "Z" Economizer With Factory Installed 7" Hood*	46	33.5	90	
W42AC - 11EER Right Hand Air Conditioners	42	25.52	84.88	8620-304	46	29.5	90	
W48A2 - 9EER Right Hand Air Conditioners	42.08	22.43	84.88	8620-234	47	27.5	90.5	170
W48A23 - 9EER Upgrade Rt. Hand A/C	42.08	22.43	84.88	8620-234	47	27.5	90.5	170
W48AA - 10EER Right Hand Air Conditioners	42.08	22.43	84.88	8620-234	47	27.5	90.5	170
W48AA - 10EER Right Hand Air Conditioners	42.08	29.43	84.88	8620-277, With "Y" or "Z" Economizer With Factory Installed 7" Hood*	46	33.5	90	
W48AC - 11EER Right Hand Air Conditioners	42	25.52	84.88	8620-304	46	29.5	90	
W60A2 - 9EER Right Hand Air Conditioners	42.08	22.43	84.88	8620-234	47	27.5	90.5	170
W60A23 - 9EER Upgrade Rt. Hand A/C	42.08	22.43	84.88	8620-234	47	27.5	90.5	170
W60AA - 10EER Right Hand Air Conditioners	42.08	22.43	93	8620-250	47	27.5	94.5	220
W60AB - 10EER Right Hand Air Conditioners	42.08	29.43	93	8620-278, With "Y" or "Z" Economizer With Factory Installed 7" Hood*	46	33.5	99	
W60AC - 11EER Right Hand Air Conditioners	42	25.52	93	8620-305	46	29.5	99	
W70A2 - 9EER Right Hand Air Conditioners	42.08	22.43	84.88	8620-234	47	27.5	90.5	170
W72AB - 10EER Right Hand Air Conditioners	42.08	22.43	93	8620-250	47	27.5	94.5	220
W72AB - 10EER Right Hand Air Conditioners	42.08	29.43	93	8620-278, With "Y" or "Z" Economizer With Factory Installed 7" Hood*	46	33.5	99	240
W72AC - 11EER Right Hand Air Conditioners	42	25.52	93	8620-305	46	29.5	99	
W36G3 - 10EER Single Stage Gas/Electric A/C	38	24.25	81.63	Not Available				
W42G3 - 10EER Single Stage Gas/Electric A/C	42	27.25	97.5	Not Available				
W48G3 - 10EER Single Stage Gas/Electric A/C	42	27.25	97.5	Not Available				
W60G3 - 10EER Single Stage Gas/Electric A/C	42	27.25	97.5	Not Available				
W18H2 - 9EER Right Hand Heat Pumps	33.3	17.13	70.56	8620-231	38	22.5	76.5	110
W18HA - 10EER Right Hand Heat Pumps	33.3	17.125	74.563	8620-263	38	22.5	80.5	
W18HA - 10EER Right Hand Heat Pumps	33.3	24.13	74.563	8620-275, With "Y" or "Z" Economizer With Factory Installed 7" Hood*	38	28.5	80	
W18HB - 11EER Right Hand Heat Pumps	33.3	17.125	74.563	8620-263	38	22.5	80.5	
W18HB - 11EER Right Hand Heat Pumps	33.3	24.13	74.563	8620-275, With "Z" Economizer With Factory Installed 7" Hood*	38	28.5	80	
W24H2 - 9EER Right Hand Heat Pumps	33.3	17.13	70.56	8620-231	38	22.5	76.5	110
W24HA - 10EER Right Hand Heat Pumps	33.3	17.125	74.563	8620-263	38	22.5	80.5	
W24HA - 10EER Right Hand Heat Pumps	33.3	24.13	74.563	8620-275, With "Y" or "Z" Economizer With Factory Installed 7" Hood*	37	28.5	80	
W24HB - 11EER Right Hand Heat Pumps	33.3	17.125	74.563	8620-263	38	22.5	80.5	
W24HB - 11EER Right Hand Heat Pumps	33.3	24.13	74.563	8620-275, With "Z" Economizer With Factory Installed 7" Hood*	37	28.5	80	
W30H2 - 9EER Right Hand Heat Pumps	38.2	17.13	70.56	8620-232	43	22.5	76.5	124
W30HA - 10EER Right Hand Heat Pumps	38.2	17.125	74.563	8620-262	43	22.5	80.5	132

Shipping Crate Matrix	Wall Mount Unit Dimensions			Crate Part #	Shipping Crate Dimensions			Shipping Crate Weight
	Unit Width	Unit Depth	Unit Height		Crate Width	Crate Depth	Crate Height	
W30HA - 10EER Right Hand Heat Pumps	38.2	24.13	74.563	8620-276, With "Y" or "Z" Economizer With Factory Installed 7" Hood*	42	28.5	80	
W30HB - 11EER Right Hand Heat Pumps	38.2	17.125	74.563	8620-262	43	22.5	80.5	132
W36H2 - 9EER Right Hand Heat Pumps	38.2	17.13	70.56	8620-232	43	22.5	76.5	124
W36HA - 10EER Right Hand Heat Pumps	38.2	17.125	74.563	8620-262	43	22.5	80.5	132
W36HB - 11EER Right Hand Heat Pumps	38.2	24.13	74.563	8620-276, With "Y" or "Z" Economizer With Factory Installed 7" Hood*	72	28.5	80	
W36H2 - 9EER Right Hand Heat Pumps	38.2	17.125	74.563	8620-262	43	22.5	80.5	132
W42H2 - 9EER Right Hand Heat Pumps	38.2	24.13	74.563	8620-276 With "Z" Economizer With Factory Installed 7" Hood*	72	28.5	80	
W42HA - 10EER Right Hand Heat Pumps	42.08	22.43	84.88	8620-234	47	27.5	90.5	170
W42HB - 11EER Right Hand Heat Pumps	42.08	22.43	84.88	8620-234	47	27.5	90.5	170
W42HC - 11EER Right Hand Heat Pumps	42.08	29.43	84.88	8620-277, With "Y" or "Z" Economizer With Factory Installed 7" Hood*	46	33.5	90	
W42H2 - 9EER Right Hand Heat Pumps	42	25.52	84.88	8620-304	46	29.5	90	
W48H2 - 9EER Right Hand Heat Pumps	42.08	22.43	84.88	8620-234	47	27.5	90.5	170
W48HA - 10EER Right Hand Heat Pumps	42.08	22.43	84.88	8620-234	47	27.5	90.5	170
W48HB - 11EER Right Hand Heat Pumps	42.08	29.43	84.88	8620-277, With "Y" or "Z" Economizer With Factory Installed 7" Hood*	46	33.5	90	
W48HC - 11EER Right Hand Heat Pumps	42	25.52	84.88	8620-304	46	29.5	90	
W60H2 - 9EER Right Hand Heat Pumps	42.08	22.43	94.88	8620-250	47	27.5	94.5	220
W60HA - 10EER Right Hand Heat Pumps	42.08	22.43	93	8620-250	47	27.5	94.5	220
W60HB - 11EER Right Hand Heat Pumps	42.08	29.43	93	8620-278, With "Y" or "Z" Economizer With Factory Installed 7" Hood*	46	33.5	99	240
W60HC - 11EER Right Hand Heat Pumps	42	25.52	93	8620-305	46	29.5	99	
W17L2 - 9EER Left Hand Air Conditioners	33.3	17.13	70.56	8620-231	38	22.5	76.5	110
W18L2 - 9EER Left Hand Air Conditioners	33.3	17.13	70.56	8620-231	38	22.5	76.5	110
W18LA - 10EER Right Hand Air Conditioners	33.3	17.125	74.563	8620-263	38	22.5	80.5	
W18LB - 11EER Right Hand Air Conditioners	33.3	24.13	74.563	8620-275, With "Y" or "Z" Economizer With Factory Installed 7" Hood*	37	28.5	80	
W18L2 - 9EER Left Hand Air Conditioners	33.3	17.125	74.563	8620-263	38	22.5	80.5	
W24L2 - 9EER Left Hand Air Conditioners	33.3	24.13	74.563	8620-275, With "Z" Economizer With Factory Installed 7" Hood*	37	28.5	80	
W24LA - 10EER Right Hand Air Conditioners	33.3	17.13	70.56	8620-231	38	22.5	76.5	110
W24LB - 11EER Right Hand Air Conditioners	33.3	17.125	74.563	8620-263	38	22.5	80.5	
W24L2 - 9EER Left Hand Air Conditioners	33.3	24.13	74.563	8620-275, With "Y" or "Z" Economizer With Factory Installed 7" Hood*	37	28.5	80	
W24LA - 10EER Right Hand Air Conditioners	33.3	17.125	74.563	8620-263	38	22.5	80.5	
W24LB - 11EER Right Hand Air Conditioners	33.3	24.13	74.563	8620-275, With "Z" Economizer With Factory Installed 7" Hood*	37	28.5	80	
W30L2 - 9EER Left Hand Air Conditioners	38.2	17.13	70.56	8620-232	43	22.5	76.5	124
W30LA - 10EER Right Hand Air Conditioners	38.2	17.125	74.563	8620-262	43	22.5	80.5	132
W30LB - 11EER Right Hand Air Conditioners	38.2	24.13	74.563	8620-276, With "Y" or "Z" Economizer With Factory Installed 7" Hood*	42	28.5	80	
W36L2 - 9EER Left Hand Air Conditioners	38.2	17.125	74.563	8620-262	43	22.5	80.5	132
W36LA - 10EER Right Hand Air Conditioners	38.2	17.13	70.56	8620-232	43	22.5	76.5	124
W36LB - 11EER Right Hand Air Conditioners	38.2	17.125	74.563	8620-262	43	22.5	80.5	132
W36L2 - 9EER Left Hand Air Conditioners	38.2	24.13	74.563	8620-276, With "Y" or "Z" Economizer With Factory Installed 7" Hood*	42	28.5	80	
W42L2 - 9EER Left Hand Air Conditioners	38.2	17.125	74.563	8620-262	43	22.5	80.5	132
W42LA - 10EER Right Hand Air Conditioners	42.08	22.43	84.88	8620-234	47	27.5	90.5	170
W42LB - 11EER Right Hand Air Conditioners	42.08	22.43	84.88	8620-234	47	27.5	90.5	170
W48L2 - 9EER Left Hand Air Conditioners	42.08	29.43	84.88	8620-277, With "Y" or "Z" Economizer With Factory Installed 7" Hood*	46	33.5	90	
W48LA - 10EER Right Hand Air Conditioners	42.08	22.43	84.88	8620-234	47	27.5	90.5	170
W48LB - 11EER Right Hand Air Conditioners	42.08	22.43	84.88	8620-234	47	27.5	90.5	170
W60L2 - 9EER Left Hand Air Conditioners	42.08	29.43	84.88	8620-277, With "Y" or "Z" Economizer With Factory Installed 7" Hood*	46	33.5	90	
W60LA - 10EER Right Hand Air Conditioners	42.08	22.43	84.88	8620-234	47	27.5	90.5	170
W60LB - 11EER Right Hand Air Conditioners	42.08	22.43	93	8620-250	47	27.5	94.5	220

Shipping Crate Matrix	Wall Mount Unit Dimensions			Crate Part #	Shipping Crate Dimensions			Shipping Crate Weight
	Unit Width	Unit Depth	Unit Height		Crate Width	Crate Depth	Crate Height	
W70LB - 10EER Right Hand Air Conditioners	42.08	29.43	93	8620-278, With "Y" or "Z" Economizer With Factory Installed 7" Hood*	46	33.5	99	240
W70L2 - 9EER Left Hand Air Conditioners	42.08	22.43	84.88	8620-234	47	27.5	90.5	170
W72LB - 10EER Right Hand Air Conditioners	42.08	22.43	93	8620-250	47	27.5	94.5	220
	42.08	29.43	93	8620-278, With "Y" or "Z" Economizer With Factory Installed 7" Hood*	46	33.5	99	240
W3LV2 - Variable Cap. 60/50hz Lt. Hand ECU A/C	38.2	17.13	70.56	8620-232	43	22.5	76.5	124
W3RV2 - Variable Cap. 60/50hz Rt. Hand ECU A/C	38.2	17.13	70.56	8620-232	43	22.5	76.5	124
W5LV2 - Variable Cap. 60/50hz Lt. Hand ECU A/C	42.08	22.43	84.88	8620-234	47	27.5	90.5	170
W5RV2 - Variable Cap. 60/50hz Rt. Hand ECU A/C	42.08	22.43	84.88	8620-234	47	27.5	90.5	170
W6LV2 - Variable Cap. 60/50hz Lt. Hand ECU A/C	42.08	22.43	94.88	8620-250	47	27.5	94.5	220
W6RV2 - Variable Cap. 60/50hz Rt. Hand ECU A/C	42.08	22.43	94.88	8620-250	47	27.5	94.5	220
WA3S3 - High Efficiency Rt Hand Step Capacity A/C	42.08	22.43	84.88	8620-234	47	27.5	90.5	170
WA4S3 - High Efficiency Rt Hand Step Capacity A/C	42.08	22.43	94.88	8620-250	47	27.5	94.5	220
WA5S3 - High Efficiency Rt Hand Step Capacity A/C	42.08	22.43	94.88	8620-250	47	27.5	94.5	220
W5SAC - High Efficiency Rt Hand Step Capacity A/C				Not Available				
WG3S2 - 11EER Step Capacity Gas/Electric A/C	42	27.25	87.5	Not Available				
WG4S2 - 11EER Step Capacity Gas/Electric A/C	42	27.25	97.5	Not Available				
WG5S2 - 11EER Step Capacity Gas/Electric A/C	42	27.25	97.5	Not Available				
WL3S2 - High Efficiency Lt Hand Step Capacity A/C	42.08	22.43	84.88	8620-234	47	27.5	90.5	170
WL4S2 - High Efficiency Lt Hand Step Capacity A/C	42.08	22.43	94.88	8620-250	47	27.5	94.5	220
WL5S2 - High Efficiency Lt Hand Step Capacity A/C	42.08	22.43	94.88	8620-250	47	27.5	94.5	220
Notes:								
* Units with Y and Z economizer vent options are shipped with the 7" intake hood installed								
** Units are shipped with ventilation intake hood installed. No crate available at this time.								
								Form: F1988 0819
								Supersedes: 0619