



# 50HZ Export Air Conditioners

## Specification Sheets

### W\*\*A Series Wall-Mount™ Air Conditioners (50hz) (R-410A Refrigerant)

Document #	Tonnage	Description
<a href="#">S3408</a>	2.0 – 6.0	W24A1, W30A1, W36A1, W42A1, W48A1, W60A1, W70A1

### WA Series Wall-Mount™ Air Conditioners (50hz) (R-22 refrigerant)

Document #	Tonnage	Description
<a href="#">S3351</a>	1.0	WA121-G Series (R22)
<a href="#">S3352</a>	2.0 – 6.0	WA242, WA253, WA302, WA372, WA423, WA484, WA602, WA701 (R22)

### WE Series Wall-Mount™ Air Conditioners (50hz) (R-407C Refrigerant)

Document #	Tonnage	Description
<a href="#">S3354</a>	1.0	WE121-G Series (R-407C)
<a href="#">S3355</a>	2.0 – 6.0	WE252, WE301, WE371, WE421, WE482, WE602, WE701 (R-407C)

## Optional Wall-Mount Accessories

Document #	Description
<a href="#">S3370</a>	WUVCLP Series Wall-Mount UV-C Light Package
<a href="#">Grille Link</a>	Supply & Return Air Grille Submittal Information
<a href="#">TechniCoat Link</a>	Phenolic Coated Coil Option Information
<a href="#">Thermostat Link</a>	Bard Thermostat Information & Installation Instructions
<a href="#">Serial Number Link</a>	Bard Serial Number Nomenclature Matrix

### W Series (Right-Hand) Wall-Mount™ A/C (50hz) (R-410A Refrigerant)

Model	Literature Assembly	Installation Manual	Parts Manual	Wiring Diagram
W24A1-D	911-0493	<a href="#">2100-508</a>	<a href="#">2110-483</a>	<a href="#">4095-143</a>
W24A1-F	911-0493	<a href="#">2100-508</a>	<a href="#">2110-483</a>	<a href="#">4095-632</a>
W30A1-D	911-0489	<a href="#">2100-508</a>	<a href="#">2110-482</a>	<a href="#">4095-143</a>
W30A1-F	911-0489	<a href="#">2100-508</a>	<a href="#">2110-482</a>	<a href="#">4095-632</a>
W36A1-D	911-0489	<a href="#">2100-508</a>	<a href="#">2110-482</a>	<a href="#">4095-143</a>
W36A1-E	911-0489	<a href="#">2100-508</a>	<a href="#">2110-482</a>	<a href="#">4095-242</a>
W36A1-F	911-0489	<a href="#">2100-508</a>	<a href="#">2110-482</a>	<a href="#">4095-632</a>
W42A1-E	911-0491	<a href="#">2100-508</a>	<a href="#">2110-481</a>	<a href="#">4095-243</a>
W42A1-F	911-0491	<a href="#">2100-508</a>	<a href="#">2110-481</a>	<a href="#">4095-634</a>



# 50HZ Export Air Conditioners

## W Series (Right-Hand) Wall-Mount™ A/C (50hz) (R-410A Refrigerant)

Model	Literature Assembly	Installation Manual	Parts Manual	Wiring Diagram
W48A1-E	911-0491	<a href="#">2100-508</a>	<a href="#">2110-481</a>	<a href="#">4095-243</a>
W48A1-F	911-0491	<a href="#">2100-508</a>	<a href="#">2110-481</a>	<a href="#">4095-634</a>
W60A1-E	911-0491	<a href="#">2100-508</a>	<a href="#">2110-481</a>	<a href="#">4095-243</a>
W60A1-F	911-0491	<a href="#">2100-508</a>	<a href="#">2110-481</a>	<a href="#">4095-634</a>
Supplemental 50hz Electrical Data For The Above Units			<a href="#">7960-574</a>	

## W Series (Left-Hand) Wall-Mount™ A/C (50hz) (R-410A Refrigerant)

Model	Literature Assembly	Installation Manual	Parts Manual	Wiring Diagram
W24L1-F	911-0494	<a href="#">2100-508</a>	<a href="#">2110-486</a>	<a href="#">4095-632</a>
W36L1-F	911-0490	<a href="#">2100-508</a>	<a href="#">2110-486</a>	<a href="#">4095-632</a>
W42L1-F	911-0497	<a href="#">2100-508</a>	<a href="#">2110-484</a>	<a href="#">4095-634</a>
W48L1-F	911-0497	<a href="#">2100-508</a>	<a href="#">2110-484</a>	<a href="#">4095-634</a>
W60L1-F	911-0497	<a href="#">2100-508</a>	<a href="#">2110-484</a>	<a href="#">4095-634</a>
Supplemental 50hz Electrical Data For The Above Units			<a href="#">7960-574</a>	

## WE Series (Right-Hand) Wall-Mount™ A/C (50hz) (R-407C Refrigerant)

Model	Literature Assembly	Installation Manual	Parts Manual	Wiring Diagram
WE121-G	911-0357	<a href="#">2100-384</a>	<a href="#">2110-447</a>	<a href="#">4095-115(E)</a>
WE252-D	911-0358	<a href="#">2100-385</a>	<a href="#">2110-448</a>	<a href="#">4095-128(C)</a>
WE252-F	911-0358	<a href="#">2100-385</a>	<a href="#">2110-448</a>	<a href="#">4095-620(C)</a>
Supplemental 50hz Electrical Data For The Above Units			<a href="#">7960-457</a>	



# 50HZ Export Air Conditioners

## WE Series (Right-Hand) Wall-Mount™ A/C (50hz) (R-407C Refrigerant)

Model	Literature Assembly	Installation Manual	Parts Manual	Wiring Diagram
WE301-D	911-0359	<a href="#">2100-385</a>	<a href="#">2110-449</a>	<a href="#">4095-128(C)</a>
WE301-F	911-0359	<a href="#">2100-385</a>	<a href="#">2110-449</a>	<a href="#">4095-620(C)</a>
WE371-D	911-0359	<a href="#">2100-385</a>	<a href="#">2110-449</a>	<a href="#">4095-128(C)</a>
WE371-F	911-0359	<a href="#">2100-385</a>	<a href="#">2110-449</a>	<a href="#">4095-620(C)</a>
WE421-F	911-0360	<a href="#">2100-385</a>	<a href="#">2110-450</a>	<a href="#">4095-623(B)</a>
WE482-F	911-0360	<a href="#">2100-385</a>	<a href="#">2110-450</a>	<a href="#">4095-623(B)</a>
WE602-F	911-0360	<a href="#">2100-385</a>	<a href="#">2110-450</a>	<a href="#">4095-623(B)</a>
WE701-F	911-0361	<a href="#">2100-385</a>	<a href="#">2110-451</a>	<a href="#">4095-627(D)</a>
Supplemental 50hz Electrical Data For The Above Units			<a href="#">7960-249</a>	

## WA Series (Right-Hand) Wall-Mount™ A/C (50hz) (R-22 Refrigerant)

Model	Literature Assembly	Installation Manual	Parts Manual	Wiring Diagram
WA121-G	911-0225	<a href="#">2100-234</a>	<a href="#">2110-412</a>	<a href="#">4095-115(E)</a>
WA242-D	911-0333	<a href="#">2100-369</a>	<a href="#">2110-442</a>	<a href="#">4095-130(B)</a>
WA242-F	911-0333	<a href="#">2100-369</a>	<a href="#">2110-442</a>	<a href="#">4095-621(A)</a>
WA253-D	911-0394	<a href="#">2100-406</a>	<a href="#">2110-463</a>	<a href="#">4095-128(C)</a>
WA253-F	911-0394	<a href="#">2100-406</a>	<a href="#">2110-463</a>	<a href="#">4095-620(C)</a>
WA302-D	911-0390	<a href="#">2100-404</a>	<a href="#">2110-461</a>	<a href="#">4095-134</a>
WA302-F	911-0390	<a href="#">2100-404</a>	<a href="#">2110-461</a>	<a href="#">4095-630</a>
WA361-D	911-0174	<a href="#">2100-192</a>	<a href="#">2110-409</a>	<a href="#">4095-130(B)</a>
WA361-E	911-0174	<a href="#">2100-192</a>	<a href="#">2110-409</a>	<a href="#">4095-228(C)</a>
WA361-F	911-0174	<a href="#">2100-192</a>	<a href="#">2110-409</a>	<a href="#">4095-621(A)</a>
WA372-D	911-0394	<a href="#">2100-404</a>	<a href="#">2110-461</a>	<a href="#">4095-134</a>
WA372-E	911-0390	<a href="#">2100-404</a>	<a href="#">2110-461</a>	<a href="#">4095-234</a>
WA372-F	911-0390	<a href="#">2100-404</a>	<a href="#">2110-461</a>	<a href="#">4095-630</a>
WA423-E	911-0370	<a href="#">2100-503</a>	<a href="#">2110-452</a>	<a href="#">4095-238</a>
WA423-F	911-0370	<a href="#">2100-503</a>	<a href="#">2110-452</a>	<a href="#">4095-631</a>
WA484-E	911-0370	<a href="#">2100-503</a>	<a href="#">2110-452</a>	<a href="#">4095-229(C)</a>
WA484-F	911-0370	<a href="#">2100-503</a>	<a href="#">2110-452</a>	<a href="#">4095-623(B)</a>
WA602-E	911-0370	<a href="#">2100-503</a>	<a href="#">2110-452</a>	<a href="#">4095-229(C)</a>
WA602-F	911-0370	<a href="#">2100-503</a>	<a href="#">2110-452</a>	<a href="#">4095-623(B)</a>
WA701-F	911-0414	<a href="#">2100-425</a>	<a href="#">2110-466</a>	<a href="#">4095-627(D)</a>
Supplemental 50hz Electrical Data For The Above Units			<a href="#">7960-482</a>	



# 50HZ Export Air Conditioners

## WL Series (Left-Hand) Wall-Mount™ A/C (50hz) (R-22 Refrigerant)

Model	Literature Assembly	Installation Manual	Parts Manual	Wiring Diagram
WL242-F	911-0340	<a href="#">2100-370</a>	<a href="#">2110-444</a>	<a href="#">4095-621(A)</a>
WL253-F	911-0396	<a href="#">2100-407</a>	<a href="#">2110-464</a>	<a href="#">4095-620(C)</a>
WL361-D	911-0234	<a href="#">2100-272</a>	<a href="#">2110-416</a>	<a href="#">4095-130(B)</a>
WL361-F	911-0234	<a href="#">2100-272</a>	<a href="#">2110-416</a>	<a href="#">4095-621(A)</a>
WL372-F	911-0392	<a href="#">2100-405</a>	<a href="#">2110-462</a>	<a href="#">4095-630</a>
WL602-F	911-0237	<a href="#">2100-277</a>	<a href="#">2110-419</a>	<a href="#">4095-623(B)</a>
Supplemental 50hz Electrical Data For The Above Units			<a href="#">7960-482</a>	

## WA Series Hot-Gas By-Pass Wall-Mount™ A/C (50hz) (R-22 Refrigerant)

Model	Literature Assembly	Installation Manual	Parts Manual	Wiring Diagram
WA361HF	911-0175	<a href="#">2100-192</a>	<a href="#">2110-409</a>	<a href="#">4095-621(A)</a>
Supplemental Hot Gas Bypass Manual For The Above			<a href="#">2100-209</a>	
WA484HF	911-0371	<a href="#">2100-398</a>	<a href="#">2110-453</a>	<a href="#">4095-624(B)</a>
WA602HF	911-0371	<a href="#">2100-398</a>	<a href="#">2110-453</a>	<a href="#">4095-624(B)</a>
Supplemental Hot Gas Bypass Manual For The Above			<a href="#">2100-235</a>	