



50HZ Export Air Conditioners

Specification Sheets

W**A Series Wall-Mount™ Air Conditioners (50hz) (R-410A Refrigerant)

Document #	Description
S3408	W24A1, W30A1, W36A1, W42A1, W48A1, W60A1, W70A1

WA Series Wall-Mount™ Air Conditioners (50hz) (R-22 refrigerant)

Document #	Description
S3351	WA121-G Series (R22)
S3352	WA242, WA253, WA302, WA372, WA423, WA484, WA602, WA701 (R22)

WE Series Wall-Mount™ Air Conditioners (50hz) (R-407C Refrigerant)

Document #	Description
S3354	WE121-G Series (R-407C)
S3355	WE252, WE301, WE371, WE421, WE482, WE602, WE701 (R-407C)

Optional Wall-Mount Accessories

Document #	Description
S3370	WUVCLP Series Wall-Mount UV-C Light Package
Grille Link	Supply & Return Air Grille Submittal Information
TechniCoat Link	Phenolic Coated Coil Option Information
Thermostat Link	Bard Thermostat Information & Installation Instructions
Serial Number Link	Bard Serial Number Nomenclature Matrix

W Series (Right-Hand) Wall-Mount™ A/C (50hz) (R-410A Refrigerant)

Model	Literature Assembly	Installation Manual	Parts Manual	Wiring Diagram
W24A1-D	911-0493	2100-508	2110-483	4095-143
W24A1-F	911-0493	2100-508	2110-483	4095-632
W30A1-D	911-0489	2100-508	2110-482	4095-143
W30A1-F	911-0489	2100-508	2110-482	4095-632
W36A1-D	911-0489	2100-508	2110-482	4095-143
W36A1-E	911-0489	2100-508	2110-482	4095-242
W36A1-F	911-0489	2100-508	2110-482	4095-632
W42A1-E	911-0491	2100-508	2110-481	4095-243
W42A1-F	911-0491	2100-508	2110-481	4095-634



50HZ Export Air Conditioners

W Series (Right-Hand) Wall-Mount™ A/C (50hz) (R-410A Refrigerant)

Model	Literature Assembly	Installation Manual	Parts Manual	Wiring Diagram
W48A1-E	911-0491	2100-508	2110-481	4095-243
W48A1-F	911-0491	2100-508	2110-481	4095-634
W60A1-E	911-0491	2100-508	2110-481	4095-243
W60A1-F	911-0491	2100-508	2110-481	4095-634
Supplemental 50hz Electrical Data For The Above Units			7960-574	

W Series (Left-Hand) Wall-Mount™ A/C (50hz) (R-410A Refrigerant)

Model	Literature Assembly	Installation Manual	Parts Manual	Wiring Diagram
W24L1-F	911-0494	2100-508	2110-486	4095-632
W36L1-F	911-0490	2100-508	2110-486	4095-632
W42L1-F	911-0497	2100-508	2110-484	4095-634
W48L1-F	911-0497	2100-508	2110-484	4095-634
W60L1-F	911-0497	2100-508	2110-484	4095-634
Supplemental 50hz Electrical Data For The Above Units			7960-574	

WE Series (Right-Hand) Wall-Mount™ A/C (50hz) (R-407C Refrigerant)

Model	Literature Assembly	Installation Manual	Parts Manual	Wiring Diagram
WE121-G	911-0357	2100-384	2110-447	4095-115(E)
WE252-D	911-0358	2100-385	2110-448	4095-128(C)
WE252-F	911-0358	2100-385	2110-448	4095-620(C)
Supplemental 50hz Electrical Data For The Above Units			7960-457	



50HZ Export Air Conditioners

WE Series (Right-Hand) Wall-Mount™ A/C (50hz) (R-407C Refrigerant)

Model	Literature Assembly	Installation Manual	Parts Manual	Wiring Diagram
WE301-D	911-0359	2100-385	2110-449	4095-128(C)
WE301-F	911-0359	2100-385	2110-449	4095-620(C)
WE371-D	911-0359	2100-385	2110-449	4095-128(C)
WE371-F	911-0359	2100-385	2110-449	4095-620(C)
WE421-F	911-0360	2100-385	2110-450	4095-623(B)
WE482-F	911-0360	2100-385	2110-450	4095-623(B)
WE602-F	911-0360	2100-385	2110-450	4095-623(B)
WE701-F	911-0361	2100-385	2110-451	4095-627(D)
Supplemental 50hz Electrical Data For The Above Units			7960-249	

WA Series (Right-Hand) Wall-Mount™ A/C (50hz) (R-22 Refrigerant)

Model	Literature Assembly	Installation Manual	Parts Manual	Wiring Diagram
WA121-G	911-0225	2100-234	2110-412	4095-115(E)
WA242-D	911-0333	2100-369	2110-442	4095-130(B)
WA242-F	911-0333	2100-369	2110-442	4095-621(A)
WA253-D	911-0394	2100-406	2110-463	4095-128(C)
WA253-F	911-0394	2100-406	2110-463	4095-620(C)
WA302-D	911-0390	2100-404	2110-461	4095-134
WA302-F	911-0390	2100-404	2110-461	4095-630
WA361-D	911-0174	2100-192	2110-409	4095-130(B)
WA361-E	911-0174	2100-192	2110-409	4095-228(C)
WA361-F	911-0174	2100-192	2110-409	4095-621(A)
WA372-D	911-0394	2100-404	2110-461	4095-134
WA372-E	911-0390	2100-404	2110-461	4095-234
WA372-F	911-0390	2100-404	2110-461	4095-630
WA423-E	911-0370	2100-503	2110-452	4095-238
WA423-F	911-0370	2100-503	2110-452	4095-631
WA484-E	911-0370	2100-503	2110-452	4095-229(C)
WA484-F	911-0370	2100-503	2110-452	4095-623(B)
WA602-E	911-0370	2100-503	2110-452	4095-229(C)
WA602-F	911-0370	2100-503	2110-452	4095-623(B)
WA701-F	911-0414	2100-425	2110-466	4095-627(D)
Supplemental 50hz Electrical Data For The Above Units			7960-482	



50HZ Export Air Conditioners

WL Series (Left-Hand) Wall-Mount™ A/C (50hz) (R-22 Refrigerant)

Model	Literature Assembly	Installation Manual	Parts Manual	Wiring Diagram
WL242-F	911-0340	2100-370	2110-444	4095-621(A)
WL253-F	911-0396	2100-407	2110-464	4095-620(C)
WL361-D	911-0234	2100-272	2110-416	4095-130(B)
WL361-F	911-0234	2100-272	2110-416	4095-621(A)
WL372-F	911-0392	2100-405	2110-462	4095-630
WL602-F	911-0237	2100-277	2110-419	4095-623(B)
Supplemental 50hz Electrical Data For The Above Units			7960-482	

WA Series Hot-Gas By-Pass Wall-Mount™ A/C (50hz) (R-22 Refrigerant)

Model	Literature Assembly	Installation Manual	Parts Manual	Wiring Diagram
WA361HF	911-0175	2100-192	2110-409	4095-621(A)
Supplemental Hot Gas Bypass Manual For The Above			2100-209	
WA484HF	911-0371	2100-398	2110-453	4095-624(B)
WA602HF	911-0371	2100-398	2110-453	4095-624(B)
Supplemental Hot Gas Bypass Manual For The Above			2100-235	