



Wall-Furnace Units

Specification Sheets

Document #	Description
S3393	WF Series Wall-Mount Gas Furnace Series Specification
F1403	WERV Energy Recovery Technical Guide
F1722	Wall-Mount™ Ventilation Overview
Color Link	Bard Wall-Mount Cabinet Finishes
Grille Link	Supply & Return Grille Submittal Information
Thermostat Link	Bard Thermostat Information & Installation Instructions
Serial Number Link	Bard Serial Number Nomenclature Matrix
Warranty Link	Bard Limited Warranty (USA, Canada & Mexico)

WF Series Wall-Mount Gas Furnace

Models	Literature Assembly	Installation Manual	Parts Manual	Wiring Diagram
WF0501-K	911-0473	2100-486	2110-879	4046-160(A)
WF0751-K	911-0473	2100-486	2110-879	4046-160(A)
WF1001-K	911-0473	2100-486	2110-879	4046-160(A)
WF1251-K	911-0473	2100-486	2110-879	4046-160(A)
WF0501-A	911-0473	2100-486	2110-879	4046-159(A)
WF0751-A	911-0473	2100-486	2110-879	4046-159(A)
WF1001-A	911-0473	2100-486	2110-879	4046-159(A)
WF1251-A	911-0473	2100-486 2100-496	2110-879	4046-159(A) User Information Guide