



Gas/Electric Wall-Mounts

Specification Sheets

Document #	Tonnage	Description
S3422		Company Brochure
S3396	3.0 – 5.0	WG3S1 – WG5S1 Step Capacity Gas/Electric Specification ~ R-410A
F1918	3.0 – 5.0	WG3S-WG5S Series Engineering Specification Guide ~ R-410A (F1918-Word)
S3418	2.0 – 5.0	W24G1 – W60G1 Series Gas/Electric Specification ~ R-410A
F1917	2.0 – 5.0	WG3S-WG5S Series Engineering Specification Guide ~ R-410A (F1917-Word)
7960-611	2.0 – 5.0	W24G1D-W60G1D Dehumidification Performance Data ~ R-410A
S3344	2.0 – 5.0	WG242-WG602 Gas/Electric Series Specification ~ R-22
F1753	2.0 – 5.0	WG242D-WG602D Dehumidification Performance Data ~ R-22
7960-464		VVK-5A Vertical Vent Kit
F1770		WGWC3 Series Wall Curb (For use with WG / WAG Series Units)
7960-493		WGWC3 Series Wall Curb Installation Instructions
F1848		Bard Wall-Mount™ Control Module Applications
F1403		WERV Energy Recovery Technical Guide
F1722		Wall-Mount™ Ventilation Overview
Vent Opt Link		Wall-Mount™ Ventilation Options
Color Link		Bard Wall-Mount Cabinet Finishes
Grille Link		Supply & Return Grille Submittal Information
TechniCoat Link		Phenolic Coated Coil Option Information
Thermostat Link		Bard Thermostat Information & Installation Instructions
Case Study Link		Bard Project Case Studies
Serial Number Link		Bard Serial Number Nomenclature Matrix
Warranty Link		Bard Limited Warranty (USA, Canada & Mexico)

WG*S Step Capacity Series Gas/Electric Wall-Mount A/C ~ R-410A

Models	Literature Assembly	Installation Manual	Parts Manual	Wiring Diagram
WG3S1-A	911-0472	2100-483	2110-807	4085-140(B)
WG3S1-B	911-0472	2100-483	2110-807	4085-240(B)
WG3S1-C	911-0472	2100-483	2110-807	4085-361(B)
WG4S1-A	911-0472	2100-483	2110-807	4085-140(B)
WG4S1-B	911-0472	2100-483	2110-807	4085-240(B)
WG4S1-C	911-0472	2100-483	2110-807	4085-361(B)
WG5S1-A	911-0472	2100-483	2110-807	4085-140(B)
WG5S1-B	911-0472	2100-483	2110-807	4085-240(B)
WG5S1-C	911-0472	2100-483	2110-807	4085-361(B)



Gas/Electric Wall-Mounts

[2100-367](#)
[2100-366](#)

WG Trouble Shooting Manual
WG User Information Guide

W**G Series Gas/Electric Air Conditioners ~ R-410A (Standard)

Models	Literature Assembly	Installation Manual	Parts Manual	Wiring Diagram
W24G1-A	911-0517	2100-525	2110-808	4085-144
W24G1-B	911-0517	2100-525	2110-808	4085-244
W24G1-C	911-0517	2100-525	2110-808	4085-365
W30G1-A	911-0517	2100-525	2110-808	4085-146
W30G1-B	911-0517	2100-525	2110-808	4085-246
W30G1-C	911-0517	2100-525	2110-808	4085-367
W36G1-A	911-0517	2100-525	2110-808	4085-146
W36G1-B	911-0517	2100-525	2110-808	4085-246
W36G1-C	911-0517	2100-525	2110-808	4085-367
W42G1-A	911-0518	2100-525	2110-809	4085-146
W42G1-B	911-0518	2100-525	2110-809	4085-246
W42G1-C	911-0518	2100-525	2110-809	4085-367
W48G1-A	911-0518	2100-525	2110-809	4085-148
W48G1-B	911-0518	2100-525	2110-809	4085-248
W48G1-C	911-0518	2100-525	2110-809	4085-369
W60G1-A	911-0518	2100-525	2110-809	4085-148
W60G1-B	911-0518	2100-525	2110-809	4085-248
W60G1-C	911-0518	2100-525	2110-809	4085-369
		2100-367		W**G Trouble Shooting Manual
		2100-366		W**G User Information Guide



Gas/Electric Wall-Mounts

W**G*D Series Gas/Electric Air Conditioners (Dehumidification)

Models	Literature Assembly	Installation Manual	Parts Manual	Wiring Diagram
W24G1DA	911-0528	2100-535	2110-810	4085-149
W24G1DB	911-0528	2100-535	2110-810	4085-249
W24G1DC	911-0528	2100-535	2110-810	4085-349
W30G1DA	911-0528	2100-535	2110-810	4085-151
W30G1DB	911-0528	2100-535	2110-810	4085-251
W30G1DC	911-0528	2100-535	2110-810	4085-373
W36G1DA	911-0528	2100-535	2110-810	4085-151
W36G1DB	911-0528	2100-535	2110-810	4085-251
W36G1DC	911-0528	2100-535	2110-810	4085-373
W42G1DA	911-0529	2100-535	2110-811	4085-151
W42G1DB	911-0529	2100-535	2110-811	4085-251
W42G1DC	911-0529	2100-535	2110-811	4085-373
W48G1DA	911-0529	2100-535	2110-811	4085-153
W48G1DB	911-0529	2100-535	2110-811	4085-253
W48G1DC	911-0529	2100-535	2110-811	4085-375
W60G1DA	911-0529	2100-535	2110-811	4085-153
W60G1DB	911-0529	2100-535	2110-811	4085-253
W60G1DC	911-0529	2100-535	2110-811	4085-375
		2100-367		
		2100-366		

W**G Trouble Shooting Manual
W**G User Information Guide



Gas/Electric Wall-Mounts

WG Series Gas/Electric Conditioners ~ (Standard) - R-22

Models	Literature Assembly	Installation Manual	Parts Manual	Wiring Diagram
WG242-A	911-0454	2100-365	2110-805	4085-134(A)
WG242-B	911-0454	2100-365	2110-805	4085-234(A)
WG243-C	911-0454	2100-365	2110-805	4085-341
WG302-A	911-0454	2100-365	2110-805	4085-130(E)
WG302-B	911-0454	2100-365	2110-805	4085-230(G)
WG303-C	911-0454	2100-365	2110-805	4085-327(E)
WG362-A	911-0457	2100-365	2110-805	4085-138(A)
WG362-B	911-0457	2100-365	2110-805	4085-238(A)
WG363-C	911-0457	2100-365	2110-805	4085-345
WG423-A	911-0457	2100-365	2110-803	4085-126(D)
WG423-B	911-0457	2100-365	2110-803	4085-226(D)
WG424-C	911-0457	2100-365	2110-803	4085-347
WG482-A	911-0457	2100-365	2110-803	4085-120(E)
WG482-B	911-0457	2100-365	2110-803	4085-220(D)
WG483-C	911-0457	2100-365	2110-803	4085-349
WG602-A	911-0457	2100-365	2110-803	4085-120(E)
WG602-B	911-0457	2100-365	2110-803	4085-220(D)
WG603-C	911-0457	2100-365	2110-803	4085-349
		2100-367		WG Trouble Shooting Manual
		2100-366		WG User Information Guide



Gas/Electric Wall-Mounts

WG Series Gas/Electric Air Conditioners (Dehumidification) – R-22

Models	Literature Assembly	Installation Manual	Parts Manual	Wiring Diagram
WG242DA	911-0455	2100-376	2110-806	4085-136(A)
WG242DB	911-0455	2100-376	2110-806	4085-236(A)
WG243DC	911-0455	2100-376	2110-806	4085-337(A)
WG302DA	911-0455	2100-376	2110-806	4085-133(F)
WG302DB	911-0455	2100-376	2110-806	4085-233(F)
WG303DC	911-0455	2100-376	2110-806	4085-333(F)
WG362DA	911-0455	2100-376	2110-806	4085-139(A)
WG362DB	911-0455	2100-376	2110-806	4085-239(A)
WG363DC	911-0455	2100-376	2110-806	4085-355
WG423DA	911-0458	2100-376	2110-804	4085-128(F)
WG423DB	911-0458	2100-376	2110-804	4085-228(F)
WG424DC	911-0458	2100-376	2110-804	4085-356
WG482DA	911-0458	2100-376	2110-804	4085-124(E)
WG482DB	911-0458	2100-376	2110-804	4085-222(F)
WG483DC	911-0458	2100-376	2110-804	4085-358
WG602DA	911-0458	2100-376	2110-804	4085-124(E)
WG602DB	911-0458	2100-376	2110-804	4085-222(F)
WG603DC	911-0458	2100-376	2110-804	4085-358
		2100-367		WG Trouble Shooting Manual
		2100-366		WG User Information Guide