



- ⚠ 1 Capacitor provides off-cycle crankcase heat.
- ⚠ 2 See alternate thermostat sheet. Set heat anticipator at .40A for both Stage 1 and Stage 2.

Fused Disconnect Switch

USE COPPER OR ALUMINUM WIRE

230/208V 60 Hz 1-Ph

Model P36A3 w/10Kw

Factory Wiring ———
Field Wiring - - - - -