



- ⚠ Capacitor provides off-cycle crankcase heat.
- ⚠ See alternate thermostat sheet. Set heat anticipator at .40A.

Fused Disconnect Switch

USE COPPER OR ALUMINUM WIRE

NEW DIAGRAM
ADD TO FILE
 DATE 5-4-84

Model
 P36A4
 w/SKW

230/208V 60Hz 1-Ph

Factory Wiring ———
 Field Wiring - - - - -