



Fused Disconnect Switch

415/380-50-3

USE COPPER OR ALUMINUM WIRE

- 1 Add jumper Rc to Rh. Set heat anticipators at .40A.
- 2 Remove jumper for 2-stage heat.
- 3 Set heat anticipators for W1 and W2 at .40A.

Single Package Air Conditioner
4 and 5 Ton
4.5, 6.75, 9kw @415V

Factory Wiring ———
Field Wiring - - - - -