


⚠ Capacitor provides off-cycle crankcase heat.

MODEL	CAPACITOR A	CAPACITOR B
PH31-1	35/370V	20/370V
PH36-2	40/370V	25/370V

See Installation Manual for 24V
Thermostat Wiring and Thermostat
Functions.



230/208-60-1

USE COPPER OR ALUMINUM WIRE

MODELS
PH31-1, PH36-2
Heat Pump
w/5Kw

4005-120 C

045