


- ⚠ Capacitor provides off-cycle crankcase heat.
- ⚠ 2nd heat contactor operates only during emergency heat or compressor cut-off.

MODEL	CAPACITOR A	CAPACITOR B
PH31-1	35/370V	30/370V
PH36-2	40/370V	25/370V



See Installation Manual for 24V
Thermostat Wiring and Thermostat
Functions

24V
Terminal
Block

See
Note
⚠

USE COPPER OR
ALUMINUM WIRE

230/208-60-1

Fuse A - 60A Time Delay
Fuse B - 60A Standard

Factory Wiring ———
Field Wiring - - - -

MODELS
PH31-1, PH36-2
Heat Pump
w/15Kw

4005-140G