

⚠ Capacitor provides off-cycle crankcase heat.

⚠ 2nd heat contactor operates only during emergency heat or compressor cut-off.

MODEL	CAPACITOR A	CAPACITOR B
PH31-1	35/370V	30/370V
PH36-2	40/370V	25/370V

