


⚠ Capacitor provides off-cycle crankcase heat.



See Installation Manual for 24V Thermostat Wiring and Thermostat Functions.

24V Terminal Block

Compressor Contactor

Reversing Valve Solenoid (124V)

Defrost Thermostat

Terminal Block

Fused Disconnect Switch

240/220-50-1

USE COPPER OR ALUMINUM WIRE

Factory Wiring ———
Field Wiring - - - - -

MODELS
PH36-2
Heat Pump
w/10kw

4005-430 B