



USE COPPER OR ALUMINUM WIRE

- ⚠️ 1 Capacitor provides off-cycle crankcase heat.
- ⚠️ 2 See alternate thermostat sheet. Set heat anticipator at .40A.

Fused Disconnect Switch

230/208-60-1

Models
20WA1 & 24WA2
w/8 or 10Kw

Factory Wiring _____
Field Wiring - - - - -