



USE COPPER OR ALUMINUM WIRE

- ⚠ 1 3-terminal capacitor provides off-cycle crankcase heat.
- ⚠ 2 This wire omitted and 2-terminal capacitor used on model 18WA1 and 20WA.
- ⚠ 3 See alternate thermostat sheet. Set heat anticipator at .40A.

Models  
18WA1, 20WA, 24WA1  
w/B or 10kw

Factory Wiring \_\_\_\_\_  
Field Wiring - - - - -