



USE COPPER OR ALUMINUM WIRE

- ① 3-terminal capacitor provides off-cycle crankcase heat.
- ② This wire omitted and 2-terminal capacitor used on model 18WA1 and 20WA.
- ③ See alternate thermostat sheet. Set heat anticipator at .40A

Models
18WA1, 20WA, 24WA1
w/4 or 5KW

factory Wiring ———
field Wiring - - - - -