



USE COPPER OR ALUMINUM WIRE

- ⚠ 1 3-terminal capacitor provides off-cycle crankcase heat.
- ⚠ 2 This wire omitted and 2-terminal capacitor used on model 18WA1 and 20WA.
- ⚠ 3 See alternate thermostat sheet. Set heat anticipator at .40A for W1 and W2.
- ⚠ 4 Add jumper Rc to Rh.

Fused Disconnect Switch

230V 60Hz 1-Ph

Models  
18WA1, 20WA, 24WA1  
w/8 or 10kw

Post-it® Fax Note	7671	Date	1/20/00	# of pages	1
To	BRAD	From			
Co./Dept.		Co.	BARD MFG CO		
Phone #	360-855-3509	Phone #			
Fax #		Fax #			

Factory Wiring  
Field Wiring