



USE COPPER CONDUCTORS ONLY

- ⚠ Capacitor provides off-cycle crankcase heat.
- ⚠ For 208V operation move this wire to 208V transformer tap.

Fused Disconnect Switch

230/208-60-1

MODELS
20WA1 & 24WA2

Factory Wiring _____
Field Wiring - - - - -