


CHART A		
42WA	49WA	60WA
35/440	40/440	45/440

Immersion Crankcase Heater



Fused Disconnect Switch

230/208-60-1

USE COPPER OR ALUMINUM WIRE

⚠ For 208V operation move this wire to 208V transformer tap.

Factory Wiring \_\_\_\_\_  
Field Wiring - - - - -

4010-110 N