



(See Chart A) Fuse Panel

USE COPPER OR ALUMINUM WIRE

230/208-60-3

**CHART A**

	42WH-3	48WH5-3
Fuse A	40A T.D.	45A T.D.
Fuse B	60A Standard	

ALL FUSES CLASS K5

**FACTORY WIRING**      **FIELD WIRING**

Low Voltage ————  
High Voltage - - - - -

⚠ If there is an X1 and X2 terminal on Q674L1181, jumper them together and connect from C to either one.

MODEL 42WH-3, 48WH5-3  
HEAT PUMP w/18KW

⚠ For 208V operation move this wire to 208V transformer tap.

4014-240T